

SERVICE MANUAL

P170SM-A

notebook



Notebook Computer

P170SM-A

Service Manual

Notice

The company reserves the right to revise this publication or to change its contents without notice. Information contained herein is for reference only and does not constitute a commitment on the part of the manufacturer or any subsequent vendor. They assume no responsibility or liability for any errors or inaccuracies that may appear in this publication nor are they in anyway responsible for any loss or damage resulting from the use (or misuse) of this publication.

This publication and any accompanying software may not, in whole or in part, be reproduced, translated, transmitted or reduced to any machine readable form without prior consent from the vendor, manufacturer or creators of this publication, except for copies kept by the user for backup purposes.

Brand and product names mentioned in this publication may or may not be copyrights and/or registered trademarks of their respective companies. They are mentioned for identification purposes only and are not intended as an endorsement of that product or its manufacturer.

Version 1.0
March 2014

Trademarks

Intel and **Intel Core** are trademarks of Intel Corporation.

Windows[®] is a registered trademark of Microsoft Corporation.

Other brand and product names are trademarks and/or registered trademarks of their respective companies.

About this Manual

This manual is intended for service personnel who have completed sufficient training to undertake the maintenance and inspection of personal computers.

It is organized to allow you to look up basic information for servicing and/or upgrading components of the ***P170SM-A*** series notebook PC.

The following information is included:

Chapter 1, Introduction, provides general information about the location of system elements and their specifications.
Chapter 2, Disassembly, provides step-by-step instructions for disassembling parts and subsystems and how to upgrade elements of the system.

Appendix A, Part Lists

Appendix B, Schematic Diagrams

Appendix C, Updating the FLASH ROM BIOS

Preface

IMPORTANT SAFETY INSTRUCTIONS

Follow basic safety precautions, including those listed below, to reduce the risk of fire, electric shock and injury to persons when using any electrical equipment:

1. Do not use this product near water, for example near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electrical shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
5. This product is intended to be supplied by a Listed Power Unit with an AC Input of 100 - 240V, 50 - 60Hz, DC Output of 19.5V, 11.8A (**230** Watts) minimum AC/DC Adapter.

CAUTION

This Computer's Optical Device is a Laser Class 1 Product


Instructions for Care and Operation

The notebook computer is quite rugged, but it can be damaged. To prevent this, follow these suggestions:


1. **Don't drop it, or expose it to shock.** If the computer falls, the case and the components could be damaged.



2. **Keep it dry, and don't overheat it.** Keep the computer and power supply away from any kind of heating element. This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.



3. **Follow the proper working procedures for the computer.** Shut the computer down properly and don't forget to save your work. Remember to periodically save your data as data may be lost if the battery is depleted.



Preface



Removal Warning

When removing any cover(s) and screw(s) for the purposes of device upgrade, remember to replace the cover(s) and screw(s) before restoring power to the system.

Also note the following when the cover is removed:


- Hazardous moving parts.
- Keep away from moving fan blades

Power Safety Warning


Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines and power cord). You must also remove your battery in order to prevent accidentally turning the machine on.

4. **Avoid interference.** Keep the computer away from high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage your data.
5. **Take care when using peripheral devices.**

Use only approved brands of peripherals.



Unplug the power cord before attaching peripheral devices.



Power Safety


The computer has specific power requirements:

- Only use a power adapter approved for use with this computer.
- Your AC adapter may be designed for international travel but it still requires a steady, uninterrupted power supply. If you are unsure of your local power specifications, consult your service representative or local power company.
- The power adapter may have either a 2-prong or a 3-prong grounded plug. The third prong is an important safety feature; do not defeat its purpose. If you do not have access to a compatible outlet, have a qualified electrician install one.
- When you want to unplug the power cord, be sure to disconnect it by the plug head, not by its wire.
- Make sure the socket and any extension cord(s) you use can support the total current load of all the connected devices.
- Before cleaning the computer, make sure it is disconnected from any external power supplies.


Do not plug in the power cord if you are wet.



Do not use the power cord if it is broken.



Do not place heavy objects on the power cord.



Battery Precautions

- Only use batteries designed for this computer. The wrong battery type may explode, leak or damage the computer.
- Do not continue to use a battery that has been dropped, or that appears damaged (e.g. bent or twisted) in any way. Even if the computer continues to work with a damaged battery in place, it may cause circuit damage, which may possibly result in fire.
- Recharge the batteries using the notebook's system. Incorrect recharging may make the battery explode.
- Do not try to repair a battery pack. Refer any battery pack repair or replacement to your service representative or qualified service personnel.
- Keep children away from, and promptly dispose of a damaged battery. Always dispose of batteries carefully. Batteries may explode or leak if exposed to fire, or improperly handled or discarded.
- Keep the battery away from metal appliances.
- Affix tape to the battery contacts before disposing of the battery.
- Do not touch the battery contacts with your hands or metal objects.

Battery Guidelines

The following can also apply to any backup batteries you may have.

- If you do not use the battery for an extended period, then remove the battery from the computer for storage.
- Before removing the battery for storage charge it to 60% - 70%.
- Check stored batteries at least every 3 months and charge them to 60% - 70%.



Battery Disposal

The product that you have purchased contains a rechargeable battery. The battery is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal.

Caution

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used battery according to the manufacturer's instructions.

Battery Level

Click the battery icon  in the taskbar to see the current battery level and charge status. A battery that drops below a level of 10% will not allow the computer to boot up. Make sure that any battery that drops below 10% is recharged within one week.

Preface

Related Documents

You may also need to consult the following manual for additional information:

User's Manual on Disc

This describes the notebook PC's features and the procedures for operating the computer and its ROM-based setup program. It also describes the installation and operation of the utility programs provided with the notebook PC.

System Startup

1. Remove all packing materials.
2. Place the computer on a stable surface.
3. Insert the battery and tighten the screws.
4. Securely attach any peripherals you want to use with the computer (e.g. keyboard and mouse) to their ports.
5. Attach the AC/DC adapter to the DC-In jack at the rear of the computer, then plug the AC power cord into an outlet, and connect the AC power cord to the AC/DC adapter.
6. Use one hand to raise the lid/LCD to a comfortable viewing angle (do not to exceed **130** degrees); use the other hand (as illustrated in [Figure 1](#)) to support the base of the computer (**Note: Never** lift the computer by the lid/LCD).
7. Press the power button to turn the computer "on".




Figure 1
**Opening the Lid/LCD/
Computer with AC/DC
Adapter Plugged-In**

Contents

Introduction1-1

Overview	1-1
External Locator - Top View with LCD Panel Open	1-4
External Locator - Front & Right side Views	1-5
External Locator - Left Side & Rear View	1-6
External Locator - Bottom View	1-7
Mainboard Overview - Top (Key Parts)	1-8
Mainboard Overview - Bottom (Key Parts)	1-9
Mainboard Overview - Top (Connectors)	1-10
Mainboard Overview - Bottom (Connectors)	1-11

Disassembly2-1

Overview	2-1
Maintenance Tools	2-2
Connections	2-2
Maintenance Precautions	2-3
Disassembly Steps	2-4
Removing the Battery	2-5
Removing the Hard Disk Drive	2-6
Removing the SSD	2-9
Removing the Optical (CD/DVD) Device	2-10
Removing the Hard Disk from the Secondary HDD Bay	2-12
Removing the Primary System Memory (RAM)	2-14
Removing the Secondary System Memory (RAM)	2-16
Removing the Wireless LAN Module	2-18
Wireless LAN, Combo, 3G & LTE Module Cables	2-19
Removing the MSATA Module	2-20
Removing and Installing the Processor	2-21
Removing and Installing the Video Card	2-24
Removing the CCD	2-27

Removing the Top Cover	2-28
------------------------------	------

Part ListsA-1

Part List Illustration Location	A-2
Top with Fingerprint	A-3
Top without Fingerprint	A-4
Bottom (N15E-GX)	A-5
Bottom (N15P-GX)	A-6
LCD	A-7
COMBO	A-8
DVD-Dual Drive	A-9

Schematic Diagrams.....B-1

Block Diagram	B-2
Processor 1/7	B-3
Processor 2/7	B-4
Processor 3/7	B-5
Processor 4/7	B-6
Processor 5/7	B-7
Processor 6/7	B-8
Processor 7/7	B-9
DDR3 CHA SO-DIMM_0	B-10
DDR3 CHA SO-DIMM_1	B-11
DDR3 CHB SO-DIMM_1	B-12
DDR3 CHB SO-DIMM_0	B-13
MXM PCI-E	B-14
Panel, Inverter, CRT	B-15
PS8625	B-16
1394a_XIO2221	B-17
Display Port	B-18
HDMI	B-19

Preface

Lynix Point 1/9	B-20	Function LED Board	B-52
Lynix Point 2/9	B-21	Indicatory LED Board	B-53
Lynix Point3/9	B-22	P170 2nd HDD Board	B-54
Lynix Point 4/9	B-23	Power & LED Board	B-55
Lynix Point 5/9	B-24	P170 Click Board	B-56
Lynix Point 6/9	B-25	P150 Fingerprint Board	B-57
Lynix Point 7/9	B-26	P170 Fingerprint Board	B-58
Lynix Point 8/9	B-27	P150 2nd HDD Board	B-59
Lynix Point 9/9	B-28	Indicatory LED Board	B-60
USB+eSATA, USB Charging	B-29	Function LED Board	B-61
USB 2.0, CCD, Mini PCIE, LID	B-30	Mini-DP	B-62
LED, Hotkey, LID SW, Fan	B-31	2nd mSATA Board	B-63
RJ 45	B-32	Power on / S4 Resume Seq.	B-64
Codec Realtek ALC892	B-33	S3 Resume Seq.	B-65
APA2607-TPA2008D2	B-34	Into S3 Sequence	B-66
KBC-ITE IT8587A	B-35	Into S4 Sequence	B-67
Backlight Keyboard	B-36	Updating the FLASH ROM BIOS..... C-1	
mSATA, FAN, TP, FP, MULTI-CON	B-37		
Card Reader RTL8411	B-38		
USB 3.0	B-39		
DDR 1.35V/0.75VS PCH 1.5V	B-40		
VDD3, VDD5	B-41		
5V, 5VS, 3.3V, 3.3VS, 1.5VS	B-42		
Power 1.05VS	B-43		
LED 5V	B-44		
Power V-Core 1	B-45		
AC_In, Charger	B-46		
TPM	B-47		
Audio Board	B-48		
P150 ODD Board	B-49		
P150 Click Board	B-50		
Power LED Board	B-51		

Chapter 1: Introduction

Overview

This manual covers the information you need to service or upgrade the **P170SM-A** series notebook computer. Information about operating the computer (e.g. getting started, and the *Setup* utility) is in the *User's Manual*. Information about drivers (e.g. VGA & audio) is also found in *User's Manual*. That manual is shipped with the computer.

Operating systems (e.g. *Windows 8*, etc.) have their own manuals as do application software (e.g. word processing and database programs). If you have questions about those programs, you should consult those manuals.

The **P170SM-A** series notebook is designed to be upgradeable. See [Disassembly on page 2 - 1](#) for a detailed description of the upgrade procedures for each specific component. Please note the warning and safety information indicated by the “” symbol.

The balance of this chapter reviews the computer's technical specifications and features.

Introduction

Specifications



Latest Specification Information

The specifications listed here are correct at the time of sending them to the press. Certain items (particularly processor types/speeds) may be changed, delayed or updated due to the manufacturer's release schedule. Check with your service center for more details.



The CPU is not a user serviceable part. Accessing the CPU in any way may violate your warranty.

Processor Options

Intel® Core™ i7 Processor

i7-4930MX (3.00GHz)

8MB L3 Cache, 22nm, DDR3L-1600MHz, TDP 57W

Intel® Core™ i7 Processor

i7-4900MQ (2.80GHz)

8MB L3 Cache, 22nm, DDR3L-1600MHz, TDP 47W

i7-4800MQ (2.70GHz), i7-4700MQ (2.40GHz)

6MB L3 Cache, 22nm, DDR3L-1600MHz, TDP 47W

i7-4600M (2.90GHz)

4MB L3 Cache, 22nm, DDR3L-1600MHz, TDP 37W

Intel® Core™ i5 Processor

i5-4330M (2.80GHz), i5-4300M (2.60GHz), i5-4200M (2.50GHz)

3MB L3 Cache, 22nm, DDR3L-1600MHz, TDP 37W

Intel® Core™ i3 Processor

i3-4100M (2.50GHz), i3-4000M (2.40GHz)

3MB L3 Cache, 22nm, DDR3L-1600MHz, TDP 37W

LCD

17.3" (43.94cm) FHD LCD

Memory

Four 204 Pin SO-DIMM Sockets Supporting **DDR3L 1600MHz** Memory

(The real memory operating frequency depends on the FSB of the processor.)

Memory Expandable up to 16GB/32GB

Note: Four SO-DIMMs are only supported by Quad-Core CPUs; Dual-Core CPUs support two SO-DIMMs maximum

Core Logic

Intel® HM87 Express Chipset

Security

Security (Kensington® Type) Lock Slot

BIOS Password

(**Factory Option**) Fingerprint Reader Module

(**Factory Option**) TPM 1.2

Storage

(**Factory Option**) One 12.7mm(h) Optical Device Type Drive (Super Multi Drive/Blu-Ray Combo Drive/Blu-Ray Writer Drive)

Two Changeable 2.5" (h) SATA (Serial) Hard Disk Drives (HDDs)/SSDs supporting RAID Level 0/1

(**Factory Option**) Two mSATA Solid State Drives (SSD) supporting RAID Level 0/1

BIOS

AMI BIOS (48Mb SPI Flash-ROM)

Video Adapter

Intel® Integrated GPU and NVIDIA® Discrete GPU

Supports Microsoft Hybrid Graphics

Intel Integrated GPU

Intel HD Graphics 4600

Dynamic Frequency (Intel Dynamic Video Memory Technology for up to **1.7GB**)

Microsoft DirectX® 11 Compatible

NVIDIA® Discrete GPU

NVIDIA® GeForce GTX 860M PCIe Video Card

4GB GDDR5 Video RAM on board

Microsoft DirectX® 11.1 Compatible

NVIDIA® GeForce GTX 870M PCIe Video Card

6GB GDDR5 Video RAM on board

Microsoft DirectX® 11.1 Compatible

NVIDIA® GeForce GTX 880M PCIe Video Card

8GB GDDR5 Video RAM on board

Microsoft DirectX® 11.1 Compatible

Pointing Device

Built-in Touchpad (scrolling key functionality integrated)

Keyboard

Illuminated Full-size "WinKey" keyboard (with numeric keypad)

Audio

High Definition Audio Compliant Interface
S/PDIF Digital Output
Two Speakers
One Sub Woofer
Built-In Microphone
Sound Blaster Audio
ANSP™ 3D sound technology on headphone output

Mini-Card Slots

Slot 1 for **WLAN** Module or **Combo WLAN and Bluetooth** Module
Slots 2 & 3 for mSATA **SSD**

Card Reader

Embedded Multi-In-1 Push-Push Card Reader
MMC (MultiMedia Card) / RS MMC
SD (Secure Digital) / Mini SD / SDHC/ SDXC
MS (Memory Stick) / MS Pro / MS Duo

Interface

Two USB 3.0 Ports (Including one AC/DC Powered USB port)
One USB 2.0 Port
One eSATA Port (USB 3.0 Port Combined)
One HDMI-Out Port
One DisplayPort (1.1a)
One Mini DisplayPort
One S/PDIF Out Jack
One Headphone/Speaker-Out Jack
One Microphone-In Jack
One Line-In Jack
One Mini-IEEE1394a Port
One RJ-45 LAN Jack
One DC-In Jack

Note: External 7.1CH Audio Output Supported by Headphone, Microphone, Line-In and S/PDIF Out Jacks

Communication

Built-In Gigabit Ethernet LAN
2,0M FHD PC Camera Module

WLAN/ Bluetooth Half Mini-Card Modules:

(**Factory Option**) Intel® Centrino® Ultimate-N 6300 Wireless LAN (**802.11a/g/n**)

(**Factory Option**) Intel® Wireless-AC 7260 Wireless LAN (**802.11a/c**) + Bluetooth **4.0**

(**Factory Option**) Intel® Wireless-N 7260 Wireless LAN (**802.11b/g/n**) + Bluetooth **4.0**

(**Factory Option**) Wireless LAN (**802.11b/g/n**) + Bluetooth **4.0**

(**Factory Option**) Wireless LAN (**802.11a/b/g/n**) + Bluetooth **4.0**

Environmental Spec**Temperature**

Operating: 5°C - 35°C
Non-Operating: -20°C - 60°C

Relative Humidity

Operating: 20% - 80%
Non-Operating: 10% - 90%

Power

Removable 8-cell Smart Lithium-Ion Battery Pack, 76.96WH

Full Range AC/DC Adapter

AC Input: 100 - 240V, 50 - 60Hz
DC Output: 19.5V, 11.8A (**230W**)


Dimensions & Weight

412mm (w) * 276mm (d) * 45.4 - 41.8mm (h)
Around 3.9kg with Battery and ODD

Introduction


Figure 1
Top View

1. Built-In PC Camera
2. PC Camera LED
3. Built-In Microphone
4. LCD
5. Speakers
6. LED Indicators
7. Power Button
8. Illuminated Keyboard
9. TouchPad and Buttons
10. Fingerprint Reader (Optional)



Note that the Touchpad and Buttons has a valid operational area indicated within the red dotted lines above.

External Locator - Top View with LCD Panel Open



External Locator - Front & Right side Views



Figure 2
Front Views

1. LED Power Indicators



Figure 3
Right Side Views

1. Optical Device Drive Bay
2. Emergency Eject Hole
3. Headphone Jack
4. Microphone Jack
5. S/PDIF-Out Jack
6. Line-In Jack
7. USB 2.0 Port

Introduction

External Locator - Left Side & Rear View

Figure 4
Left Side View

1. Mini-IEEE 1394a Port
2. RJ-45 LAN Jack
3. USB 3.0 Port / USB Charge
4. USB 3.0 Port
5. Combined eSATA/ Powered USB 3.0 Port
6. Multi-in-1 Card Reader



Figure 5
Rear View

1. Vent/Fan Intake
2. Display Port
3. HDMI-Out Port
4. Mini Display Port
5. DC-In Jack
6. Security Lock Slot



External Locator - Bottom View




Figure 6
Bottom View

1. Sub Woofer
2. Fan Outlet/Intake
3. Component Bay Cover
4. Primary HDD Bay
5. Secondary HDD Bay
6. Battery



Overheating


To prevent your computer from overheating make sure nothing blocks the vent/fan intakes while the computer is in use.

Introduction

Figure 7
Mainboard Top
Key Parts

1. Platform
Controller Hub
2. Audio Codec
3. KBC ITE IT8587

Mainboard Overview - Top (Key Parts)



Mainboard Overview - Bottom (Key Parts)




Figure 8
**Mainboard Bottom
Key Parts**


1. VGA-Card Connector
2. CPU Socket (no CPU installed)
3. Memory Slots
DDR3L SO-DIMM
(Primary)
4. Hard Disk Connector
5. MSATA Connector

Introduction

Figure 9
**Mainboard Top
Connectors**


Mainboard Overview - Top (Connectors)

1. USB 3.0 Port / e-SATA
2. Multi-in-1 Card Reader
3. KB LED Connector
4. TP LED Cable Connector
5. LED 4 Cable Connector
6. TouchPad Cable Connector
7. MSATA Cable Connector
8. LED 3 Cable Connector
9. Keyboard Cable Connector
10. Audio Cable Connector
11. LCD Cable Connector
12. eDP Cable Connector



Mainboard Overview - Bottom (Connectors)

Figure 10
**Mainboard Bottom
Connectors**



1. DC-In Jack
2. Mini Display Port
3. HDMI-Out Port
4. Display Port
5. VGA Fan Cable Connector
6. Sub Woofer Cable Connector
7. CPU Fan Cable Connector
8. USB 3.0 Ports
9. RJ-45 LAN Jack
10. Mini-IEEE 1394a Port

Chapter 2: Disassembly

Overview

This chapter provides step-by-step instructions for disassembling the **P170SM-A** series notebook's parts and subsystems. When it comes to reassembly, reverse the procedures (unless otherwise indicated).


We suggest you completely review any procedure before you take the computer apart.

Procedures such as upgrading/replacing the RAM, optical device and hard disk are included in the User's Manual but are repeated here for your convenience.

To make the disassembly process easier each section may have a box in the page margin. Information contained under the figure # will give a synopsis of the sequence of procedures involved in the disassembly procedure. A box with a  lists the relevant parts you will have after the disassembly process is complete. **Note:** The parts listed will be for the disassembly procedure listed ONLY, and not any previous disassembly step(s) required. Refer to the part list for the previous disassembly procedure. The amount of screws you should be left with will be listed here also.

A box with a  will also provide any possible helpful information. A box with a  contains warnings.

An example of these types of boxes are shown in the sidebar.



Disassembly

NOTE: All disassembly procedures assume that the system is turned **OFF**, and disconnected from any power supply (the battery is removed too).

Maintenance Tools

The following tools are recommended when working on the notebook PC:

- M3 Philips-head screwdriver
- M2.5 Philips-head screwdriver (magnetized)
- M2 Philips-head screwdriver
- Small flat-head screwdriver
- Pair of needle-nose pliers
- Anti-static wrist-strap

Connections

Connections within the computer are one of four types:

Locking collar sockets for ribbon connectors	To release these connectors, use a small flat-head screwdriver to gently pry the locking collar away from its base. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.
Pressure sockets for multi-wire connectors	To release this connector type, grasp it at its head and gently rock it from side to side as you pull it out. Do not pull on the wires themselves. When replacing the connection, do not try to force it. The socket only fits one way.
Pressure sockets for ribbon connectors	To release these connectors, use a small pair of needle-nose pliers to gently lift the connector away from its socket. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.
Board-to-board or multi-pin sockets	To separate the boards, gently rock them from side to side as you pull them apart. If the connection is very tight, use a small flat-head screwdriver - use just enough force to start.

Maintenance Precautions

The following precautions are a reminder. To avoid personal injury or damage to the computer while performing a removal and/or replacement job, take the following precautions:

1. **Don't drop it.** Perform your repairs and/or upgrades on a stable surface. If the computer falls, the case and other components could be damaged.
2. **Don't overheat it.** Note the proximity of any heating elements. Keep the computer out of direct sunlight.
3. **Avoid interference.** Note the proximity of any high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage components and/or data. You should also monitor the position of magnetized tools (i.e. screwdrivers).
4. **Keep it dry.** This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.
5. **Be careful with power.** Avoid accidental shocks, discharges or explosions.
 - Before removing or servicing any part from the computer, turn the computer off and detach any power supplies.
 - When you want to unplug the power cord or any cable/wire, be sure to disconnect it by the plug head. Do not pull on the wire.
6. **Peripherals** – Turn off and detach any peripherals.
7. **Beware of static discharge.** ICs, such as the CPU and main support chips, are vulnerable to static electricity. Before handling any part in the computer, discharge any static electricity inside the computer. When handling a printed circuit board, do not use gloves or other materials which allow static electricity buildup. We suggest that you use an anti-static wrist strap instead.
8. **Beware of corrosion.** As you perform your job, avoid touching any connector leads. Even the cleanest hands produce oils which can attract corrosive elements.
9. **Keep your work environment clean.** Tobacco smoke, dust or other air-born particulate matter is often attracted to charged surfaces, reducing performance.
10. **Keep track of the components.** When removing or replacing any part, be careful not to leave small parts, such as screws, loose inside the computer.

Cleaning

Do not apply cleaner directly to the computer, use a soft clean cloth.

Do not use volatile (petroleum distillates) or abrasive cleaners on any part of the computer.



Power Safety Warning

Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines and power cord). You must also remove your battery in order to prevent accidentally turning the machine on.

Disassembly Steps

The following table lists the disassembly steps, and on which page to find the related information. **PLEASE PERFORM THE DISASSEMBLY STEPS IN THE ORDER INDICATED.**

To remove the Battery:

1. Remove the battery [page 2 - 5](#)

To remove the HDD from the Primary Bay:

1. Remove the battery [page 2 - 5](#)
2. Remove the HDD [page 2 - 6](#)

To remove the SSD:

1. Remove the battery [page 2 - 5](#)
2. Remove the HDD [page 2 - 6](#)
3. Remove the SSD [page 2 - 9](#)

To remove the Optical Device:

1. Remove the battery [page 2 - 5](#)
2. Remove the Optical device [page 2 - 10](#)

To remove the HDD from the Secondary Bay:

1. Remove the battery [page 2 - 5](#)
2. Remove the Optical device [page 2 - 10](#)
3. Remove the HDD [page 2 - 12](#)

To remove the Primary System Memory:

1. Remove the battery [page 2 - 5](#)
2. Remove the system memory [page 2 - 14](#)

To remove the Secondary System Memory:

1. Remove the battery [page 2 - 5](#)
2. Remove the keyboard [page 2 - 16](#)
3. Remove the system memory [page 2 - 16](#)

To remove the WLAN Module:

1. Remove the battery [page 2 - 5](#)
2. Remove the keyboard [page 2 - 16](#)
3. Remove the wireless LAN [page 2 - 18](#)

To remove the MSATA Module:

1. Remove the battery [page 2 - 5](#)
2. Remove the MSATA [page 2 - 20](#)

To remove and install a Processor:

1. Remove the battery [page 2 - 5](#)
2. Remove the processor [page 2 - 21](#)
3. Install the processor [page 2 - 23](#)

To remove and install a Video Card:

1. Remove the battery [page 2 - 5](#)
2. Remove the video card [page 2 - 24](#)
3. Install the video card [page 2 - 26](#)

To remove the CCD:

1. Remove the battery [page 2 - 5](#)
2. Remove the CCD [page 2 - 27](#)


Removing the Battery

1. Turn the computer **off**, and turn it over.
2. Slide the latch **1** in the direction of the arrow (*Figure 1a*).
3. Slide the latch **2** in the direction of the arrow, and hold it in place (*Figure 1a*).
4. The battery may be levered up at point **3** (*Figure 1b*).
5. Lift the battery **4** out of the compartment (*Figure 1c*).



Figure 1
Battery Removal

- a. Slide the latch and hold in place.
- b. Slide the battery out in the direction of the arrow.
- c. Lift the battery out.



Disassembly

Figure 2
HDD Assembly Removal

- Locate the HDD bay cover and remove the screws.
- Remove the hard disk bay cover by levering the cover at point ③.


Removing the Hard Disk Drive

The hard disk drive can be taken out to accommodate other 2.5" serial (SATA) hard disk drives with a height of 9.5mm (h). Follow your operating system's installation instructions, and install all necessary drivers and utilities (as outlined in **Chapter 4 of the User's Manual**) when setting up a new hard disk.

Hard Disk Upgrade Process

- Turn **off** the computer, and remove the battery ([page 2 - 5](#)).
- Locate the hard disk bay cover and remove screws ① - ② ([Figure 2a](#)).
- Remove the hard disk bay cover ④ by levering the cover at point ③ ([Figure 2b](#)).

a.



b.



4.Hard Disk Bay Cover

- 2 Screws



HDD System Warning


New HDD's are blank. Before you begin make sure:

You have backed up any data you want to keep from your old HDD.

You have all the CD-ROMs and FDDs required to install your operating system and programs.

If you have access to the internet, download the latest application and hardware driver updates for the operating system you plan to install. Copy these to a removable medium.

4. Slide the HDD assembly in the direction of the arrow 5 (Figure 3c).
5. Remove the hard disk assembly 6 (Figure 3d).
6. Remove screws 7 & 8 and the insulation plate 9 (Figure 3e).
7. Reverse the process to install a new hard disk (do not forget to replace all the screws and covers).



- c. Slide the HDD assembly in the direction of the arrow.
- d. Remove the hard disk assembly.
- e. Remove the screws and the insulation plate.



- 6. HDD
- 9. HDD Insulation Plate
- 2 Screws

Disassembly

Hard Disk Size Note (Foam Rubber Insert)

Note that the hard disks pictured on the following pages are all 9.5mm(H) hard disk drives. In some cases 7mm(H) hard disk drives will be installed.

Figure 4
**Foam Rubber
Insert for 7mm(H)
HDDs**



- If you are replacing a 9.5mm(H) HDD with a 7mm(H) HDD then insert the foam rubber insert (as shown above).
- If you are replacing a 7mm(H) HDD with a 9.5mm(H) HDD then remove the foam rubber insert.

Removing the SSD

1. Turn **off** the computer, and remove the battery ([page 2 - 5](#)) and hard disk ([page 2 - 9](#)).
2. Remove the screws **1** from the shielding plate ([Figure 5a](#)).
3. Remove the SSD shielding plate **2** and remove the screw **3** from the SSD ([Figure 5b](#)).
4. The SSD module **4** will pop-up and you can remove it from the computer ([Figure 5c](#)).
5. Reverse the process to install a new SSD.




Figure 5
SSD Removal

- a. Remove the screws.
- b. Remove the shielding plate and screw.
- c. Remove the SSD module.



2. SSD Shielding Plate
4. SSD Module

- 2 Screws




Disassembly

Figure 6
**Optical Device
Removal**

- Locate the secondary hard disk bay cover and remove the screws.
- Remove the cover and screw.
- Push the optical device out off the computer at point 6.

Removing the Optical (CD/DVD) Device

- Turn **off** the computer, and remove the battery ([page 2 - 5](#)).
- Locate the **secondary** hard disk bay cover and remove screws **1** & **2** ([Figure 6a](#)).
- Remove the hard disk bay cover **3** and screw at point **4** ([Figure 6b](#)).
- Use a screwdriver to carefully push out the optical device **5** out of the bay at point **6** ([Figure 6d](#)).
- Reverse the process to install any new optical (CD/DVD) device.



- 3. Secondary HDD Bay Cover
- 5. Optical Device
- 3 Screws

6. Carefully pry the bezel **8** off the optical device at point **7** (*Figure 7d*).
7. Separate the bezel **8** and the optical device.
8. Reverse the process to attach the front bezel **8** with the new optical device at point **9** (*Figure 7f*).
9. Insert the new device and carefully slide it into the computer (the device only fits one way. DO NOT FORCE IT; The screw holes should line up).
10. Replace the component bay cover and tighten the screws.
11. Restart the computer to allow it to automatically detect the new device.

d.



f.



e.




Figure 7
**Optical Device
Removal (cont'd.)**

- d. Pry the bezel off the optical device.
- e. Separate the bezel and optical device
- f. Install the front bezel.



8. Bezel Cover

- 1 Screw

Disassembly

Figure 8
**Secondary HDD
 Assembly Removal**

- a. Remove the screws from the secondary HDD assembly.
- b. Slide the secondary HDD assembly in the direction of the arrow.
- c. Lift the secondary HDD assembly up and out of the bay.


5. Hard Disk Assembly
- 3 Screws

Removing the Hard Disk from the Secondary HDD Bay


Note that the **secondary** hard disk (if installed) is located under the optical device bay (CD/DVD).

1. Turn **off** the computer, and turn it over, remove the battery ([page 2 - 5](#)) and optical device ([page 2 - 10](#)).
2. Remove screws ① - ③ from the secondary HDD assembly ([Figure 8a](#)).
3. Slide the secondary HDD assembly in the direction of the arrow ④ (it will not move fully out of the bay [Figure 8a](#)).
4. Lift the secondary HDD assembly ⑤ up and out of the bay (in the reverse direction of the arrow ④ [Figure 8c](#)).



a.



b.



c.



5. Remove screws ⑥ - ⑨ and the insulation plate ⑩ from the hard disk ⑪ (*Figure 9d*).





Figure 9
**Secondary HDD
Assembly Removal**

- d. Remove the screws and the insulation plate.

6. Reverse the process to install a new disk (make sure you install the insulation plate).
7. Slide the HDD assembly into the bay at an angle as illustrated.
8. Make sure the insulation plate slides under the HDD bay guide at point ⑫.
9. Slide the assembly in the direction of the arrow ⑬ and secure the assembly with the screws.



- ⑩. HDD Insulation Plate
- ⑪. HDD
- 4 Screws

Disassembly

Figure 10
RAM Module Removal

- Remove the screws.
- Slide the bottom cover until the cover and case indicators are aligned.

Removing the Primary System Memory (RAM)

The computer has **four** memory sockets for 204 pin Small Outline Dual In-line (SO-DIMM) **DDR 3L** type memory modules (see ***“Memory” on page 1 - 2***). The total memory size is automatically detected by the POST routine once you turn on your computer.



Note that **four** SO-DIMMs are **only** supported by Quad-Core CPUs; Dual-Core CPUs support two SO-DIMMs maximum (see ***“Memory” on page 1 - 2*** for full details).

Two primary memory sockets are located under component bay cover (the bottom case cover), and two secondary memory sockets are located under the keyboard (not user upgradable). If you are installing only two RAM modules then they should be installed in the primary memory sockets under the component bay cover.

Note that the RAM located under the keyboard is not user upgradable.

Memory Upgrade Process

- Turn **off** the computer, and turn it over, remove the battery (***page 2 - 5***).
- Remove screws **1** - **4** at the bottom of the computer (***Figure 10a***).
- Slide the bottom cover in the direction of the arrow **5** until the cover & case indicators **6** are aligned (***Figure 10b***).





- 6 Screws

4. Lift the component bay cover **7** off the computer case. The modules will be visible at point **8** (**Figure 11c**).
5. Gently pull the two release latches (**9** & **10**) on the sides of the memory socket(s) in the direction indicated below (**Figure 11d**).
6. The RAM module **11** will pop-up, and you can remove it (**Figure 11e**).
7. Pull the latches to release the second module if necessary.
8. Insert a new module holding it at about a 30° angle and fit the connectors firmly into the memory slot.
9. The module's pin alignment will allow it to only fit one way. Make sure the module is seated as far into the slot as it will go. DO NOT FORCE the module; it should fit without much pressure.
10. Press the module in and down towards the mainboard until the slot levers click into place to secure the module.
11. Replace the bay cover and screws.
12. Restart the computer to allow the BIOS to register the new memory configuration as it starts up.

Figure 11
RAM Module
Removal (cont'd.)

- c. Lift the component bay cover off the computer case. The modules will be visible at point **10**.
- d. Gently pull the two release latches on the sides of the memory socket(s) in the direction indicated below.
- e. The RAM module will pop-up, and you can remove it.



Contact Warning

Be careful not to touch the metal pins on the module's connecting edge. Even the cleanest hands have oils which can attract particles, and degrade the module's performance.



7. Component Bay Cover
11. RAM Module

Disassembly

Figure 12
**RAM Module
Removal**


- a. Remove the top cover module.
 - b. Remove the screws.
 - c. Carefully lift the keyboard up, being careful not to bend the keyboard ribbon cable.
1. Turn **off** the computer, and turn it over, remove the battery ([page 2 - 5](#)), and component bay cover ([page 2 - 14](#)).
 2. Remove the top cover module **A** ([Figure 12a](#)).
 3. Remove screws **1** - **5** ([Figure 12a](#)).
 4. Carefully lift the keyboard **B** up, being careful not to bend the keyboard ribbon cable **6** ([Figure 12c](#)).




- A. Top Cover Module
B. Keyboard
- 5 Screws

5. Disconnect the keyboard ribbon cable **6** and LED ribbon cable **7** from the locking collar socket **8** & **9** by using a small flat-head screwdriver to pry the locking collar pins away from the base. (**Figure 13e**).
6. Remove the keyboard and the memory sockets **10** & **11** will be visible (**Figure 13f**).
7. Gently pull the two release latches (**12** & **13**) on the sides of the memory socket(s) in the direction indicated below (**Figure 13g**).
8. The RAM module **14** will pop-up, and you can remove it.
9. Pull the latches to release the second module if necessary.
10. Insert a new module holding it at about a 30° angle and fit the connectors firmly into the memory slot.
11. The module's pin alignment will allow it to only fit one way. Make sure the module is seated as far into the slot as it will go. DO NOT FORCE the module; it should fit without much pressure.
12. Press the module in and down towards the mainboard until the slot levers click into place to secure the module.
13. Replace the bay cover and screws.
14. Restart the computer to allow the BIOS to register the new memory configuration as it starts up.


e.



g.



f.



Contact Warning

Be careful not to touch the metal pins on the module's connecting edge. Even the cleanest hands have oils which can attract particles, and degrade the module's performance.



14. RAM Modules

Figure 13
RAM Module
Removal (cont'd.)

- e. Disconnect the keyboard ribbon cable and LED ribbon cable from the locking collar socket by using a small flat-head screwdriver to pry the locking collar pins away from the base.
- f. Remove the keyboard and the memory sockets will be visible.
- g. Gently pull the two release latches on the sides of the memory socket(s) in the direction indicated below.

Disassembly


Figure 14
Wireless LAN
Module Removal

- a. The Wireless LAN module will be visible at point ① under the keyboard
- b. Disconnect the cables ② - ③, then remove screw ④ from the module socket (Figure 14b).
- c. The WLAN module will pop up.
- d. Lift the WLAN module out.

Removing the Wireless LAN Module

1. Turn **off** the computer, remove the battery ([page 2 - 5](#)) and the keyboard ([page 2 - 16](#)).
2. The Wireless LAN module will be visible at point ① under the keyboard ([Figure 14a](#)).
3. Carefully disconnect cables ② - ③, then remove screw ④ from the module socket ([Figure 14b](#)).
4. The Wireless LAN module ⑤ will pop-up ([Figure 14c](#)).
5. Lift the Wireless LAN module ([Figure 14d](#)) up and off the computer.

a.




c.



b.



d.



✎
5. WLAN Module

- 1 Screw

Wireless LAN, Combo, 3G & LTE Module Cables

Note that the cables for connecting to the antennae on WLAN, WLAN & Bluetooth Combo, 3G and LTE modules are not labelled. The cables/covers (each cable will have either a black or transparent cable cover) are color coded for identification as outlined in the table below.

Module Type	Antenna Type	Cable Color	Cable Cover Type
WLAN/WLAN & Bluetooth Combo	WM 1	Black	Transparent
	WM 2	Gray	
	WM 3	White	
LTE Broadband	LTE 1	Black	Black
	LTE 2	Gray	
3G Broadband	3G 1	Black	Black
	3G 2	Gray	

Cable 1 is usually connected to antenna 1 (Main) on the module, and cable 2 to antenna 2 (Aux).

Disassembly


Figure 15
**MSATA Module
Removal**

- Locate the module.
- Remove the screw.
- The module will pop-up.
- Lift the module up off the socket.

Removing the MSATA Module

- Turn **off** the computer, remove the battery ([page 2 - 5](#)), and component bay cover ([page 2 - 14](#)).
- Locate the module, it is visible at point **1** ([Figure 15a](#)).
- Carefully remove the screw **2** from the module ([Figure 15b](#)).
- Lift the module **3** up and off the computer ([Figure 15b](#)).

a.




c.



b.



d.



3. MSATA Module


- 1 Screw

Removing and Installing the Processor

Processor Removal Procedure

1. Turn **off** the computer, remove the battery ([page 2 - 5](#)), and component bay cover ([page 2 - 14](#)).
2. Remove screws **1** - **4** from the heat sink unit in the order indicated on the label (i.e screw 4 first through to screw 1 last [Figure 16a](#)).
3. Carefully (it may be hot) remove the heat sink unit **5** ([Figure 16b](#)).

a.



Note: Loosen the screws in the reverse order 4-3-2-1 as indicated on the label.

b.



Figure 16
**Processor
Removal
Procedure**

- a. Remove the screws in the correct order.
- b. Carefully remove the heat sink unit.



CPU Warning

In order to prevent damaging the contact pins when removing the CPU, it is necessary to first remove the WLAN module from the computer.



5. Heat Sink Unit

- 4 Screws


Disassembly

Figure 17
Processor Removal
(cont'd)


- c. Turn the release latch to unlock the CPU.
- d. Lift the CPU out of the socket.

4. Turn the release latch **6** towards the unlock symbol , to release the CPU (**Figure 17c**).
5. Carefully (it may be hot) lift the CPU **A** up out of the socket (**Figure 17d**).
6. See [page 2 - 23](#) for information on inserting a new CPU.
7. When re-inserting the CPU, pay careful attention to the pin alignment, it will fit only one way (DO NOT FORCE IT!).

c.




Unlock



Lock

d.



Caution

The heat sink, and CPU area in general, contains parts which are subject to high temperatures. Allow the area time to cool before removing these parts.




A. CPU

Processor Installation Procedure

1. Insert the CPU **A**, pay careful attention to the pin alignment (**Figure 18a**), it will fit only one way (DO NOT FORCE IT!), and turn the release latch **B** towards the lock symbol  (**Figure 18b**).
2. **Remove the sticker C** (**Figure 18c**) from the heat sink unit (if it is a new unit).
3. Insert the heat sink unit **D** as indicated in **Figure 18c**.
4. Tighten the CPU heat sink screws in the order **1**, **2**, **3** & **4** (the order as indicated on the label and **Figure 18d**).
5. Replace the CPU fan, component bay cover and tighten the screws (**page 2 - 21**).


Figure 18
Processor
Installation

- a. Insert the CPU.
- b. Turn the release latch towards the lock symbol.
- c. Remove the sticker from the heat sink unit and insert the heat sink.
- d. Tighten the screws.



Note:

Tighten the screws in the order 1-2-3-4 as indicated on the label.



Disassembly

Figure 19
Video Card
Removal Procedure

- Remove the screws in the correct order.
- Carefully remove the heat sink units.
- Remove the video card screws. The video card will pop up.
- Remove the video card.



Caution

The heat sink, and video card area in general, contains parts which are subject to high temperatures. Allow the area time to cool before removing these parts.



8. Heat Sink Unit
11. Video Card

- 9 Screws

Removing and Installing the Video Card



Video Card Removal Procedure

- Turn **off** the computer, turn it over and remove the battery ([page 2 - 5](#)) and component cover ([page 2 - 14](#)).
- Remove screws **1** - **7** from the heat sink unit in the order indicated on the label (i.e screw **7** first through to screw **1** last) ([Figure 19a](#)).
- Carefully (**they may be hot**) remove the heat sink unit **8** ([Figure 19b](#)).
- Remove screws **9** & **10** from the video card and the video card **11** will pop up ([Figure 19c](#)).
- Remove the video card **11** ([Figure 19d](#)).

a.





c.




Note:

Please use a flat head screwdriver to remove screws **9** & **10**.

b.



d.



Heat Sink Screw Removal and Insertion


Remove the screws from the heat sink in the order indicated here: **7-6-5-4-3-2-1**.

When tightening the screws, make sure that they are tightened in the order: **1-2-3-4-5-6-7**.

For video card (N15E-GX) additional removal procedure

6. Remove screws **12** - **15** from the video card assembly (**Figure 20e**).
7. Separate the shielding plate **16** from the video card **11** (**Figure 19d**).

e.



f.




Figure 20
**Video Card
Removal Procedure
(cont'd.)**

- e. Remove the screws.
- f. Separate shielding plate and video card.



11. Video Card
16. Shielding Plate

- 4 Screws

Disassembly

Figure 21
Installing a New Video Card

- e. Insert the video card at a 30 degree angle.
- f. Fit the connectors straight and even.



Caution

The heat sink, and video card area in general, contains parts which are subject to high temperatures. Allow the area time to cool before removing these parts.




11. Video Card

- 2 Screws

Installing a New Video Card

1. Prepare to fit the video card **11** into the slot by holding it at about a 30° angle (*Figure 21e*).
2. The card needs to be fully into the slot, and the video card and socket have a guide-key and pin which align to allow the card to fit securely (*Figure 21f*).
3. Fit the connectors firmly into the socket, straight and evenly.




e.



Note:

Take special care that the speaker cable is not hindering the video card during installation.

f.



4. DO NOT attempt to push one end of the card in ahead of the other.
5. The card's pin alignment will allow it to only fit one way. **Make sure the module is seated as far into the socket as it will go** (none of the gold colored contact should be showing). DO NOT FORCE the card; it should fit without much pressure.
6. Secure the card with screws **9** & **10** (*Figure 21 on page 2 - 26*).
7. Place the heat sink back on the card, and secure the screws in the order indicated in *Figure 21 on page 2 - 26*.
8. Attach the video card fan and secure with the screws as indicated in *Figure 19 on page 2 - 24*.
9. Reinsert the component bay cover, and secure with the screws as indicated in *Figure 12 on page 2 - 16*.

Removing the CCD

1. Turn **off** the computer, remove the battery ([page 2 - 5](#)).
2. Remove the rubbers and screws **1** - **6** ([Figure 22a](#)).
3. Run your fingers around the inner frame of the LCD panel at the points indicated by the arrows **A** - **D** ([Figure 22b](#)).
4. Carefully Remove the LCD panel **7** off ([Figure 22c](#)).
5. Disconnect the cable **8** ([Figure 22d](#)).
6. Remove the CCD module **9** off ([Figure 22e](#)).





Figure 22
CCD Module
Removal

- a. Remove the rubbers and screws.
- b. Run your fingers around the inner frame of the LCD panel at the points indicated by the arrow.
- c. Remove the LCD panel.
- d. Disconnect the cable.
- e. Remove the CCD module.



7. LCD Front Panel
9. CCD Module

- 6 Rubber and Screws

Disassembly



Figure 23

Top Cover Removal

- Disconnect the cable connectors and lift the the wires from its holder.
- Disconnect the cables and remove the screws.
- Remove the fan unit(s).

Removing the Top Cover



- Turn **off** the computer, remove the battery ([page 2 - 5](#)), component bay cover ([page 2 - 14](#)), and keyboard ([page 2 - 16](#)).
- Disconnect the cable connectors **1** - **3** and carefully lift the corresponding wires at the point **4** from the holder as indicated by the arrows **A** - **C** ([Figure 23a](#)).
- Turn the computer over, remove the fan cables **5** & **6** and screws **7** - **13** ([Figure 22b](#)).
- Remove the fan unit(s) **14** off the computer ([Figure 22c](#)).



14. Fan Unit(s)

- 7 Screws

5. Remove screws 15 - 35 (Figure 24d).
6. Lift the top cover at point 36 (Figure 24e).
7. Carefully separate the top cover 37 from the bottom case 39 in the direction of the arrow at point 38. The hinge cover 40 will automatically be released from its holder (Figure 24f).
8. Reverse the process to install the top cover (do not forget to replace all the screws, hinge cover and bottom case).



- d. Remove the screws.
- e. Lift the LCD panel.
- f. Separate the top cover from the bottom case of the computer.



37. Top Cover
39. Bottom Case
40. Hinge Cover

- 21 Screws

Appendix A: Part Lists

This appendix breaks down the **P170SM-A** series notebook's construction into a series of illustrations. The component part numbers are indicated in the tables opposite the drawings.

Note: This section indicates the *manufacturer's* part numbers. Your organization may use a different system, so be sure to cross-check any relevant documentation.

Note: Some assemblies may have parts in common (especially screws). However, the part lists DO NOT indicate the total number of duplicated parts used.

Note: Be sure to check any update notices. The parts shown in these illustrations are appropriate for the system at the time of publication. Over the product life, some parts may be improved or re-configured, resulting in *new* part numbers.

Part List Illustration Location

The following table indicates where to find the appropriate part list illustration.

Table A- 1
Part List Illustration
Location

Parts	
Top with Fingerprint	<i>page A - 3</i>
Top without Fingerprint	<i>page A - 4</i>
Bottom (N15E-GX)	<i>page A - 5</i>
Bottom (N15P-GX)	<i>page A - 6</i>
LCD	<i>page A - 7</i>
COMBO	<i>page A - 8</i>
DVD-Dual Drive	<i>page A - 9</i>

Top with Fingerprint





Figure A - 1
Top with
Fingerprint

ITEM	PART NAME	PART NO	REMARK
1	TOP COSMETIC PLATE PMMA P170HM	6-42-P1702-022	
2	CENTER COVER MODULE (GRAPHIC PRINT) (M170) (P170SM)	6-42-P17S2-100-N	
3	SCREW M2X3L KI NI ICT NY (DD=H4.5,DT=0.4)	6-35-B1120-3RE	
4	KEYBOARD V2250B2-45-0000 P170M BLACK MOULDED (M170) (P170M)	6-80-P17S0-010-3	
5	SPONGE CR 45*6*0.5T P170EM	6-47-0019A-007	
6	KEYBOARD MYLAR (75*70*0.1) P170EM	6-40-P17E2-010	
7	TOP CASE PROTECT MYLAR(PET+38915) P170HM	6-40-P1702-020	
8	T.P. MYLAR P170HM	6-40-P1702-030	
9	TOILE 24H TOP CASE MODULE ASSY P170SM-A	6-79-P170SMA2-010	
10	SPEAKER FRONT RAL SHOT TSE 23W 4 ECEPHEMAD (M170) (P170M)	6-23-SP177-011-A	
11	SCREW M2X6.2L NI ICT NY FOR SPEAKER	6-35-Z1120-6R2	
12	AL FOIL (40*15*0.25T) P170HM	6-47-P1702-010	
13	FFC CABLE FOR CLICK IN TO M170 (P170) (P170M) (P170M)	6-43-P1700-022-2	
14	FFC CABLE FOR TOUCH PAD 6PIN (SHENGSHANG)	6-43-C4502-010-2	
15	TOUCH PAD SYNAPTICS TM-00146-003 MULTI-GE5	6-49-C4802-010	
16	POWER SWITCH AND LED BOARD V4.0 P170SM	6-77-P17SS-D04	
17	SCREW M2X4L KI NI ICT NY (DD=H4.0,DT=0.5)	6-35-B1120-4RA	
18	CLICK BUTTON MODULE (W. EGISPEC FP) P170SM	6-42-P1702-300	
19	CLICK BOARD V3.0 (FINGERPRINT) BOARD V3.0A ASSY P170SM	6-77-P17SA-N03	
19	CLICK BOARD V4.0A (FINGERPRINT) BOARD V3.0A ASSY P170SM	6-77-P17SA-N04A	
20	FFC CABLE FOR POWER IN TO M170 (P170) (P170M) (P170M)	6-43-P1700-012-2	

Part Lists

Top without Fingerprint

Figure A - 2
Top without
Fingerprint

ITEM	PART NAME	PART NO	REMARK
1	TOP COSMETIC PLATE PMMA P170HM	6-42-P1702-022	
2	CENTER COVER MODULE GRAPHIC PRINT ONLY NO FINGER	6-42-P17S2-100-N	
3	SCREW M2*3L KI NI ICT NY (OD=4.5,DT=0.4)	6-35-B1120-3RE	
4	W/O LED VIBRATION IS 40MM PITCH 0.15MM W/O PITCH	6-80-P17S0-010-3	
5	SPONGE CR 45*6*0.5T P170EM	6-47-0019A-007	
6	KEYBOARD MYLAR (75*70*0.1) P170EM	6-40-P17E2-010	
7	TOP CASE PROTECT MYLAR(PET+300915) P170HM	6-40-P1702-020	
8	TP MYLAR P170HM	6-40-P1702-030	
9	TOILE 24H TOP CASE MODULE ASSY P170SM-A	6-79-P170SMA2-010	
10	SPEAKER FROM RL 5W 152 22K 4 (EVENHARD) W/O PITCH	6-23-SP177-011-A	
11	SCREW M2*6.2L NI ICT NY FOR SPEAKER	6-35-Z1120-6R2	
12	AL FOIL(40*15*0.25T) P170HM	6-47-P1702-010	
13	FFC CABLE FOR CLICK TO W/O LED PITCH 0.15MM W/O PITCH	6-43-P1700-022-2	
14	FFC CABLE FOR TOUCH PAD 6PIN (HENGSHANG)	6-43-C4502-010-2	
15	TOUCH PAD SYNAPTICS TM-0146-003 MULTI-GES	6-49-C4802-010	
16	POWER SWITCH AND LED BOARD V4.0 P170SM	6-77-P17SS-D04	
17	SCREW M2*4L KI NI ICT NY (OD=4.0,DT=0.5)	6-35-B1120-4RA	
18	CLICK BUTTON W/O-TP MODULE P170HM	6-42-P1702-102	
19	CLICK BOARD V4.0A (W/O FP) P170SM	6-77-P17S2-D04A-1	
20	FFC CABLE FOR POWER BK TO W/O LED PITCH 0.15MM W/O PITCH	6-43-P1700-012-2	

Bottom (N15E-GX)



[illegible]

Figure A - 3
Bottom (N15E-GX)

A.Part Lists

Figure A - 4
Bottom
(N15P-GX)

[illegible]

A - 6 Bottom (N15P-GX)

LCD





Figure A - 5
LCD

ITEM	PART NAME	PART NO	REMARK
1	FRONT PROTECTION MYLAR (PET-3M91S) P170HM	6-40-P1701-010	
2	LCD FRONT COVER UP RUBBER P170HM	6-47-P1701-043	
3	SCREW M2.5X4.0 BK/Z ICT NY	6-35-B6120-SR0	
4	LCD FRONT COVER MODULE (PAND) P170SM-A0APD0	6-39-P17S1-010-AW	
5	CCD LENS PMMA P170HM	6-42-P1701-010	
6	SCREW M2.5X6L K BZ ICT NY	6-35-B2125-6RA	
7	SCREW M2X4L K1 NI ICT NY (OD=4.5,DT=0.4)	6-35-B1120-3RE	
8	LCD HINGE R SECC (PVT) P170EM	6-33-P17E1-0R1	
9	WIRE CABLE FOR LCD TO BACK COVER MODULE (PVT) P170EM	6-43-P1701-011-D	FOR LVDS
10	LCD 17.3" FHD CHINESE N730GE-L11 QLED 60 NM	6-43-P17S1-A10-1K	FOR EDP
11	LCD 17.3" FHD CHINESE N730GE-ENLED 60 NM	6-50-NB260-D01	
12	GT VPE PCB H-60MM 24G/350G/5G L-600MM P170HM	6-23-7P170-021	
13	WIRE CABLE CCD-NUC TO NO 32MM 5V 0P/N R/L P170SM-A	6-43-P17ST-A11	
14	LCD HINGE L SECC (PVT) P170EM	6-33-P17E1-0L1	
15	LCD HINGE R SECC (PVT) P170EM	6-33-P17E1-0R1	
16	LCD HINGE L SECC (PVT) P170EM	6-23-7P170-031	
17	TABLE 24H - BACK COVER MODULE ASSY P170SM-A	6-79-P170SMA1-001	
18	BACK PROTECTION MYLAR (B83S+3M91S) P170HM	6-40-P1701-020	
19	SCREW M2.5X4L K1 BK/D ICT NY	6-35-B4125-4RA	

COMBO

Figure A - 6
COMBO



DVD-Dual Drive




Figure A - 7
DVD-Dual Drive

Part Lists

Appendix B: Schematic Diagrams

This appendix has circuit diagrams of the **P170SM-A** notebook's PCB's. The following table indicates where to find the appropriate schematic diagram.

Diagram - Page	Diagram - Page	Diagram - Page	Diagram - Page
Block Diagram - Page B - 2	Lynix Point 2/9 - Page B - 21	DDR 1.35V/0.75VS PCH 1.5V - Page B - 40	P150 2nd HDD Board - Page B - 59
Processor 1/7 - Page B - 3	Lynix Point3/9 - Page B - 22	VDD3, VDD5 - Page B - 41	Indicatory LED Board - Page B - 60
Processor 2/7 - Page B - 4	Lynix Point 4/9 - Page B - 23	5V, 5VS, 3.3V, 3.3VS, 1.5VS - Page B - 42	Function LED Board - Page B - 61
Processor 3/7 - Page B - 5	Lynix Point 5/9 - Page B - 24	Power 1.05VS - Page B - 43	2nd mSATA Board - Page B - 63
Processor 4/7 - Page B - 6	Lynix Point 6/9 - Page B - 25	LED 5V - Page B - 44	Power on / S4 Resume Seq. - Page B - 64
Processor 5/7 - Page B - 7	Lynix Point 7/9 - Page B - 26	Power V-Core 1 - Page B - 45	S3 Resume Seq. - Page B - 65
Processor 6/7 - Page B - 8	Lynix Point 8/9 - Page B - 27	AC_In, Charger - Page B - 46	Into S3 Sequence - Page B - 66
Processor 7/7 - Page B - 9	Lynix Point 9/9 - Page B - 28	TPM - Page B - 47	Into S4 Sequence - Page B - 67
DDR3 CHA SO-DIMM_0 - Page B - 10	USB+eSATA, USB Charging - Page B - 29	Audio Board - Page B - 48	
DDR3 CHA SO-DIMM_1 - Page B - 11	USB 2.0, CCD, Mini PCIE, LID - Page B - 30	P150 ODD Board - Page B - 49	
DDR3 CHB SO-DIMM_1 - Page B - 12	LED, Hotkey, LID SW, Fan - Page B - 31	P150 Click Board - Page B - 50	
DDRIII CHB SO-DIMM_0 - Page B - 13	RJ 45 - Page B - 32	Power LED Board - Page B - 51	
MXM PCI-E - Page B - 14	Codec Realtek ALC892 - Page B - 33	Function LED Board - Page B - 52	
Panel, Inverter, CRT - Page B - 15	APA2607-TPA2008D2 - Page B - 34	Indicatory LED Board - Page B - 53	
PS8625 - Page B - 16	KBC-ITE IT8587A - Page B - 35	P170 2nd HDD Board - Page B - 54	
1394a_XIO2221 - Page B - 17	Backlight Keyboard - Page B - 36	Power & LED Board - Page B - 55	
Display Port - Page B - 18	mSATA, FAN, TP, FP, MULTI-CON - Page B - 37	P170 Click Board - Page B - 56	
HDMI - Page B - 19	Card Reader RTL8411 - Page B - 38	P150 Fingerprint Board - Page B - 57	
Lynix Point 1/9 - Page B - 20	USB 3.0 - Page B - 39	P170 Fingerprint Board - Page B - 58	

Table B - 1
Schematic
Diagrams





Version Note

The schematic diagrams in this chapter are based upon version 6-7P-P15SG-0A3. If your mainboard (or other boards) are a later version, please check with the Service Center for updated diagrams (if required).

Schematic Diagrams

Block Diagram







Schematic Diagrams

Processor 2/7

Sheet 3 of 66
Processor 2/7




Processor 3/7




Sheet 4 of 66
Processor 3/7

Processor 4/7

Sheet 5 of 66
Processor 4/7




Processor 5/7 B - 7




Schematic Diagrams

Processor 6/7

Sheet 7 of 66
Processor 6/7




Processor 7/7 B - 9



DDR3 CHA SO-DIMM_0


Channel A SO-DIMM 0 [RAM1]

CHANGE TO STANDARD




DDR3 CHA SO-DIMM_1

Sheet 10 of 66
DDR3 CHA SO-
DIMM_1



Channel B SO-DIMM 1 [RAM4]


Channel B SO-DIMM 0 [RAM2]




MXM PCI-E

B. Schematic Diagrams


Sheet 13 of 66
MXM PCI-E




Sheet 14 of 66
Panel, Inverter,
CRT



PS8625




Sheet 15 of 66
PS8625

1394a_XIO2221 B - 17




dGPU DISPLAY PORT

Close to Display PORT




3.3VS
5V2

HDMI



Sheet 18 of 66
HDMI


Lynx Point 1/9



Sheet 19 of 66
Lynx Point 1/9

B.Schematic Diagrams

Lynx Point 2/9




Sheet 20 of 66
Lynx Point 2/9

Lynix Point3/9

B.Schematic Diagrams


Sheet 21 of 66
Lynix Point 3/9



Lynx Point 4/9 B - 23



Lynx Point 5/9




Lynx Point 6/9 B - 25




Schematic Diagrams

Lynx Point 7/9

Sheet 25 of 66
Lynx Point 7/9




Lynix Point 8/9 B - 27



Lynix Point 9/9

Sheet 27 of 66
Lynx Point 9/9




Schematic Diagrams




Schematic Diagrams

USB 2.0, CCD, Mini PCIE, LID

Sheet 29 of 66
USB 2.0, CCD,
Mini PCIE, LED




Sheet 30 of 66
LED, Hotkey,
LID SW, Fan



RJ 45

B. Schematic Diagrams

Sheet 31 of 66
RJ 45



Layout Note:

- (1)(3)MIC1-L (U13.21) (2)MIC1-R (U13.22)
- (3)LINE-L (U13.23) (4)LINE-R (U13.24)

周圍必須包圍 AUDIO，且儘量避免跨線
+SVS & +VIN plane.

Layout Note:

- (1)(3)MIC1-L (U13.21) (2)MIC1-R (U13.22)
- (3)LINE-L (U13.23) (4)LINE-R (U13.24)

周圍必須包圍 AUDIO，且儘量避免跨線
+SVS & +VIN plane.

Connect standby power(for pop noise)

HeadPhone

VT1818S P2P ALC892

DIGITAL


ANALOG

BluRay content protection


Schematic Diagrams

APA2607-TPA2008D2

Sheet 33 of 66
APA2607-
TPA2008D2




KBC-ITE IT8587A




Sheet 34 of 66
KBC-ITE IT8587A

Backlight Keyboard

Sheet 35 of 66
Backlight
Keyboard



mSATA, FAN, TP, FP, MULTI-CON




Sheet 36 of 66
mSATA, FAN, TP,
FP, MULTI-CON


B.Schematic Diagrams

Card Reader RTL8411

Sheet 37 of 66
Card Reader
RTL8411




USB 3.0




Sheet 38 of 66
USB 3.0

B. Schematic Diagrams

Sheet 39 of 66
DDR 1.35V/0.75VS
PCH 1.5V




VDD3, VDD5




Sheet 40 of 66
VDD3, VDD5

B. Schematic Diagrams


Sheet 41 of 66
5V, 5VS, 3.3V,
3.3VS, 1.5VS



Power 1.05VS


Sheet 42 of 66
Power 1.05VS

LED 5V




Sheet 43 of 66
LED 5V

Power V-Core 1



Sheet 44 of 66
Power V-Core 1

AC_In, Charger




[illegible]

Sheet 46 of 66
TPM


Schematic Diagrams

Audio Board

Sheet 47 of 66
Audio Board




P150 ODD Board

Sheet 48 of 66
P150 ODD Board


Schematic Diagrams

P150 Click Board

Sheet 49 of 66
P150 Click Board




Power LED Board




Sheet 50 of 66
Power LED Board

Function LED Board



Sheet 51 of 66
Function LED
Board

Indicator LED Board




Sheet 52 of 66
Indicator LED
Board


P170 2nd HDD Board

Sheet 53 of 66
P170 2nd HDD
Board

P170 ONLY



Power & LED Board




Sheet 54 of 66
Power & LED Board


Schematic Diagrams

P170 Click Board

Sheet 55 of 66
P170 Click Board



P150 Fingerprint Board




Sheet 56 of 66
P150 Fingerprint
Board


Schematic Diagrams

P170 Fingerprint Board

Sheet 57 of 66
P170 Fingerprint
Board




P150 2nd HDD Board



Sheet 58 of 66
P150 2nd HDD
Board


Indicator LED Board



Sheet 59 of 66
Indicator LED
Board

B.Schematic Diagrams


Function LED Board




Sheet 60 of 66
Function LED
Board

Mini-DP

Sheet 61 of 66
MIni-DP




2nd mSATA Board




Sheet 62 of 66
2nd mSATA Board


Power on / S4 Resume Seq.



S3 Resume Seq.


Sheet 64 of 66
S3 Resume Seq.

Into S3 Sequence



Sheet 65 of 66
Into S3 Sequence

Into S4 Sequence



Sheet 66 of 66
Into S4 Sequence

Appendix C: Updating the FLASH ROM BIOS

To update the FLASH ROM BIOS, you must:

- Download the BIOS update from the web site.
- Unzip the files onto a bootable CD/DVD/USB Flash Drive.
- Reboot your computer from an external CD/DVD/USB Flash Drive.
- Use the flash tools to update the flash BIOS using the commands indicated below.
- Restart the computer booting from the HDD and press **F2** at startup enter the BIOS.
- Load setup defaults from the BIOS and save the default settings and exit the BIOS to restart the computer.
- After rebooting the computer you may restart the computer again and make any required changes to the default BIOS settings.

Download the BIOS

1. Go to www.clevo.com.tw and point to **E-Services** and click **E-Channel**.
2. Use your user ID and password to access the appropriate download area (BIOS), and download the latest BIOS files (the BIOS file will be contained in a batch file that may be run directly once unzipped) for your computer model (see sidebar for important information on BIOS versions).

Unzip the downloaded files to a bootable CD/DVD or USB Flash drive

1. Insert a bootable CD/DVD/USB flash drive into the CD/DVD drive/USB port of the computer containing the downloaded files.
2. Use a tool such as Winzip or Winrar to unzip all the BIOS files and refresh tools to your bootable CD/DVD/USB flash drive (you may need to create a bootable CD/DVD with the files using a 3rd party software).

Set the computer to boot from the external drive

1. With the bootable CD/DVD/USB flash drive containing the BIOS files in your CD/DVD drive/USB port, restart the computer and press **F2** (in most cases) to enter the BIOS.
2. Use the arrow keys to highlight the **Boot** menu.
3. Use the “+” and “-” keys to move boot devices up and down the priority order.
4. Make sure that the CD/DVD drive/USB flash drive is set first in the boot priority of the BIOS.
5. Press **F4** to save any changes you have made and exit the BIOS to restart the computer.



BIOS Version

Make sure you download the latest correct version of the BIOS appropriate for the computer model you are working on.

You should only download BIOS versions that are **V1.01.XX or higher** as appropriate for your computer model.

Note that BIOS versions are not backward compatible and therefore **you may not downgrade your BIOS to an older version** after upgrading to a later version (e.g if you upgrade a BIOS to ver 1.01.05, you **MAY NOT** then go back and flash the BIOS to ver 1.01.04).

BIOS Update

Use the flash tools to update the BIOS

1. Make sure you are not loading any memory management programs such as HIMEM by holding the **F8** key as you see the message “**Starting MS-DOS**”. You will then be prompted to give “**Y**” or “**N**” responses to the programs being loaded by DOS. Choose “**N**” for any memory management programs.
2. You should now be at the DOS prompt e.g: **DISK C:\>** (C is the designated drive letter for the CD/DVD drive/USB flash drive).
3. **Type the following command** at the DOS prompt:

C:\> Flash.bat

4. The utility will then proceed to flash the BIOS.
5. You should then be prompted to press any key to restart the system or turn the power off, and then on again but make sure you remove the CD/DVD/USB flash drive from the CD/DVD drive/USB port before the computer restarts.

Restart the computer (booting from the HDD)

1. With the CD/DVD/USB flash drive removed from the CD/DVD drive/USB port the computer should restart from the HDD.
2. Press **F2** as the computer restarts to enter the BIOS.
3. Use the arrow keys to highlight the **Exit** menu.
4. Select **Load Setup Defaults** (or press **F3**) and select “**Yes**” to confirm the selection.
5. Press **F4** to save any changes you have made and exit the BIOS to restart the computer.

Your computer is now running normally with the updated BIOS

You may now enter the BIOS and make any changes you require to the default settings.