

SERVICE MANUAL

PB50EF / PB51EF

notebook



Notebook Computer

PB50EF / PB51EF

Service Manual

Notice

The company reserves the right to revise this publication or to change its contents without notice. Information contained herein is for reference only and does not constitute a commitment on the part of the manufacturer or any subsequent vendor. They assume no responsibility or liability for any errors or inaccuracies that may appear in this publication nor are they in anyway responsible for any loss or damage resulting from the use (or misuse) of this publication.

This publication and any accompanying software may not, in whole or in part, be reproduced, translated, transmitted or reduced to any machine readable form without prior consent from the vendor, manufacturer or creators of this publication, except for copies kept by the user for backup purposes.

Brand and product names mentioned in this publication may or may not be copyrights and/or registered trademarks of their respective companies. They are mentioned for identification purposes only and are not intended as an endorsement of that product or its manufacturer.

Version 1.0
February 2019

Trademarks

Intel and Intel Core are trademarks of Intel Corporation.

Windows® is a registered trademark of Microsoft Corporation.

Other brand and product names are trademarks and /or registered trademarks of their respective companies.



About this Manual

This manual is intended for service personnel who have completed sufficient training to undertake the maintenance and inspection of personal computers.

It is organized to allow you to look up basic information for servicing and/or upgrading components of the **PB50EF** / **PB51EF** series notebook PC.

The following information is included:

Chapter 1, Introduction, provides general information about the location of system elements and their specifications.
Chapter 2, Disassembly, provides step-by-step instructions for disassembling parts and subsystems and how to upgrade elements of the system.

Appendix A, Part Lists

Appendix B, Schematic Diagrams

Appendix C, Updating the FLASH ROM BIOS

Preface

IMPORTANT SAFETY INSTRUCTIONS

Follow basic safety precautions, including those listed below, to reduce the risk of fire, electric shock and injury to persons when using any electrical equipment:

1. Do not use this product near water, for example near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electrical shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
5. This product is intended to be supplied by a Listed Power Unit as follows:
 - AC Input of 100 - 240V, 50 - 60Hz, DC Output of 19.5V, 11.8A (**230** Watts) minimum AC/DC Adapter.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.


Instructions for Care and Operation

The notebook computer is quite rugged, but it can be damaged. To prevent this, follow these suggestions:


1. **Don't drop it, or expose it to shock.** If the computer falls, the case and the components could be damaged.



2. **Keep it dry, and don't overheat it.** Keep the computer and power supply away from any kind of heating element. This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.




3. **Follow the proper working procedures for the computer.** Shut the computer down properly and don't forget to save your work. Remember to periodically save your data as data may be lost if the battery is depleted.



Preface


4. **Avoid interference.** Keep the computer away from high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage your data.
5. **Take care when using peripheral devices.**



Power Safety

The computer has specific power requirements:

- Only use a power adapter approved for use with this computer.
- Your AC adapter may be designed for international travel but it still requires a steady, uninterrupted power supply. If you are unsure of your local power specifications, consult your service representative or local power company.
- The power adapter may have either a 2-prong or a 3-prong grounded plug. The third prong is an important safety feature; do not defeat its purpose. If you do not have access to a compatible outlet, have a qualified electrician install one.
- When you want to unplug the power cord, be sure to disconnect it by the plug head, not by its wire.
- Make sure the socket and any extension cord(s) you use can support the total current load of all the connected devices.
- Before cleaning the computer, make sure it is disconnected from any external power supplies.



Power Safety Warning

Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines and power cord). It is advisable to also remove your battery in order to prevent accidentally turning the machine on.

Battery Precautions

- Only use batteries designed for this computer. The wrong battery type may explode, leak or damage the computer.
- Do not continue to use a battery that has been dropped, or that appears damaged (e.g. bent or twisted) in any way. Even if the computer continues to work with a damaged battery in place, it may cause circuit damage, which may possibly result in fire.
- Recharge the batteries using the notebook's system. Incorrect recharging may make the battery explode.
- Do not try to repair a battery pack. Refer any battery pack repair or replacement to your service representative or qualified service personnel.
- Keep children away from, and promptly dispose of a damaged battery. Always dispose of batteries carefully. Batteries may explode or leak if exposed to fire, or improperly handled or discarded.
- Keep the battery away from metal appliances.
- Affix tape to the battery contacts before disposing of the battery.
- Do not touch the battery contacts with your hands or metal objects.

Battery Guidelines

The following can also apply to any backup batteries you may have.

- If you do not use the battery for an extended period, then remove the battery from the computer for storage.
- Before removing the battery for storage charge it to 60% - 70%.
- Check stored batteries at least every 3 months and charge them to 60% - 70%.



Battery Disposal

The product that you have purchased contains a rechargeable battery. The battery is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal.

Caution

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used battery according to the manufacturer's instructions.

Battery Level

Click the battery icon  in the taskbar to see the current battery level and charge status. A battery that drops below a level of 10% will not allow the computer to boot up. Make sure that any battery that drops below 10% is recharged within one week.

Related Documents

You may also need to consult the following manual for additional information:

User's Manual on CD/DVD

This describes the notebook PC's features and the procedures for operating the computer and its ROM-based setup program. It also describes the installation and operation of the utility programs provided with the notebook PC.

System Startup

1. Remove all packing materials.
2. Place the computer on a stable surface.
3. Insert the battery and make sure it is locked in position.
4. Securely attach any peripherals you want to use with the computer (e.g. keyboard and mouse) to their ports.
5. **When first setting up the computer use the following procedure** (as to safeguard the computer during shipping, the battery will be locked to not power the system until first connected to the AC/DC adapter and initially set up as below):
 - Attach the AC/DC adapter cord to the DC-In jack on the left of the computer, then plug the AC power cord into an outlet, and connect the AC power cord to the AC/DC adapter and **leave it there for 6 seconds or longer**.
 - Remove the adapter cord from the computer's DC-In jack, and then plug it back in again; the battery will now be unlocked.
6. Use one hand to raise the lid/LCD to a comfortable viewing angle (do not exceed 130 degrees); use the other hand (as illustrated in Figure 1) to support the base of the computer (**Note: Never** lift the computer by the lid/LCD).
7. Press the power button to turn the computer "on".





Figure 1
**Opening the Lid/LCD/
Computer with AC/DC
Adapter Plugged-In**



Shut Down

Note that you should always shut your computer down by choosing the **Shut down** command in **Windows** (see below). This will help prevent hard disk or system problems.

1. Click the Start Menu icon .
2. Click the **Power** item .
3. Choose **Shut Down** from the menu.



Contents

Introduction1-1

Overview	1-1
Specifications	1-2
External Locator - Top View with LCD Panel Open	1-4
External Locator - Front & Right Side Views	1-5
External Locator - Left Side & Rear View	1-6
External Locator - Bottom View	1-7
Mainboard Overview - Top (Key Parts)	1-8
Mainboard Overview - Bottom (Key Parts)	1-9
Mainboard Overview - Top (Connectors)	1-10
Mainboard Overview - Bottom (Connectors)	1-11

Disassembly2-1

Overview	2-1
Maintenance Tools	2-2
Connections	2-2
Maintenance Precautions	2-3
Disassembly Steps	2-4
Removing the Battery	2-5
Removing the Keyboard	2-6
Removing the Hard Disk Drive	2-7
Removing the System Memory (RAM)	2-9
Removing the M.2 SSD Module	2-10
Removing the Wireless LAN Module	2-11
Wireless LAN, Combo Module Cables	2-12
Removing the CCD	2-13

Part ListsA-1

Part List Illustration Location	A-2
Top	A-3
Bottom	A-4

Main Board	A-5
HDD	A-6
LCD	A-7

Schematic Diagrams.....B-1

System Block Diagram	B-2
Processor 1/6	B-3
Processor 2/6	B-4
Processor 3/6	B-5
Processor 4/6	B-6
Processor 5/6	B-7
Processor 6/6	B-8
DDR4 CHA SO-DIMM_0	B-9
DDR4 CHB SO-DIMM_0	B-10
Panel	B-11
HDMI	B-12
Mini DP Port	B-13
PS8330B	B-14
PS8331	B-15
GPU 1/6	B-16
GPU 2/6	B-17
Frame Buffer Partition A	B-18
Frame Buffer Partition A	B-19
Frame Buffer Partition B	B-20
Frame Buffer Partition B	B-21
GPU 3/6	B-22
Frame Buffer Partition C	B-23
Frame Buffer Partition C	B-24
Frame Buffer Partition D	B-25
Frame Buffer Partition D	B-26
GPU 4/6	B-27

Preface

GPU 5/6	B-28	TR-TBT	B-60
IFP I/O Interface	B-29	AR_TBT_SP PWR	B-61
GPU 6/6	B-30	TPS65987	B-62
GPU NVVDD, FBVDDQ	B-31	TBT/Type C	B-63
GPU GND	B-32	Conn_to Extend Board	B-64
GPU Decoupling	B-33	3.3VA, 3.3V, 3.3VS, 5VS	B-65
GPU Decoupling 2	B-34	PWR_SW VCCST, STG, SFR_OC	B-66
GPU Pwr Ctrl, Level Shift	B-35	PWR_SW 1V8_AON, RUN	B-67
PCH 1/9	B-36	VDD3, VDD5	B-68
PCH 2/9	B-37	DDR 1.2V, 0.6VS, 2.5V	B-69
PCH 3/9	B-38	1.8VA, 1.05VA	B-70
PCH 4/9	B-39	VCCIO	B-71
PCH 5/9	B-40	VCore, VCCGT, VCCSA	B-72
PCH 6/9	B-41	VCore Output Stage	B-73
PCH 7/9	B-42	VCCGT, VCCSA	B-74
PCH 8/9	B-43	NVVDD 1 & 2	B-75
PCH 9/9	B-44	NVVDD 3	B-76
HDD Port	B-45	PEX_VDD	B-77
M.2 WLAN+BT	B-46	FBVDDQ	B-78
M.2 PCIEX4 SATA	B-47	AC-In, Charger	B-79
CCD, FP	B-48	LED Board	B-80
USB	B-49	Power Board	B-81
USB Redriver	B-50	HDD Board	B-82
ANX7440	B-51	Audio Board, Fan	B-83
USB+DP Type-C	B-52	Audio Board_USB	B-84
TPM	B-53	Audio Board_AMP, Jack	B-85
LAN RTL8111H	B-54	Per Keyboard	B-86
ALC1220	B-55	RTS5250	B-87
EC ITE8587	B-56	AMP TPA2008D2	B-88
Fan, TP, Smart AMP PWR	B-57	Subwoofer	B-89
LED Keyboard Ctrl	B-58	Smart AMP	B-90
LID	B-59	Smart AMP for Subwoofer	B-91

Speaker Con B-92

Chapter 1: Introduction

Overview

This manual covers the information you need to service or upgrade the **PB50EF / PB51EF** series notebook computer. Information about operating the computer (e.g. getting started, and the *Setup* utility) is in the *User's Manual*. Information about drivers (e.g. VGA & audio) is also found in the *User's Manual*. The manual is shipped with the computer.

Operating systems (e.g. *Windows 10*, etc.) have their own manuals as do application softwares (e.g. word processing and database programs). If you have questions about those programs, you should consult those manuals.

The **PB50EF / PB51EF** series notebook is designed to be upgradeable. See [Disassembly on page 2 - 1](#) for a detailed description of the upgrade procedures for each specific component. Please take note of the warning and safety information indicated by the “” symbol.

The balance of this chapter reviews the computer's technical specifications and features.

Introduction

Specifications



Latest Specification Information

The specifications listed here are correct at the time of sending them to the press. Certain items (particularly processor types/speeds) may be changed, delayed or updated due to the manufacturer's release schedule. Check with your service center for more details.



CPU Speed & Computer in DC Mode

Note that when the computer is in DC mode (powered by the battery only) the CPU may not run at full speed. This is a design feature implemented in order to protect the battery.

Processor Options

i9-8950HK (2.90GHz)

12MB Smart Cache, **14nm**, DDR4-2666MHz, TDP 45W

i7-8750H (2.20GHz)

9MB Smart Cache, **14nm**, DDR4-2666MHz, TDP 45W

Core Logic

Intel® HM370 Express Chipset

LCD Options

15.6" (39.62cm), 16:9, UHD (3840x2160)/FHD (1920x1080)

BIOS

128Mb SPI Flash ROM

INSYDE BIOS

Memory

Dual Channel DDR4

Two 260 Pin SO-DIMM Sockets

Supporting **DDR4 2666MHz** Memory Modules

Memory Expandable from **8GB (minimum)** up to **64GB (maximum)**

Compatible with 4GB, 8GB, 16GB or 32GB Modules

(The real memory operating frequency depends on the FSB of the processor.)

Supports XMP 3000MHz (XMP is processor dependent)

Security

Security (Kensington® Type) Lock Slot

BIOS Password

Intel PTT for Systems Without TPM Hardware

(Factory Option) TPM 2.0

(Factory Option) Fingerprint Sensor

Video Adapter Options

Microsoft Hybrid Graphics Mode or Discrete Graphics Mode

Supports up to 4 Active Displays

Supports NVIDIA Surround View via HDMI x 1, MiniDP x1 and Display Port over Type-C

Intel Integrated GPU

Intel® UHD Graphics 630

Dynamic Frequency

Intel Dynamic Video Memory Technology

Microsoft DirectX®12 Compatible

NVIDIA® Discrete GPU

NVIDIA® GeForce RTX 2070

8GB GDDR6 Video RAM

Microsoft DirectX®12 Compatible

Pointing Device

(Factory Option) Built-in Touchpad/Secure Pad (with Microsoft PTP Multi Gesture & Scrolling Functionality)

Keyboard

Full Size **Multi Full Color** LED Keyboard (with numeric keypad)

Or

(Factory Option) Full Size **Full Color** "Per Key" LED Keyboard (with numeric keypad)

Storage

One changeable 2.5" (6cm) **7.0mm (h)** **SATA** (Serial) Hard Disk Drive/Solid State Drive (SSD)

(Factory Option) **One** M.2 **SATA/PCIe Gen3 x4** Solid State Drive (SSD)

Audio

High Definition Audio Compliant Interface
S/PDIF Digital Output
Built-In Array Microphone
Two Speakers
Sound BlasterX® Pro-Gaming 360°
Or
Sound Blaster Cinema 5

Communication

1.0M HD PC Camera Module
Built-In 10/100/1000Mb Base-TX Ethernet LAN

WLAN/ Bluetooth M.2 Modules:

(**Factory Option**) Intel® Dual Band Wireless-AC 9260 Wireless LAN (**802.11ac**) + Bluetooth

(**Factory Option**) Intel® Dual Band Wireless-AC 9560 Wireless LAN (**802.11ac**) + Bluetooth

(**Factory Option**) Intel® Dual Band Wireless-AC 9462 Wireless LAN (**802.11ac**) + Bluetooth

(**Factory Option**) Qualcomm® Atheros Killer™ Wireless-AC 1550i Wireless LAN (**802.11ac**) + Bluetooth

Card Reader

Embedded Multi-In-1 Push-Push Card Reader
MMC (MultiMedia Card) / RS MMC
SD (Secure Digital) / Mini SD / SDHC/ SDXC

M.2 Slots

Slot 1 for **Combo WLAN and Bluetooth** Module
Slot 2 for **SATA or PCIe Gen3 x4 SSD**
Slot 3 for **PCIe Gen3 x4 SSD**

Interface

One USB 3.1 Gen 2 Type-C Port*

**The maximum amount of current supplied by USB Type-C ports is 500mA (USB 2.0)/900mA (USB 3.1).*

Or

(**Factory Option**) One Thunderbolt 3 Port**

***The maximum amount of current supplied by Thunderbolt 3 port is 3000mA.*

Three USB 3.0 (USB 3.1 Gen 1) Type-A Ports (Including one AC/DC Powered USB Port)

One DisplayPort 1.3 over USB 3.1 Gen 2 Type-C Port

One Mini DisplayPort 1.3

One HDMI-Out Port

One 2- In-1 Audio Jack (Microphone and S/PDIF Optical)

One 2- In-1 Audio Jack (Headphone and Microphone)

One RJ-45 LAN Jack

One DC-In Jack

**USB 3.1 Gen 2**

Note that when a single USB device is plugged in to a USB 3.1 Gen 2 port the data transfer speed will be 10Gbps, however when two devices are plugged in to both USB 3.1 Gen 2 ports, this bandwidth will be shared between the ports.

Features

Intel® Optane™ Technology

Supports NVIDIA® G-SYNC™ Technology

(NVIDIA® G-SYNC™ Technology is supported by some LCD panels and RTX series video adapters Only)

Virtual Reality Ready

Windows® Mixed Reality Compatible

(**Factory Option**) USB Drive

Environmental Spec**Temperature**

Operating: 5°C - 35°C

Non-Operating: -20°C - 60°C

Relative Humidity

Operating: 20% - 80%

Non-Operating: 10% - 90%

Power

Removable 6 Cell Smart Lithium-Ion Battery Pack, 62WH

Full Range AC/DC Adapter

AC Input: 100 - 240V, 50 - 60Hz

DC Output: 19.5V, 11.8A (**230W**)

Dimensions & Weight

359mm (w) * 257.8mm (d) * 29.9mm (h)

2.5kg (Barebone with 62WH Battery)

Introduction

Figure 1
Top View

1. PC Camera
2. *PC Camera LED
**When the PC camera is in use, the LED will be illuminated.*
3. Built-In Array Microphone
4. LCD
5. Power Button
6. Keyboard
7. Touchpad & Buttons
8. Fingerprint Sensor (Optional)

External Locator - Top View with LCD Panel Open



External Locator - Front & Right Side Views

FRONT VIEW



RIGHT SIDE VIEW



Figure 2
Front View

1. LED Indicator
2. Multi-in-1 Card Reader

Figure 3
Right Side View

1. USB 3.1 Gen 2 Type-C Port Or
(Factory Option) Thunderbolt 3 Port
2. USB 3.0 (USB 3.1 Gen 1) Type-A Port
3. Vent

Introduction

External Locator - Left Side & Rear View

Figure 4
Left Side View

1. Security Lock Slot
2. Vent
3. *Powered USB 3.0 (USB 3.1 Gen 1) Type-A Port
4. 2-In-1 Audio Jack (Microphone and S/PDIF Optical)
5. 2-In-1 Audio Jack (Headphone and Microphone)

LEFT SIDE VIEW



Figure 5
Rear View

1. Vent
2. RJ-45 LAN Jack
3. HDMI-Out Port
4. Mini DisplayPort 1.3
5. DisplayPort 1.3 over USB 3.1 Gen 2 Type-C Port
6. USB 3.0 (USB 3.1 Gen 1) Type-A Port
7. DC-In Jack

REAR VIEW



External Locator - Bottom View




Figure 6
Bottom View

1. Vent
2. Battery
3. Speakers




Overheating

To prevent your computer from overheating, make sure nothing blocks any vent while the computer is in use.

Figure 7
**Mainboard Top
Key Parts**

1. KBC-ITE IT8587

Mainboard Overview - Top (Key Parts)



Mainboard Overview - Bottom (Key Parts)




Figure 8
**Mainboard Bottom
Key Parts**


1. PCH
2. GPU
3. CPU
4. Memory Slots
DDR4 SO-DIMM
5. Mini-Card
Connector (M.2
PCIE/SATA SSD
Module)
6. Mini-Card
Connector (M.2
PCIE Module)
7. Mini-Card
Connector (WLAN
Module)

Introduction

Figure 9
**Mainboard Top
Connectors**

1. Per Key Cable Connector
2. Keyboard Cable Connector
3. LED Keyboard Cable Connector
4. Power Switch Connector
5. Multi-in-1 Card Reader
6. USB 3.1 Gen 2 Type-C Port Or
(Factory Option) Thunderbolt 3 Port
7. USB 3.0 (USB 3.1 Gen 1) Type-A Port

Mainboard Overview - Top (Connectors)



Mainboard Overview - Bottom (Connectors)




Figure 10
**Mainboard Bottom
Connectors**

1. RJ-45 LAN Jack
2. HDMI-Out Port
3. Mini DisplayPort 1.3
4. DisplayPort 1.3 over USB 3.1 Gen 2 Type-C Port
5. USB 3.0 (USB 3.1 Gen 1) Type-A Port
6. DC-In Jack
7. Battery Connector
8. HDD Cable Connector
9. Touchpad Cable Connector
10. LED Indicator Connector
11. Audio Board Connector
12. Panel Connector

Chapter 2: Disassembly

Overview

This chapter provides step-by-step instructions for disassembling the **PB50EF / PB51EF** series notebook's parts and subsystems. When it comes to reassembly, reverse the procedures (unless otherwise indicated).



We suggest you completely review any procedure before you take the computer apart.

Procedures such as upgrading/replacing the RAM, optical device and hard disk are included in the User's Manual but are repeated here for your convenience.

To make the disassembly process easier each section may have a box in the page margin. Information contained under the figure # will give a synopsis of the sequence of procedures involved in the disassembly procedure. A box with a  lists the relevant parts you will have after the disassembly process is complete. **Note:** The parts listed will be for the disassembly procedure listed ONLY, and not any previous disassembly step(s) required. Refer to the part list for the previous disassembly procedure. The amount of screws you should be left with will be listed here also.

A box with a  will also provide any possible helpful information. A box with a  contains warnings.

An example of these types of boxes are shown in the sidebar.




Disassembly

NOTE: All disassembly procedures assume that the system is turned **OFF**, and disconnected from any power supply (the battery is removed too).

Maintenance Tools

The following tools are recommended when working on the notebook PC:

- M3 Philips-head screwdriver
- M2.5 Philips-head screwdriver (magnetized)
- M2 Philips-head screwdriver
- Small flat-head screwdriver
- Pair of needle-nose pliers
- Anti-static wrist-strap



Connections

Connections within the computer are one of four types:

Locking collar sockets for ribbon connectors

To release these connectors, use a small flat-head screwdriver to gently pry the locking collar away from its base. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.

Pressure sockets for multi-wire connectors

To release this connector type, grasp it at its head and gently rock it from side to side as you pull it out. Do not pull on the wires themselves. When replacing the connection, do not try to force it. The socket only fits one way.

Pressure sockets for ribbon connectors

To release these connectors, use a small pair of needle-nose pliers to gently lift the connector away from its socket. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.

Board-to-board or multi-pin sockets

To separate the boards, gently rock them from side to side as you pull them apart. If the connection is very tight, use a small flat-head screwdriver - use just enough force to start.

Maintenance Precautions

The following precautions are a reminder. To avoid personal injury or damage to the computer while performing a removal and/or replacement job, take the following precautions:

1. **Don't drop it.** Perform your repairs and/or upgrades on a stable surface. If the computer falls, the case and other components could be damaged.
2. **Don't overheat it.** Note the proximity of any heating elements. Keep the computer out of direct sunlight.
3. **Avoid interference.** Note the proximity of any high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage components and/or data. You should also monitor the position of magnetized tools (i.e. screwdrivers).
4. **Keep it dry.** This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.
5. **Be careful with power.** Avoid accidental shocks, discharges or explosions.
 - Before removing or servicing any part from the computer, turn the computer off and detach any power supplies.
 - When you want to unplug the power cord or any cable/wire, be sure to disconnect it by the plug head. Do not pull on the wire.
6. **Peripherals** – Turn off and detach any peripherals.
7. **Beware of static discharge.** ICs, such as the CPU and main support chips, are vulnerable to static electricity. Before handling any part in the computer, discharge any static electricity inside the computer. When handling a printed circuit board, do not use gloves or other materials which allow static electricity buildup. We suggest that you use an anti-static wrist strap instead.
8. **Beware of corrosion.** As you perform your job, avoid touching any connector leads. Even the cleanest hands produce oils which can attract corrosive elements.
9. **Keep your work environment clean.** Tobacco smoke, dust or other air-born particulate matter is often attracted to charged surfaces, reducing performance.
10. **Keep track of the components.** When removing or replacing any part, be careful not to leave small parts, such as screws, loose inside the computer.

Cleaning

Do not apply cleaner directly to the computer, use a soft clean cloth.

Do not use volatile (petroleum distillates) or abrasive cleaners on any part of the computer.

(For Computer Models Supplied with Light Blue Cleaning Cloth) Some computer models in this series come supplied with a light blue cleaning cloth. To clean the computer case with this cloth follow the instructions below.

- Power off the computer and peripherals.
- Disconnect the AC/DC adapter from the computer.
- Use a little water to dampen the cloth slightly.
- Clean the computer case with the cloth.
- Dry the computer with a dry cloth, or allow it time to dry before turning on.
- Reconnect the AC/DC adapter and turn the computer on.



Power Safety Warning

Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines and power cord). It is advisable to also remove your battery in order to prevent accidentally turning the machine on.

Disassembly Steps

The following table lists the disassembly steps, and on which page to find the related information. **PLEASE PERFORM THE DISASSEMBLY STEPS IN THE ORDER INDICATED.**

To remove the Battery:

1. Remove the battery *page 2 - 5*

To remove the Keyboard:

1. Remove the battery *page 2 - 5*
2. Remove the keyboard *page 2 - 6*

To remove the HDD:

1. Remove the battery *page 2 - 5*
2. Remove the keyboard *page 2 - 6*
3. Remove the HDD *page 2 - 7*

To remove the System Memory:

1. Remove the battery *page 2 - 5*
2. Remove the keyboard *page 2 - 6*
3. Remove the HDD *page 2 - 7*
4. Remove the system memory *page 2 - 9*

To remove and install the M.2 SSD:

1. Remove the battery *page 2 - 5*
2. Remove the keyboard *page 2 - 6*
3. Remove the HDD *page 2 - 7*
4. Remove the M.2 SSD *page 2 - 10*

To remove the Wireless LAN Module:

1. Remove the battery *page 2 - 5*
2. Remove the keyboard *page 2 - 6*
3. Remove the HDD *page 2 - 7*
4. Remove the WLAN *page 2 - 11*

To remove the CCD Module:


1. Remove the battery *page 2 - 5*
2. Remove the CCD module *page 2 - 13*

Removing the Battery

1. Turn **off** the computer, turn it over.
2. Remove screws **1** - **2** (*Figure 1a*).
3. Carefully lift the battery **3** up in the direction of the arrow at point **4** (*Figure 1b*).
4. Remove the battery **3** off the computer (*Figure 1c*).
5. Reverse the process to install a new battery (do not forget to replace all the screws and bottom cover).

Figure 1
Battery Removal

- a. Remove the screws.
- b. Lift the battery up.
- c. Remove the battery.



- 3. Battery
- 2 Screws

Disassembly

Figure 2

Keyboard Removal

- a. Remove the screws from the bottom of the computer and then eject the keyboard using a special eject stick to push the keyboard out while releasing the keyboard as shown.
- b. Lift the keyboard up and disconnect the keyboard ribbon cable from the locking collar socket.
- c. Remove the keyboard.



Re-inserting the Keyboard

When re-inserting the keyboard firstly, align the keyboard tabs at the bottom of the keyboard with the slots in the case.




4. Eject Stick
6. Keyboard

- 2 Screws

Removing the Keyboard

1. Turn **off** the computer, remove the battery ([page 2 - 5](#)).
2. Remove screws **1** - **2** from the bottom of the computer.
3. Open it up with the LCD on a flat surface before pressing at point **3** to release the keyboard module (use the special eject stick **4** to do this) while releasing the keyboard in the direction of the arrow **5** as shown ([Figure 2a](#)).
4. Carefully lift the keyboard **6** up, being careful not to bend the keyboard ribbon cable **7**. Disconnect the keyboard ribbon cable **7** from the locking collar socket by using a flat-head screwdriver to pry the locking collar pins **8** away from the base ([Figure 2b](#)).
5. Carefully lift the keyboard **6** off the computer ([Figure 2c](#)).



Removing the Hard Disk Drive

The hard disk drive can be taken out to accommodate other 2.5" serial (SATA) hard disk drives with a height of 7mm (h). Follow your operating system's installation instructions, and install all necessary drivers and utilities (as outlined in **Chapter 4 of the User's Manual**) when setting up a new hard disk.

Hard Disk Disassembly Process

1. Turn **off** the computer, remove the battery ([page 2 - 5](#)) and keyboard ([page 2 - 6](#)).
2. Remove screws **1** - **2** ([Figure 3a](#)).
3. Remove the SD card cover **3** and screws **4** - **13** ([Figure 3b](#)).
4. Carefully lift the bottom case **14** up in the direction of the arrow at point **15** - **20** and remove it ([Figure 3c](#)).




Figure 3
HDD Assembly Removal

- a. Remove the screws.
- b. Remove the SD cover and screws.
- c. Remove the bottom case.



HDD System Warning

New HDD's are blank. Before you begin make sure:

You have backed up any data you want to keep from your old HDD.

You have all the CD-ROMs and FDDs required to install your operating system and programs.

If you have access to the internet, download the latest application and hardware driver updates for the operating system you plan to install. Copy these to a removable medium.



3. SD Card Cover
16. Bottom Case






- 12 Screws

Disassembly

Figure 4
**HDD Assembly
Removal (cont'd.)**

- d. Locate the HDD.
- e. Remove the screw.
- f. Slide and pull the HDD assembly out of the bay.
- g. Remove the screws and bracket from the HDD.

- 5. The HDD will be visible at point **21** on the mainboard (*Figure 4d*).
- 6. Remove screws **22** - **24** from the HDD assembly and disconnect the ribbon cable **25** from the locking collar socket by using a flat-head screwdriver to pry the locking collar pins **26** away from the base (*Figure 4e*).
- 7. Lift the hard disk assembly **27** out of the bay **28** (*Figure 4f*).
- 8. Remove screws **29** - **30** and bracket **31** from the hard disk **32** (*Figure 4g*).
- 9. Reverse the process to install a new hard disk (do not forget to carefully reinsert the bottom case in reverse order (see *Figure 3c*) and to replace the screws).



27. HDD Assembly
31. HDD Bracket
32. HDD

- 5 Screws

Removing the System Memory (RAM)

The computer has four memory sockets for 260 pin Small Outline Dual In-line Memory Modules (SO-DIMM) supporting DDR4 Up to 2400 MHz. The main memory can be expanded up to 64GB. The total memory size is automatically detected by the POST routine once you turn on your computer.

Memory Upgrade Process

1. Turn **off** the computer, remove the battery ([page 2 - 5](#)), keyboard ([page 2 - 6](#)) and bottom cover ([page 2 - 7](#)).
2. The RAM modules will be visible at point **1** on the mainboard ([Figure 5a](#)).
3. Gently pull the two release latches (**2** & **3**) on the sides of the memory socket in the direction indicated by the arrows ([Figure 5b](#)). The RAM module **4** will pop-up ([Figure 5c](#)), and you can then remove it.
4. Pull the latches to release the second module if necessary.
5. Insert a new module holding it at about a 30° angle and fit the connectors firmly into the memory slot.
6. The module will only fit one way as defined by its pin alignment. Make sure the module is seated as far into the slot as it will go. **DO NOT FORCE IT**; it should fit without much pressure.
7. Press the module in and down towards the mainboard until the slot levers click into place to secure the module.
8. Replace the bottom cover and the screws (see [page 2 - 7](#)).
9. Restart the computer to allow the BIOS to register the new memory configuration as it starts up.

Figure 5
RAM Module Removal

- a. The RAM modules will be visible at point **1** on the mainboard.
- b. Pull the release latches.
- c. Remove the module.




Contact Warning

Be careful not to touch the metal pins on the module's connecting edge. Even the cleanest hands have oils which can attract particles, and degrade the module's performance.



4. RAM Module



Disassembly




Figure 6
M.2 SSD-1 Module Removal

- Locate the M.2 SSD.
- Remove the screw.
- The M.2 SSD module will pop up.

Removing the M.2 SSD Module

M.2 SSD Removal Procedure

- Turn **off** the computer, remove the battery ([page 2 - 5](#)), keyboard ([page 2 - 6](#)) and bottom cover ([page 2 - 7](#)).
- The M.2 SSD modules will be visible at point **1** on the mainboard ([Figure 6a](#)).
- Remove the screw **2** ([Figure 6b](#)).
- The M.2 SSD module **3** ([Figure 6c](#)) will pop-up, and you can remove it from the computer.
- Reverse the process to install a new module (do not forget to replace the screws and thermal pad).



3.M2 SSD Module

- 1 Screw

Removing the Wireless LAN Module

1. Turn **off** the computer, remove the battery ([page 2 - 5](#)), keyboard ([page 2 - 6](#)) and bottom cover ([page 2 - 7](#)).
2. The Wireless LAN module will be visible at point **1** on the mainboard ([Figure 7a](#)).
3. Carefully disconnect the cables **2** & **3**, and then remove the screw **4** ([Figure 7b](#))
4. The Wireless LAN module **5** ([Figure 7c](#)) will pop-up, and you can remove it from the computer.




Figure 7
**Wireless LAN
Module Removal**

- a. Locate the WLAN.
- b. Disconnect the cables and remove the screw.
- c. The WLAN module will pop up.

Note: Make sure you reconnect the antenna cable to the “1 + 2” socket ([Figure 7b](#)).



5. Wireless LAN Module

- 1 Screw

Disassembly

Wireless LAN, Combo Module Cables

Note that the cables for connecting to the antennae on WLAN, WLAN & Bluetooth Combo modules are not labelled. The cables/covers (each cable will have either a black or transparent cable cover) are color coded for identification as outlined in the table below.

Module Type	Antenna Type	Cable Color	Cable Cover Type
WLAN/WLAN & Bluetooth Combo	WM 1	Black	Transparent
	WM 2	Black	White

Cable 1 is usually connected to antenna 1 on the module, and cable 2 to antenna 2.

Removing the CCD

1. Turn **off** the computer, turn it over to remove the battery ([page 2 - 5](#)).
2. Lay the computer down on a flat surface with the top case up forming a 130 degree angle.
3. Carefully run your fingers around the inner frame of the LCD panel to lift at points **1** - **4** as indicated by the arrows ([Figure 8a](#)).
4. Remove the LCD front cover **5** ([Figure 8b](#)).




Figure 8
CCD Removal

- a. Carefully release the inner frame of the LCD panel at the points indicated by the arrows.
- b. Remove the LCD front cover.



5. LCD Front Cover

Disassembly

Figure 9
CCD Removal
(cont'd)

- c. Disconnect the cable from the locking collar socket.
- d. Remove the CCD module.

- 5. Disconnect the cable ⑥ from the locking collar socket by using a flat-head screwdriver to pry the locking collar pins ⑦ away from the base (*Figure 9c*).
- 6. Remove the CCD module ⑧ (*Figure 9d*).
- 7. Reverse the process to install a new CCD module.



8. CCD Module

Appendix A:Part Lists

This appendix breaks down the **PB50EF / PB51EF** series notebook's construction into a series of illustrations. The component part numbers are indicated in the tables opposite the drawings.

Note: This section indicates the *manufacturer's* part numbers. Your organization may use a different system, so be sure to cross-check any relevant documentation.

Note: Some assemblies may have parts in common (especially screws). However, the part lists DO NOT indicate the total number of duplicated parts used.

Note: Be sure to check any update notices. The parts shown in these illustrations are appropriate for the system at the time of publication. Over the product life, some parts may be improved or re-configured, resulting in *new* part numbers.


Part List Illustration Location

The following table indicates where to find the appropriate part list illustration.

Table A - 1
**Part List Illustration
Location**

Part	
Top	<i>page A - 3</i>
Bottom	<i>page A - 4</i>
Main Board	<i>page A - 5</i>
HDD	<i>page A - 6</i>
LCD	<i>page A - 7</i>

Top




ITEM	PART NAME	PART NO	REMARK
1	KB FOR LED PER KEY KB US SERIES N950TD	6-N950TD-KB-LPK-US	
1	KB FOR MULTI ISC BL KB US SERIES N950TD	6-N950TD-KB-MCL-US	
2	PPE-PROCESS TOP CASE MODULE (W/O PROGRAM TOUCH PAD/MYLAR-SPONGE) PRESET	6-78-PB50EF02-011	FOR PB50EF/EDK-GX
2	PPE-PROCESS TOP CASE MODULE (W/O PROGRAM SECURE PAD/MYLAR-SPONGE) PRESET	6-78-PB50EF02-021	FOR PBS1EF/EDK-GX
2	PPE-PROCESS TOP CASE MODULE (W/O PROGRAM TOUCH PAD/MYLAR-SPONGE) PRESET	6-78-PB50ED12-010	FOR PB50ED1K-GX
2	PPE-PROCESS TOP CASE MODULE (W/O PROGRAM SECURE PAD/MYLAR-SPONGE) PRESET	6-78-PB50ED12-020	FOR PB50ED1K-GX
2	PPE-PROCESS TOP CASE MODULE (W/O PROGRAM TOUCH PAD/MYLAR-SPONGE) PRESET	6-78-PB51EF02-010	FOR PBS1EF/ED
2	PPE-PROCESS TOP CASE MODULE (W/O PROGRAM SECURE PAD/MYLAR-SPONGE) PRESET	6-78-PB51EF02-020	FOR PBS1EF/ED
2	PPE-PROCESS TOP CASE MODULE (W/O PROGRAM TOUCH PAD/MYLAR-SPONGE) PRESET	6-78-PB51ED12-010	FOR PBS1ED1K-GX
2	PPE-PROCESS TOP CASE MODULE (W/O PROGRAM SECURE PAD/MYLAR-SPONGE) PRESET	6-78-PB51ED12-020	FOR PBS1ED1K-GX
3	HINGE COVER L (PC+ABS) PB50EF	6-42-PB502-052	
4	SCREW M2x4L KI NI ICT NY (OD=04.5,DT=0.8)	6-35-B1120-4RC	
5	AUDIO JACK BOARD V3.0 (W/REDRIVER) PB50EF	6-77-PB508-D03	
6	SCREW M2.5x4L (D=4.6,T=0.8) KI NI ICT NY	6-35-B1125-4RA	
7	W/O HDD ASS'Y PB50EF	6-79-PB50EF0J-010	
7	W/HDD ASS'Y PB50EF	6-79-PB50EF0J-020	
8	KB TRANSFER BRACKET SECC PB50EF	6-33-PB502-030	
9	SCREW M2.5x2.5L KI BK/Z ICT NY(0.8,T=0.6)	6-35-B6125-2R5	
10	PER KEY BOARD V3.0 PB50EF	6-77-PB507-D03	
11	SCREW M2x2L KI BK/Z ICT NY(0.8,T=0.6)	6-35-B6120-2RE	
12	FFC CABLE PER-KEY TO MB (P=45) L=320MM 60V 40PIN Q00 PPSHET	6-43-PB500-072	FOR LED PER KEY KB
13	FFC CABLE TP TO MB (P=45) L=320MM 60V 40PIN Q00 PPSHET	6-43-PB500-052	FOR W/FF GAMMA SECURE PAD
14	SCREW M2x2L KI NI ICT NY (OD=05,T=0.8)	6-35-B1120-2RA	
15	FFC CABLE AUDIO TO MB (P=45) L=300MM 60V 40PIN Q00 PPSHET	6-43-PB500-032	
16	FFC CABLE HDD TO MB (P=45) L=265MM 60V 40PIN Q00 PPSHET	6-43-PB500-062	
17	SPEAKER CABLE R/L R 30MM L 180MM 2V 40P (CUTTER) PPSHET	6-23-5PB50-0S1	
18	SCREW M2x6.2L NI ICT NY FOR SPEAKER	6-35-Z1120-6R2	
19	LED BOARD V3.0 PB50EF	6-77-PB504-D03	
20	TP BRACKET AL5052 PB50EF	6-33-PB502-010	
21	CONDUCTIVE FOR TP/L38x45 MM PB50EF	6-47-PB502-020	
22	HDD BOARD V3.0 PB50EF	6-77-PB50N-D03	
23	GAMMA SECURE PAD FINGER PRINT STICKER FOR P95/P5/P7	6-45-P95N8-D10	FOR W/FF GAMMA TOUCH PAD
24	CONDUCTIVE CLOTH BOSS-1 PB50EF	6-47-PB502-010	
25	HINGE COVER R (PC+ABS) PB50EF	6-42-PB502-042	
26	TAPE MYLAR TRANSPARENT (20x10x0.05) P180HM	6-40-P1803-020	
27	FFC CABLE LED TO MB (P=45) L=557MM 60V 40PIN Q00 PPSHET	6-43-PB500-022	
28	FFC CABLE TP TO MB (P=45) L=407MM 60V 40PIN Q00 PPSHET	6-43-PB500-042	
29	PWR BTN BOARD V3.0 PB50EF	6-77-PB50C-D03	
30	FFC CABLE POWER TO MB (P=10) L=100MM 60V 4PIN Q00 PPSHET	6-43-PB500-012	
31	SCREW M2.5x8L KI BK/Z NY ICT	6-35-B6125-8R0	
32	ACETATE CLOTH (5x8x0.2T) NB70TJL	6-47-NB702-030	短期対策
33	W/O PER-KEY RUBBER (40.7x10) PB50EF	6-47-PB502-030	FOR FOR MULTI ISC BL KB
34	TAPE MYLAR (C) MYLAR M550J	6-40-M55J2-030	
35	TOP CASE MYLAR FR83 25x7x0.05 P180HM	6-40-P1802-030	

Figure A - 1
Top

Bottom

Figure A - 2
Bottom



ITEM	PART NAME	PART NO	REMARK
1	(PRE-PROCESS) BOTTOM CASE MODULE PB50EF	6-78-PB50EF03-010	
1	(PRE-PROCESS) BOTTOM CASE MODULE PB51EF	6-78-PB51EF03-010	
2	.SCREW M2.5*8L K1 BK/Z NY ICT	6-35-B6125-8R0	
3	PRODUCT LABEL FOR PB50EF	6-45-PB50EF03-010	
3	PRODUCT LABEL FOR PB50EF-G	6-45-PB50EFG3-010	
3	PRODUCT LABEL FOR PB51EF	6-45-PB51EF03-010	
3	PRODUCT LABEL FOR PB51EF-G	6-45-PB51EFG3-010	
4	IMP S LI ULV/SANW/2CM 32P IMP/ALC CAC 0040230 980229W 400 (TEXTURE) PRESET	6-87-PB50S-61D02	
4	IMP S LI ULV/SANW/2CM 32P 021A2/LG 0040230 980229W 400 (TEXTURE) PRESET	6-87-PB50S-62D02	
5	DUMMY 3000 NON PUSH TYPE PC+ABS (C7220P-700D)(CHANGED) W97020W	6-42-W9708-011	


A.Part Lists



Main Board A - 5


HDD

Figure A - 4
HDD



ITEM	PART	NAME	PART	NO	REMARK
1	SCREW	M3*3.0L KI NI ICT NY	6-35-B1130-3R5		
2	HDD BKT	7MM SECC T=0.5 N250LU	6-33-N250J-011		
3	SCREW	M2*4L KI NI ICT NY (DD=04.5,DT=0.8)	6-35-B1120-4RC		

LCD



ITEM	PART NAME	PART NO	REMARK
1	LCD PROTECT MYLAR BOPP N150ZU	6-40-N15Z8-010	
2	CCD LENS PMMA PB50EF	6-42-PB501-010	
3	FRONT COVER MODULE PB50EF	6-39-PB501-012	
4	LCD NIS6' FHD/VVA/NOT/NDN GT/EP BDE NES600M-N63 LED 24MM	6-50-L1B26-Z020	
4	LCD NIS6' FHD/VVA/NOT/NDN GT/EP INNOLUX NES600M-FAL QLED 32MM	6-50-LBB32-V020	
4	LCD NIS6' FHD/PS/M4/NDN GT/EP LG LP55WFC-SPIN QLED 32MM	6-50-LBB32-L013	
4	LCD NIS6' FHD/PS/M4/NDN GT/EP LG LP55WFC-SPR QLED 32MM	6-50-LBB26-L121	
4	LCD NIS6' FHD/PS/M4/NDN GT/EP LG LP55WFC-SPIN QLED 32MM	6-50-LBB32-G121	
4	LCD NIS6' FHD/PS/M4/NDN GT/EP LG LP55WFC-SPR QLED 32MM	6-50-LBB32-L016	
5	MYLAR(7*6*0.15MM, BLACK) FOR P640RF	6-40-00150-760	
6	TAPE MYLAR TRANSPARENT (20*10*0.05) P1801H	6-40-P1803-020	
7	LALATAPE FOR 026 PANEL (35*10*1.8T) PB50EF	6-47-PB501-030	FOR 6-50-L1B26-Z020 6-50-LBB32-L121
7-1	LALATAPE FOR 032 PANEL (35*10*1.2T) PB50EF	6-47-PB501-040	FOR 6-50-LBB32-V020 6-50-LBB32-L013
8	BACK COVER MODULE PB50EF	6-39-PB501-022	
8	BACK COVER MODULE PB51EF	6-39-PB511-021	
9	ANTENNA CLOUT 20MM PESX BLAN WET M2 P23 DR 2.4G/5G 30MM PB50EF	6-23-7PB50-010	
10	ANTENNA CLOUT 20MM PESX BLAN WET M2 P23 DR 2.4G/5G 30MM PB50EF	6-23-7PB50-020	
11	CCD CABLE L=500MM 30V 8PIN (H/L) PB50EF	6-43-PB50T-012	
12	SCREW M2.5*2.5L KI BK/Z ICT NY(Φ8,T=0.6)	6-35-B6125-2R5	OPTION
12	SCREW M2.5*4L (D=4.6,T=0.8) KI NI ICT NY	6-35-B1125-4RA	OPTION
13	HINGE L (SK7+SGCC) PB50EF	6-33-PB501-0L1	
14	HINGE R (SK7+SGCC) PB50EF	6-33-PB501-0R1	
15	PANEL SIDE MYLAR (240*3*0.25T) FOR INNOLUX	6-40-PB501-060	FOR 6-50-LBB32-V020
18	ACETATE CLOTH (5*8*0.2T) NB70TJ1	6-47-NB702-030	短期対策
20	BACK SPONGE DOWN 012T (104*10*1.2T) PB50EF	6-47-0019A-1AL	FOR 6-50-LBB32-V020 6-50-LBB32-L013
20-1	BACK SPONGE DOWN 018T (104*10*1.8T) PB50EF	6-47-0019A-1AK	FOR 6-50-L1B26-Z020 6-50-LBB26-L121

Figure A - 5
LCD

Appendix B: Schematic Diagrams

This appendix has circuit diagrams of the **PB50EF / PB51EF** notebook's PCB's. The following table indicates where to find the appropriate schematic diagram.

Diagram - Page	Diagram - Page	Diagram - Page	Diagram - Page
System Block Diagram - Page B - 2	Frame Buffer Partition D - Page B - 26	USB Redriver - Page B - 50	VCCGT, VCCSA - Page B - 74
Processor 1/6 - Page B - 3	GPU 4/6 - Page B - 27	ANX7440 - Page B - 51	NVVD 1 & 2 - Page B - 75
Processor 2/6 - Page B - 4	GPU 5/6 - Page B - 28	USB+DP Type-C - Page B - 52	NVVD 3 - Page B - 76
Processor 3/6 - Page B - 5	IFP I/O Interface - Page B - 29	TPM - Page B - 53	PEX_VDD - Page B - 77
Processor 4/6 - Page B - 6	GPU 6/6 - Page B - 30	LAN RTL8111H - Page B - 54	FBVDDQ - Page B - 78
Processor 5/6 - Page B - 7	GPU NVVD, FBVDDQ - Page B - 31	ALC1220 - Page B - 55	AC-In, Charger - Page B - 79
Processor 6/6 - Page B - 8	GPU GND - Page B - 32	EC ITE8587 - Page B - 56	LED Board - Page B - 80
DDR4 CHA SO-DIMM_0 - Page B - 9	GPU Decoupling - Page B - 33	Fan, TP, Smart AMP PWR - Page B - 57	Power Board - Page B - 81
DDR4 CHB SO-DIMM_0 - Page B - 10	GPU Decoupling 2 - Page B - 34	LED Keyboard Ctrl - Page B - 58	HDD Board - Page B - 82
Panel - Page B - 11	GPU Pwr Ctrl, Level Shift - Page B - 35	LID - Page B - 59	Audio Board, Fan - Page B - 83
HDMI - Page B - 12	PCH 1/9 - Page B - 36	TR-TBT - Page B - 60	Audio Board_USB - Page B - 84
Mini DP Port - Page B - 13	PCH 2/9 - Page B - 37	AR_TBT_SP PWR - Page B - 61	Audio Board_AMP, Jack - Page B - 85
PS8330B - Page B - 14	PCH 3/9 - Page B - 38	TPS65987 - Page B - 62	Per Keyboard - Page B - 86
PS8331 - Page B - 15	PCH 4/9 - Page B - 39	TBT/Type C - Page B - 63	RTS5250 - Page B - 87
GPU 1/6 - Page B - 16	PCH 5/9 - Page B - 40	Conn_to Extend Board - Page B - 64	AMP TPA2008D2 - Page B - 88
GPU 2/6 - Page B - 17	PCH 6/9 - Page B - 41	3.3VA, 3.3V, 3.3VS, 5VS - Page B - 65	Subwoofer - Page B - 89
Frame Buffer Partition A - Page B - 18	PCH 7/9 - Page B - 42	PWR_SW VCCST, STG, SFR_OC - Page B - 66	Smart AMP - Page B - 90
Frame Buffer Partition A - Page B - 19	PCH 8/9 - Page B - 43	PWR_SW 1V8_AON, RUN - Page B - 67	Smart AMP for Subwoofer - Page B - 91
Frame Buffer Partition B - Page B - 20	PCH 9/9 - Page B - 44	VDD3, VDD5 - Page B - 68	Speaker Con - Page B - 92
Frame Buffer Partition B - Page B - 21	HDD Port - Page B - 45	DDR 1.2V, 0.6VS, 2.5V - Page B - 69	
GPU 3/6 - Page B - 22	M.2 WLAN+BT - Page B - 46	1.8VA, 1.05VA - Page B - 70	
Frame Buffer Partition C - Page B - 23	M.2 PCIEX4 SATA - Page B - 47	VCCIO - Page B - 71	
Frame Buffer Partition C - Page B - 24	CCD, FP - Page B - 48	VCore, VCCGT, VCCSA - Page B - 72	
Frame Buffer Partition D - Page B - 25	USB - Page B - 49	VCore Output Stage - Page B - 73	

Table B - 1
**SCHEMATIC
DIAGRAMS**




Version Note

The schematic diagrams in this chapter are based upon version 6-7P-PB5E7-001. If your mainboard (or other boards) are a later version, please check with the Service Center for updated diagrams (if required).

Schematic Diagrams


System Block Diagram

Sheet 1 of 91
System Block
Diagram




Processor 2/6

Sheet 3 of 91
Processor 2/6



Processor 3/6


Sheet 4 of 91
Processor 3/6

Processor 4/6

B.Schematic Diagrams




Processor 5/6

Sheet 6 of 91
Processor 5/6

Processor 6/6

Sheet 7 of 91
Processor 6/6




Sheet 8 of 91
DDR4 CHA SO-
DIMM_0




DDR4 CHB SO-DIMM_0

Channel B SO-DIMM 0




Panel B - 11




Schematic Diagrams

HDMI

Sheet 11 of 91
HDMI




PS8330B



Sheet 13 of 91
PS8330B

B.Schematic Diagrams


PS8331




GPU 1/6

B.Schematic Diagrams

Sheet 15 of 91
GPU 1/6




GPU 2/6


Sheet 16 of 91
GPU 2/6

B.Schematic Diagrams

Sheet 17 of 91
Frame Buffer
Partition A



Frame Buffer Partition A




Sheet 20 of 91
Frame Buffer
Partition B



GPU 3/6

Sheet 21 of 91
GPU 3/6




Sheet 22 of 91
Frame Buffer
Partition C




B.Schematic Diagrams

Sheet 23 of 91
Frame Buffer
Partition C




Frame Buffer Partition D




Sheet 24 of 91
 Frame Buffer
 Partition D

Sheet 25 of 91
Frame Buffer
Partition D




GPU 4/6

Sheet 26 of 91
GPU 4/6

GPU 5/6

Sheet 27 of 91
GPU 5/6




The schematic diagram illustrates the internal connections and components of the MDP (Media and Display Processor) and IFPE (Image Processing and Feature Extraction) blocks. Key components and connections include:

- GPUs:** Two GPUs are shown, labeled "Near the GPU" and "Under the GPU". They are connected to various pins and components, including capacitors (C701, C702, C703, C704, C705, C706, C707, C708, C709, C710, C711, C712, C713, C714, C715, C716, C717, C718, C719, C720, C721, C722, C723, C724, C725, C726, C727, C728, C729, C730, C731, C732, C733, C734, C735, C736, C737, C738, C739, C740, C741, C742, C743, C744, C745, C746, C747, C748, C749, C750, C751, C752, C753, C754, C755, C756, C757, C758, C759, C760, C761, C762, C763, C764, C765, C766, C767, C768, C769, C770, C771, C772, C773, C774, C775, C776, C777, C778, C779, C780, C781, C782, C783, C784, C785, C786, C787, C788, C789, C790, C791, C792, C793, C794, C795, C796, C797, C798, C799, C800, C801, C802, C803, C804, C805, C806, C807, C808, C809, C810, C811, C812, C813, C814, C815, C816, C817, C818, C819, C820, C821, C822, C823, C824, C825, C826, C827, C828, C829, C830, C831, C832, C833, C834, C835, C836, C837, C838, C839, C840, C841, C842, C843, C844, C845, C846, C847, C848, C849, C850, C851, C852, C853, C854, C855, C856, C857, C858, C859, C860, C861, C862, C863, C864, C865, C866, C867, C868, C869, C870, C871, C872, C873, C874, C875, C876, C877, C878, C879, C880, C881, C882, C883, C884, C885, C886, C887, C888, C889, C890, C891, C892, C893, C894, C895, C896, C897, C898, C899, C900, C901, C902, C903, C904, C905, C906, C907, C908, C909, C910, C911, C912, C913, C914, C915, C916, C917, C918, C919, C920, C921, C922, C923, C924, C925, C926, C927, C928, C929, C930, C931, C932, C933, C934, C935, C936, C937, C938, C939, C940, C941, C942, C943, C944, C945, C946, C947, C948, C949, C950, C951, C952, C953, C954, C955, C956, C957, C958, C959, C960, C961, C962, C963, C964, C965, C966, C967, C968, C969, C970, C971, C972, C973, C974, C975, C976, C977, C978, C979, C980, C981, C982, C983, C984, C985, C986, C987, C988, C989, C990, C991, C992, C993, C994, C995, C996, C997, C998, C999, C1000, C1001, C1002, C1003, C1004, C1005, C1006, C1007, C1008, C1009, C1010, C1011, C1012, C1013, C1014, C1015, C1016, C1017, C1018, C1019, C1020, C1021, C1022, C1023, C1024, C1025, C1026, C1027, C1028, C1029, C1030, C1031, C1032, C1033, C1034, C1035, C1036, C1037, C1038, C1039, C1040, C1041, C1042, C1043, C1044, C1045, C1046, C1047, C1048, C1049, C1050, C1051, C1052, C1053, C1054, C1055, C1056, C1057, C1058, C1059, C1060, C1061, C1062, C1063, C1064, C1065, C1066, C1067, C1068, C1069, C1070, C1071, C1072, C1073, C1074, C1075, C1076, C1077, C1078, C1079, C1080, C1081, C1082, C1083, C1084, C1085, C1086, C1087, C1088, C1089, C1090, C1091, C1092, C1093, C1094, C1095, C1096, C1097, C1098, C1099, C1100, C1101, C1102, C1103, C1104, C1105, C1106, C1107, C1108, C1109, C1110, C1111, C1112, C1113, C1114, C1115, C1116, C1117, C1118, C1119, C1120, C1121, C1122, C1123, C1124, C1125, C1126, C1127, C1128, C1129, C1130, C1131, C1132, C1133, C1134, C1135, C1136, C1137, C1138, C1139, C1140, C1141, C1142, C1143, C1144, C1145, C1146, C1147, C1148, C1149, C1150, C1151, C1152, C1153, C1154, C1155, C1156, C1157, C1158, C1159, C1160, C1161, C1162, C1163, C1164, C1165, C1166, C1167, C1168, C1169, C1170, C1171, C1172, C1173, C1174, C1175, C1176, C1177, C1178, C1179, C1180, C1181, C1182, C1183, C1184, C1185, C1186, C1187, C1188, C1189, C1190, C1191, C1192, C1193, C1194, C1195, C1196, C1197, C1198, C1199, C1200, C1201, C1202, C1203, C1204, C1205, C1206, C1207, C1208, C1209, C1210, C1211, C1212, C1213, C1214, C1215, C1216, C1217, C1218, C1219, C1220, C1221, C1222, C1223, C1224, C1225, C1226, C1227, C1228, C1229, C1230, C1231, C1232, C1233, C1234, C1235, C1236, C1237, C1238, C1239, C1240, C1241, C1242, C1243, C1244, C1245, C1246, C1247, C1248, C1249, C1250, C1251, C1252, C1253, C1254, C1255, C1256, C1257, C1258, C1259, C1260, C1261, C1262, C1263, C1264, C1265, C1266, C1267, C1268, C1269, C1270, C1271, C1272, C1273, C1274, C1275, C1276, C1277, C1278, C1279, C1280, C1281, C1282, C1283, C1284, C1285, C1286, C1287, C1288, C1289, C1290, C1291, C1292, C1293, C1294, C1295, C1296, C1297, C1298, C1299, C1300, C1301, C1302, C1303, C1304, C1305, C1306, C1307, C1308, C1309, C1310, C1311, C1312, C1313, C1314, C1315, C1316, C1317, C1318, C1319, C1320, C1321, C1322, C1323, C1324, C1325, C1326, C1327, C1328, C1329, C1330, C1331, C1332, C1333, C1334, C1335, C1336, C1337, C1338, C1339, C1340, C1341, C1342, C1343, C1344, C1345, C1346, C1347, C1348, C1349, C1350, C1351, C1352, C1353, C1354, C1355, C1356, C1357, C1358, C1359, C1360, C1361, C1362, C1363, C1364, C1365, C1366, C1367, C1368, C1369, C1370, C1371, C1372, C1373, C1374, C1375, C1376, C1377, C1378, C1379, C1380, C1381, C1382, C1383, C1384, C1385, C1386, C1387, C1388, C1389, C1390, C1391, C1392, C1393, C1394, C1395, C1396, C1397, C1398, C1399, C1400, C1401, C1402, C1403, C1404, C1405, C1406, C1407, C1408, C


Schematic Diagrams

GPU 6/6

Sheet 29 of 91
GPU 6/6




GPU NVVDD, FBVDDQ




Sheet 30 of 91
GPU NVVDD,
FBVDDQ

GPU GND

Sheet 31 of 91
GPU GND



GPU Decoupling B - 33



Schematic Diagrams




Schematic Diagrams

Schematic Diagrams

PCH 1/9

Sheet 35 of 91
PCH 1/9



[illegible]

Pin Straps (1)


RESERVED
External pull-up is required. Recommend
100K if pulled up to 3.3V or 75K if
pulled up to 1.8V.
This strap should sample HIGH. There
should NOT be any on-board device
driving it to opposite direction during
strap sampling.

DESIGN NOTE:
USB2 COMP RES:
PLACE WITHIN 1 INCH

To J SSD2

Schematic Diagrams


PCH 4/9



Sheet 38 of 91
PCH 4/9

B.Schematic Diagrams

PCH 6/9

Sheet 40 of 91
PCH 6/9


PCH 8/9

Sheet 42 of 91
PCH 8/9


B.Schematic Diagrams

PCH 9/9

Sheet 43 of 91
PCH 9/9



HDD Port


Sheet 44 of 91
HDD Port

© 2006 The Authors
Journal compilation © 2006 Blackwell Publishing Ltd

M.2 WLAN+BT

B.Schematic Diagrams


Sheet 45 of 91
M.2 WLAN+BT




Schematic Diagrams

CCD, FP

Sheet 47 of 91
CCD, FP




USB

Sheet 48 of 91
USB

Schematic Diagrams

USB Redriver

Sheet 49 of 91
USB Redriver



Layout Rules:

1. Place ANX7440/30/90/96 and USB Type-C/Type-A connector in an open area for easier routing.
2. High-speed trace should be routed with high-priority.
3. If using internal DC/DC, create a dedicated DC/DC VDDND.
4. High-speed trace must keep distance from DC/DC and other noise source. RX to TX spacing should be >20mils.
5. High-speed trace must be continuous and without stub, especially to RX traces.
6. Ground void should be applied to wide pad along the high-speed traces.
7. RSD ground should be wide.
8. Every AVDD05 pin must have a 0.01uF decoupling capacitor that is very close.
9. AVDD09 power delivery must be wide and away from noisy signal.

Table 5-3 DC Address Selection for Top Register

ADR_SEL0	ADR_SEL1	DC Address (P-BH)	DC Address (B-BH)
0	0	0000_000	0x0
0	1	0000_010	0x1
1	0	0000_100	0x2
1	1	0000_110	0x3

Signal GND and GND_DCDC must be separated. They are connected at a single point.

PCB Footprint: qfn60-7x7mm-1

ANX7440_FLP

ANX7440_SDA

ANX7440_SCL

ANX7440_VDD

ANX7440_GND

ANX7440_TXP

ANX7440_RXP

ANX7440_TXN

ANX7440_RXN

ANX7440_TXP0

ANX7440_RXP0

ANX7440_TXN0

ANX7440_RXN0

ANX7440_TXP1

ANX7440_RXP1

ANX7440_TXN1

ANX7440_RXN1

ANX7440_TXP2

ANX7440_RXP2

ANX7440_TXN2

ANX7440_RXN2

ANX7440_TXP3

ANX7440_RXP3

ANX7440_TXN3

ANX7440_RXN3

ANX7440_TXP4

ANX7440_RXP4

ANX7440_TXN4

ANX7440_RXN4

ANX7440_TXP5

ANX7440_RXP5

ANX7440_TXN5

ANX7440_RXN5

ANX7440_TXP6

ANX7440_RXP6

ANX7440_TXN6

ANX7440_RXN6

ANX7440_TXP7

ANX7440_RXP7

ANX7440_TXN7

ANX7440_RXN7

ANX7440_TXP8

ANX7440_RXP8

ANX7440_TXN8

ANX7440_RXN8

ANX7440_TXP9

ANX7440_RXP9

ANX7440_TXN9

ANX7440_RXN9

ANX7440_TXP10

ANX7440_RXP10

ANX7440_TXN10

ANX7440_RXN10

ANX7440_TXP11

ANX7440_RXP11

ANX7440_TXN11

ANX7440_RXN11

ANX7440_TXP12

ANX7440_RXP12

ANX7440_TXN12

ANX7440_RXN12

ANX7440_TXP13

ANX7440_RXP13

ANX7440_TXN13

ANX7440_RXN13

ANX7440_TXP14

ANX7440_RXP14

ANX7440_TXN14

ANX7440_RXN14

ANX7440_TXP15

ANX7440_RXP15

ANX7440_TXN15

ANX7440_RXN15

ANX7440_TXP16

ANX7440_RXP16

ANX7440_TXN16

ANX7440_RXN16

ANX7440_TXP17

ANX7440_RXP17

ANX7440_TXN17

ANX7440_RXN17

ANX7440_TXP18

ANX7440_RXP18

ANX7440_TXN18

ANX7440_RXN18

ANX7440_TXP19

ANX7440_RXP19

ANX7440_TXN19

ANX7440_RXN19

ANX7440_TXP20

ANX7440_RXP20

ANX7440_TXN20

ANX7440_RXN20

ANX7440_TXP21

ANX7440_RXP21

ANX7440_TXN21

ANX7440_RXN21

ANX7440_TXP22

ANX7440_RXP22

ANX7440_TXN22

ANX7440_RXN22

ANX7440_TXP23

ANX7440_RXP23

ANX7440_TXN23

ANX7440_RXN23

ANX7440_TXP24

ANX7440_RXP24

ANX7440_TXN24

ANX7440_RXN24

ANX7440_TXP25

ANX7440_RXP25

ANX7440_TXN25

ANX7440_RXN25

ANX7440_TXP26

ANX7440_RXP26

ANX7440_TXN26

ANX7440_RXN26

ANX7440_TXP27

ANX7440_RXP27

ANX7440_TXN27

ANX7440_RXN27

ANX7440_TXP28

ANX7440_RXP28

ANX7440_TXN28

ANX7440_RXN28

ANX7440_TXP29

ANX7440_RXP29

ANX7440_TXN29

ANX7440_RXN29

ANX7440_TXP30

ANX7440_RXP30

ANX7440_TXN30

ANX7440_RXN30

ANX7440_TXP31

ANX7440_RXP31

ANX7440_TXN31

ANX7440_RXN31

ANX7440_TXP32

ANX7440_RXP32

ANX7440_TXN32

ANX7440_RXN32

ANX7440_TXP33

ANX7440_RXP33

ANX7440_TXN33

ANX7440_RXN33

ANX7440_TXP34

ANX7440_RXP34

ANX7440_TXN34

ANX7440_RXN34

ANX7440_TXP35

ANX7440_RXP35

ANX7440_TXN35

ANX7440_RXN35

ANX7440_TXP36

ANX7440_RXP36

ANX7440_TXN36

ANX7440_RXN36

ANX7440_TXP37

ANX7440_RXP37

ANX7440_TXN37

ANX7440_RXN37

ANX7440_TXP38

ANX7440_RXP38

ANX7440_TXN38

ANX7440_RXN38

ANX7440_TXP39

ANX7440_RXP39

ANX7440_TXN39

ANX7440_RXN39

ANX7440_TXP40

ANX7440_RXP40


ANX7440_TXN40

ANX7440_RXN40

ANX7440_TXP

USB+DP Type-C


Sheet 51 of 91
USB+DP Type-C



LAN RTL8111H

B.Schematic Diagrams

Sheet 53 of 91
LAN RTL8111H




B.Schematic Diagrams

The image shows a complex PCB layout for a digital audio player. The layout is divided into several functional sections:


- For 3.3V HDA Link:** This section at the top left includes components for the HDA link, such as resistors R219, R220, R221, R222, R223, R224, R225, R226, R227, R228, R229, R230, R231, R232, R233, R234, R235, R236, R237, R238, R239, R240, R241, R242, R243, R244, R245, R246, R247, R248, R249, R250, R251, R252, R253, R254, R255, R256, R257, R258, R259, R260, R261, R262, R263, R264, R265, R266, R267, R268, R269, R270, R271, R272, R273, R274, R275, R276, R277, R278, R279, R280, R281, R282, R283, R284, R285, R286, R287, R288, R289, R290, R291, R292, R293, R294, R295, R296, R297, R298, R299, R300, R301, R302, R303, R304, R305, R306, R307, R308, R309, R310, R311, R312, R313, R314, R315, R316, R317, R318, R319, R320, R321, R322, R323, R324, R325, R326, R327, R328, R329, R330, R331, R332, R333, R334, R335, R336, R337, R338, R339, R340, R341, R342, R343, R344, R345, R346, R347, R348, R349, R350, R351, R352, R353, R354, R355, R356, R357, R358, R359, R360, R361, R362, R363, R364, R365, R366, R367, R368, R369, R370, R371, R372, R373, R374, R375, R376, R377, R378, R379, R380, R381, R382, R383, R384, R385, R386, R387, R388, R389, R390, R391, R392, R393, R394, R395, R396, R397, R398, R399, R400, R401, R402, R403, R404, R405, R406, R407, R408, R409, R410, R411, R412, R413, R414, R415, R416, R417, R418, R419, R420, R421, R422, R423, R424, R425, R426, R427, R428, R429, R430, R431, R432, R433, R434, R435, R436, R437, R438, R439, R440, R441, R442, R443, R444, R445, R446, R447, R448, R449, R450, R451, R452, R453, R454, R455, R456, R457, R458, R459, R460, R461, R462, R463, R464, R465, R466, R467, R468, R469, R470, R471, R472, R473, R474, R475, R476, R477, R478, R479, R480, R481, R482, R483, R484, R485, R486, R487, R488, R489, R490, R491, R492, R493, R494, R495, R496, R497, R498, R499, R500, R501, R502, R503, R504, R505, R506, R507, R508, R509, R510, R511, R512, R513, R514, R515, R516, R517, R518, R519, R520, R521, R522, R523, R524, R525, R526, R527, R528, R529, R530, R531, R532, R533, R534, R535, R536, R537, R538, R539, R540, R541, R542, R543, R544, R545, R546, R547, R548, R549, R550, R551, R552, R553, R554, R555, R556, R557, R558, R559, R560, R561, R562, R563, R564, R565, R566, R567, R568, R569, R570, R571, R572, R573, R574, R575, R576, R577, R578, R579, R580, R581, R582, R583, R584, R585, R586, R587, R588, R589, R590, R591, R592, R593, R594, R595, R596, R597, R598, R599, R600, R601, R602, R603, R604, R605, R606, R607, R608, R609, R610, R611, R612, R613, R614, R615, R616, R617, R618, R619, R620, R621, R622, R623, R624, R625, R626, R627, R628, R629, R630, R631, R632, R633, R634, R635, R636, R637, R638, R639, R640, R641, R642, R643, R644, R645, R646, R647, R648, R649, R650, R651, R652, R653, R654, R655, R656, R657, R658, R659, R660, R661, R662, R663, R664, R665, R666, R667, R668, R669, R670, R671, R672, R673, R674, R675, R676, R677, R678, R679, R680, R681, R682, R683, R684, R685, R686, R687, R688, R689, R690, R691, R692, R693, R694, R695, R696, R697, R698, R699, R700, R701, R702, R703, R704, R705, R706, R707, R708, R709, R710, R711, R712, R713, R714, R715, R716, R717, R718, R719, R720, R721, R722, R723, R724, R725, R726, R727, R728, R729, R730, R731, R732, R733, R734, R735, R736, R737, R738, R739, R740, R741, R742, R743, R744, R745, R746, R747, R748, R749, R750, R751, R752, R753, R754, R755, R756, R757, R758, R759, R760, R761, R762, R763, R764, R765, R766, R767, R768, R769, R770, R771, R772, R773, R774, R775, R776, R777, R778, R779, R780, R781, R782, R783, R784, R785, R786, R787, R788, R789, R790, R791, R792, R793, R794, R795, R796, R797, R798, R799, R800, R801, R802, R803, R804, R805, R806, R807, R808, R809, R810, R811, R812, R813, R814, R815, R816, R817, R818, R819, R820, R821, R822, R823, R824, R825, R826, R827, R828, R829, R830, R831, R832, R833, R834, R835, R836, R837, R838, R839, R840, R841, R842, R843, R844, R845, R846, R847, R848, R849, R850, R851, R852, R853, R854, R855, R856, R857, R858, R859, R860, R861, R862, R863, R864, R865, R866, R867, R868, R869, R870, R871, R872, R873, R874, R875, R876, R877, R878, R879, R880, R881, R882, R883, R884, R885, R886, R887, R888, R889, R890, R891, R892, R893, R894, R895, R896, R897, R898, R899, R900, R901, R902, R903, R904, R905, R906, R907, R908, R909, R910, R911, R912, R913, R914, R915, R916, R917, R918, R919, R920, R921, R922, R923, R924, R925, R926, R927, R928, R929, R930, R931, R932, R933, R934, R935, R936, R937, R938, R939, R940, R941, R942, R943, R944, R945, R946, R947, R948, R949, R950, R951, R952, R953, R954, R955, R956, R957, R958, R959, R960, R961, R962, R963, R964, R965, R966, R967, R968, R969, R970, R971, R972, R973, R974, R975, R976, R977, R978, R979, R980, R981, R982, R983, R984, R985, R986, R987, R988, R989, R990, R991, R992, R993, R994, R995, R996, R997, R998, R999, R1000, R1001, R1002, R1003, R1004

EC ITE8587

B.Schematic Diagrams




Schematic Diagrams




Schematic Diagrams

LED Keyboard Ctrl

Sheet 57 of 91
LED Keyboard Ctrl




LID



Sheet 58 of 91
LID


TR-TBT

B. Schematic Diagrams



Schematic Diagrams


AR_TBT_SP PWR



Sheet 60 of 91
AR_TBT_SP PWR


B.Schematic Diagrams

Sheet 63 of 91
Conn_to Extend
Board



PWR_SW VCCST, STG, SFR_OC


Sheet 65 of 91
PWR_SW VCCST,
STG, SFR_OC



[illegible]

PWR_SW 1V8_AON, RUN B - 67

DDR 1.2V, 0.6VS, 2.5V




Sheet 68 of 91
DDR 1.2V, 0.6VS,
2.5V


Schematic Diagrams

1.8VA, 1.05VA


Sheet 69 of 91
1.8VA, 1.05VA



VCCIO



VCore, VCCGT, VCCSA



Sheet 71 of 91
VCore


B.Schematic Diagrams




Schematic Diagrams

VCCGT, VCCSA

Sheet 73 of 91
VCCGT, VCCSA




NVVDD 1 & 2




NVVDD 3

Sheet 75 of 91
NVVDD 3




PEX_VDD


Sheet 76 of 91
PEX_VDD

FBVDDQ

Sheet 77 of 91
FBVDDQ



AC-In, Charger




Sheet 78 of 91
AC-In, Charger


Schematic Diagrams

LED Board

Sheet 79 of 91
LED Board



Power Board


Sheet 80 of 91
Power Board

B.Schematic Diagrams

Schematic Diagrams

HDD Board

Sheet 81 of 91
HDD Board



20180723 Swap pin1,40

AJ AUDIO1

Footprint=FP201-040X1-0M pin1 fix

40 AVDD5

39

38

37

36

35 A5VS

34

33 A3.3V

32

31 A3.3VS

30

29

28

27 AUSB3_TXN5 83

26 AUSB3_TXP5 83

25

24 AUSB3_RXN5 83

23 AUSB3_RXP5 83

22

21 AUSB_PN5 83

20 AUSB_PP5 83

19

18 D02 1018 HP has fan noise

17 ACPU_FAN_GND

16 ACPU_FAN ADD_ON 83

15 ACPU_FANSSEN

14 AAAMP_EN ASPDIFO 84

13 AAAMP_EN 84

12 AHP_SENSE 84

11 AMIC_SENSE 84

10

9 AMIC1_R 84

8 AMIC1_L 84

7

6 AMIC2_RL 84

5

4 AHEADPHONE-R

3 AHEADPHONE-L

2

1 AGND

FP201H-040S10M
P/N = 6-20-94K20-140 AGND_A_AUDG
PCB Footprint = FP201-040X1-0M
AUD BD

20180719 CPU FAN

CPU FAN

A5VS

AC20 10µ 6.3V_XSR_06 AUD BD

AC19 10µ 6.3V_XSR_06 AUD BD

>40mll

AGND

AGND

AC36 100p 25V_NPO_02 AUD BD1

D01A 0822 Change footprint

ACPUS FANSEN

AJ_CFN1

1

2

3

4

50273-0040N-001
P/N = 6-20-44100-004
PCB Footprint = 85205-04L
AUD BD

20180418 update footprint

AR40 4.7K_04 AUD BD

A3.3VS

AC34 100p 25V_NPO_02 AUD BD1

D01A 0822 Change footprint

ACPUS FAN_GND

D02 1017 HP has fan noise

83 AVDD5

84 A5VS

83,84 A3.3V

AH4 *H6_5B7_OD2_8 H6_5B7_OD2_8

AUD BD

AGND

20180730 Modify footprint

AH5 *H7_OD2_8 H7_OD2_8

AUD BD

AGND

D02 1018 footprint

AH1 *H7_0B10_OD2_8 H7_0B10_OD2_8

AUD BD

AGND

AH6 *H4_5D2_3 H4_5D2_3

AUD BD

AGND

AH2 *H4_5D2_3 H4_5D2_3

AUD BD

AGND

20180730 Modify footprint

AH3 6-34-P750S-010 20180601 81212

H7_OD3_7

AUD BD

AGND

1AR1 *0_04

2AR1 *0_04

3AR1 *0_04

4AR1 *0_04 AUD BD W/O REDRIVER


5AR1 *0_04

6AR1 *0_04

Schematic Diagrams

Audio Board_USB

Sheet 83 of 91
Audio Board_USB




Audio Board_AMP, Jack B - 85


Schematic Diagrams

Per Keyboard

Sheet 85 of 91
Per Keyboard




RTS5250 B - 87





AMP TPA2008D2

Sheet 87 of 91
AMP TPA2008D2




Subwoofer

Sheet 88 of 91
Subwoofer



Smart AMP for Subwoofer



Sheet 90 of 91
 Samrt AMP for
 Subwoofer

Schematic Diagrams

Speaker Con

Sheet 91 of 91
Speaker Con

