

SERVICE MANUAL

N240JU / N241JU

notebook



Notebook Computer

N240JU / N241JU

Service Manual

Notice

The company reserves the right to revise this publication or to change its contents without notice. Information contained herein is for reference only and does not constitute a commitment on the part of the manufacturer or any subsequent vendor. They assume no responsibility or liability for any errors or inaccuracies that may appear in this publication nor are they in anyway responsible for any loss or damage resulting from the use (or misuse) of this publication.

This publication and any accompanying software may not, in whole or in part, be reproduced, translated, transmitted or reduced to any machine readable form without prior consent from the vendor, manufacturer or creators of this publication, except for copies kept by the user for backup purposes.

Brand and product names mentioned in this publication may or may not be copyrights and/or registered trademarks of their respective companies. They are mentioned for identification purposes only and are not intended as an endorsement of that product or its manufacturer.

Version 1.0
September 2015

Trademarks

Pentium and Celeron are trademarks of Intel Corporation.

Windows[®] is a registered trademark of Microsoft Corporation.

Other brand and product names are trademarks and /or registered trademarks of their respective companies.

About this Manual

This manual is intended for service personnel who have completed sufficient training to undertake the maintenance and inspection of personal computers.

It is organized to allow you to look up basic information for servicing and/or upgrading components of the *N240JU* / *N241JU* series notebook PC.

The following information is included:

Chapter 1, Introduction, provides general information about the location of system elements and their specifications.
Chapter 2, Disassembly, provides step-by-step instructions for disassembling parts and subsystems and how to upgrade elements of the system.

Appendix A, Part Lists

Appendix B, Schematic Diagrams

Appendix C, Updating the FLASH ROM BIOS

Preface

IMPORTANT SAFETY INSTRUCTIONS

Follow basic safety precautions, including those listed below, to reduce the risk of fire, electric shock and injury to persons when using any electrical equipment:

1. Do not use this product near water, for example near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electrical shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
5. This product is intended to be supplied by a Listed Power Unit with an AC Input of 100 - 240V, 50 - 60Hz, DC Output of 19V, 2.1A (**40 Watts**) minimum AC/DC Adapter.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.


Instructions for Care and Operation

The notebook computer is quite rugged, but it can be damaged. To prevent this, follow these suggestions:


1. **Don't drop it, or expose it to shock.** If the computer falls, the case and the components could be damaged.



2. **Keep it dry, and don't overheat it.** Keep the computer and power supply away from any kind of heating element. This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.




3. **Follow the proper working procedures for the computer.** Shut the computer down properly and don't forget to save your work. Remember to periodically save your data as data may be lost if the battery is depleted.



Preface


4. **Avoid interference.** Keep the computer away from high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage your data.
5. **Take care when using peripheral devices.**



Power Safety

The computer has specific power requirements:

- Only use a power adapter approved for use with this computer.
- Your AC adapter may be designed for international travel but it still requires a steady, uninterrupted power supply. If you are unsure of your local power specifications, consult your service representative or local power company.
- The power adapter may have either a 2-prong or a 3-prong grounded plug. The third prong is an important safety feature; do not defeat its purpose. If you do not have access to a compatible outlet, have a qualified electrician install one.
- When you want to unplug the power cord, be sure to disconnect it by the plug head, not by its wire.
- Make sure the socket and any extension cord(s) you use can support the total current load of all the connected devices.
- Before cleaning the computer, make sure it is disconnected from any external power supplies.



Power Safety Warning

Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines and power cord). It is advisable to also remove your battery in order to prevent accidentally turning the machine on.

Battery Precautions

- Only use batteries designed for this computer. The wrong battery type may explode, leak or damage the computer.
- Do not continue to use a battery that has been dropped, or that appears damaged (e.g. bent or twisted) in any way. Even if the computer continues to work with a damaged battery in place, it may cause circuit damage, which may possibly result in fire.
- Recharge the batteries using the notebook's system. Incorrect recharging may make the battery explode.
- Do not try to repair a battery pack. Refer any battery pack repair or replacement to your service representative or qualified service personnel.
- Keep children away from, and promptly dispose of a damaged battery. Always dispose of batteries carefully. Batteries may explode or leak if exposed to fire, or improperly handled or discarded.
- Keep the battery away from metal appliances.
- Affix tape to the battery contacts before disposing of the battery.
- Do not touch the battery contacts with your hands or metal objects.

Battery Guidelines

The following can also apply to any backup batteries you may have.

- If you do not use the battery for an extended period, then remove the battery from the computer for storage.
- Before removing the battery for storage charge it to 60% - 70%.
- Check stored batteries at least every 3 months and charge them to 60% - 70%.



Battery Disposal

The product that you have purchased contains a rechargeable battery. The battery is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal.

Caution

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used battery according to the manufacturer's instructions.

Battery Level

Click the battery icon  in the taskbar to see the current battery level and charge status. A battery that drops below a level of 10% will not allow the computer to boot up. Make sure that any battery that drops below 10% is recharged within one week.

Preface

Related Documents

You may also need to consult the following manual for additional information:

User's Manual on CD/DVD

This describes the notebook PC's features and the procedures for operating the computer and its ROM-based setup program. It also describes the installation and operation of the utility programs provided with the notebook PC.

System Startup

1. Remove all packing materials.
2. Place the computer on a stable surface.
3. Insert the battery and make sure it is locked in position.
4. Securely attach any peripherals you want to use with the computer (e.g. keyboard and mouse) to their ports.
5. Attach the AC/DC adapter to the DC-In jack at the rear of the computer, then plug the AC power cord into an outlet, and connect the AC power cord to the AC/DC adapter.
6. Use one hand to raise the lid/LCD to a comfortable viewing angle (do not exceed 127 degrees); use the other hand (as illustrated in Figure 1) to support the base of the computer (**Note: Never** lift the computer by the lid/LCD).
7. Press the power button to turn the computer "on".




Figure 1
**Opening the Lid/LCD/
Computer with AC/DC
Adapter Plugged-In**



Shut Down

Note that you should always shut your computer down by choosing the **Shut down** command in **Windows** (see below). This will help prevent hard disk or system problems.

Click **Settings** in the **Charms Bar** (use the **Windows Logo Key**  + **C** key combination to access the Charms Bar) and choose **Shut down** from the **Power** menu.

Or

Choose **Shut down or sign out > Shut down** from the context menu (use the **Windows Logo Key**  + **X** key combination to access the context menu).

Contents

Introduction1-1

Overview	1-1
Specifications	1-2
External Locator - Top View with LCD Panel Open	1-4
External Locator - Front & Right Side Views	1-5
External Locator - Left Side & Rear View	1-6
External Locator - Bottom View	1-7
Mainboard Overview - Top (Key Parts)	1-8
Mainboard Overview - Bottom (Key Parts)	1-9
Mainboard Overview - Top (Connectors)	1-10
Mainboard Overview - Bottom (Connectors)	1-11

Disassembly2-1

Overview	2-1
Maintenance Tools	2-2
Connections	2-2
Maintenance Precautions	2-3
Disassembly Steps	2-4
Removing the Battery	2-5
Removing the Hard Disk Drive	2-6
Removing the System Memory (RAM)	2-8
Removing the Keyboard	2-10
Removing the Wireless LAN Module	2-11
Wireless LAN, and Combo Module Cables	2-12
Removing the 3G Module	2-13
Removing and Installing the M.2 SSD Module	2-14
Removing the CCD	2-16

Part ListsA-1

Part List Illustration Location	A-2
Top	A-3

Top (TV Tuner)	A-4
Bottom	A-5
LCD	A-6
HDD	A-7

Schematic Diagrams.....B-1

System Block Diagram	B-2
Processor 1/11	B-3
Processor 2/11	B-4
Processor 3/11	B-5
Processor 4/11	B-6
Processor 5/11	B-7
Processor 6/11	B-8
Processor 7/11	B-9
Processor 8/11	B-10
Processor 9/11	B-11
Processor 10/11	B-12
Processor 11/11	B-13
DDR3 SO-DIMM_0	B-14
DDR3 SO-DIMM_1	B-15
HDMI	B-16
Panel	B-17
Conn, CCD, Fan, T/P, TV	B-18
PS8625	B-19
SATA, LED, KB, G-Sensor	B-20
USB, TPM	B-21
WLAN/BT, 3G/mSATA	B-22
NGFF_M SSD	B-23
Audio Codec	B-24
KBC ITE IT8587	B-25
3V, 5V, 3VS, 5VS, CTL Signal	B-26

Preface

VDD3, VDD5	B-27
VDDQ_VTT, 1.5VS, 1.8VS	B-28
1.0V Series	B-29
VCore, VCCGT, VCCSA, VCCIO	B-30
NCP81206 Regulator	B-31
Charger, DC-In	B-32
USB Board	B-33
CRT	B-34
RTL8411B	B-35
Power SW Board	B-36
Click Board	B-37
LED Board	B-38
HDD Board	B-39

Updating the FLASH ROM BIOS..... C-1

Download the BIOS	C-1
Unzip the downloaded files to a bootable CD/DVD/ or	
USB Flash drive	C-1
Set the computer to boot from the external drive	C-1
Use the flash tools to update the BIOS	C-2
Restart the computer (booting from the HDD)	C-2

Chapter 1: Introduction

Overview

This manual covers the information you need to service or upgrade the **N240JU / N241JU** series notebook computer. Information about operating the computer (e.g. getting started, and the *Setup* utility) is in the *User's Manual*. Information about drivers (e.g. VGA & audio) is also found in the *User's Manual*. The manual is shipped with the computer.

Operating systems (e.g. *Window 8.1*, etc.) have their own manuals as do application softwares (e.g. word processing and database programs). If you have questions about those programs, you should consult those manuals.

The **N240JU / N241JU** series notebook is designed to be upgradeable. See [Disassembly on page 2 - 1](#) for a detailed description of the upgrade procedures for each specific component. Please take note of the warning and safety information indicated by the “” symbol.

The balance of this chapter reviews the computer's technical specifications and features.

Introduction

Specifications



Latest Specification Information

The specifications listed here are correct at the time of sending them to the press. Certain items (particularly processor types/speeds) may be changed, delayed or updated due to the manufacturer's release schedule. Check with your service center for more details.



CPU

The CPU is not a user serviceable part. Accessing the CPU in any way may violate your warranty.

Processor Options

Intel® Core™ i7 Processor

i7-6500U (2.50GHz)

4MB Smart Cache, **14nm**, DDR3L-1600MHz, TDP 15W

Intel® Core™ i5 Processor

i5-6200U (2.30GHz)

3MB Smart Cache, **14nm**, DDR3L-1600MHz, TDP 15W

Intel® Core™ i3 Processor

i3-6100U (2.30GHz)

3MB Smart Cache, **14nm**, DDR3L-1600MHz, TDP 15W

Intel® Pentium® Processor

4405U (2.10GHz)

2MB Smart Cache, **14nm**, DDR3L-1600MHz, TDP 15W

Intel® Celeron® Processor

3955U (2.00GHz), 3855U (1.60GHz)

2MB Smart Cache, **14nm**, DDR3L-1600MHz, TDP 15W

BIOS

64Mb SPI Flash ROM

AMI BIOS

Memory

Two 204 Pin SO-DIMM Sockets Supporting **DDR3L**

1600MHz Memory

Memory Expandable up to 16GB

(The real memory operating frequency depends on the FSB of the processor.)

LCD Options

14" (35.56cm), 16:9, HD (1366x768) (Thickness: 3.6mm)/
FHD (1920x1080) (Thickness: 3.0mm)

Video Adapter

Intel GPU (CPU integrated)

Intel HD Graphics 520 (Core i7/i5/i3 CPU)

Dynamic Frequency

Intel Dynamic Video Memory Technology

Microsoft DirectX®12 Compatible

Intel HD Graphics 510 (Pentium/Celeron CPU)

Dynamic Frequency

Intel Dynamic Video Memory Technology

Microsoft DirectX®12 Compatible

Storage

One Changeable 2.5" 7mm (h) SATA HDD/SSD

(Factory Option for Core i7-6500U/i5-6200U/i3-6100U/Celeron 3955U) One M.2 **SATA/PCIe Gen3 x4** Solid State Drive (SSD)

(Factory Option for Pentium 4405U/Celeron 3855U) One M.2 **PCIe Gen2 x2** Solid State Drive (SSD)

Audio

High Definition Audio Compliant Interface

2 * Built-In Speakers

Built-In Microphone

(Factory Option) Built-In Array Microphone

Security

Security (Kensington® Type) Lock Slot

BIOS Password

Intel PTT

Pointing Device

Built-in Touchpad

Keyboard

"WinKey" keyboard (with embedded numeric keypad)

Card Reader

Embedded Multi-In-1 Card Reader
MMC (MultiMedia Card) / RS MMC
SD (Secure Digital) / Mini SD / SDHC/ SDXC

M.2 Slots**(Core i7-6500U/i5-6200U/i3-6100U/Celeron 3955U)**

Slot 1 for **WLAN and Bluetooth** Combo Module
Slot 2 for **SATA/PCIe Gen3 x4 SSD**
(Factory Option) Slot 3 for **3G/4G** Module

M.2 Slots**(Pentium 4405U/Celeron 3855U)**

Slot 1 for **WLAN and Bluetooth** Combo Module
Slot 2 for **PCIe Gen2 x2 SSD**
(Factory Option) Slot 3 for **3G/4G** Module

Interface

One HDMI-Out Port
One External Monitor Port
One Headphone-Out Jack
One Microphone-In Jack
One RJ-45 LAN Jack
One DC-in Jack
Two USB 3.0 Ports
One USB 2.0 Port

Communication

Built-In Gigabit Ethernet LAN
1.0M HD PC Camera Module
(Factory Option) **3G** or **4G** M.2 Module

WLAN/ Bluetooth M.2 Modules:

(Factory Option) Intel® Wireless-AC 8260 Wireless LAN
(802.11ac) + Bluetooth 4.1
(Factory Option) Intel® Wireless-AC 7265 Wireless LAN
(802.11ac) + Bluetooth 4.1
(Factory Option) Intel® Wireless-AC 3165 Wireless LAN
(802.11ac) + Bluetooth 4.0
(Factory Option) Intel® Wireless-N 7265 Wireless LAN
(802.11b/g/n) + Bluetooth 4.0
(Factory Option) Third-Party Wireless LAN (802.11b/g/n) +
Bluetooth 4.0

Environmental Spec**Temperature**

Operating: 5°C - 35°C
Non-Operating: -20°C - 60°C

Relative Humidity

Operating: 20% - 80%
Non-Operating: 10% - 90%

Power

Full Range AC/DC Adapter
AC Input: 100 - 240V, 50 - 60Hz
DC Output: 19V, 2.1A (**40W**)

Removable 4 Cell Smart Lithium-Ion Battery Pack, 32WH
(Factory Option) Removable 4 Cell Smart Lithium-Ion Battery Pack, 44WH
(Factory Option) Removable 3 Cell Smart Lithium-Ion Battery Pack, 24WH

Dimensions & Weight


340mm (w) * 243.5mm (d) * 22.2mm (h)
(Height Excluding Battery Area)
1.8kg (Barebone with 32WH Battery)

Introduction

Figure 1
Top View

1. PC Camera
2. *PC Camera LED
**When the PC camera is in use, the LED will be illuminated in red.*
3. Built-In Microphone
4. LCD
5. Power Button
6. Keyboard
7. Touchpad & Buttons

External Locator - Top View with LCD Panel Open



External Locator - Front & Right Side Views

FRONT VIEW



Figure 2
Front View

1. LED Indicator
- 2.

RIGHT SIDE VIEW



Figure 3
Right Side View

1. USB 2.0 Port
2. Multi-in-1 Card Reader
3. External Monitor Port
4. RJ-45 LAN Jack

Introduction

External Locator - Left Side & Rear View

Figure 4
Left Side View

1. Security Lock Slot
2. DC-In Jack
3. HDMI-Out Port
4. Vent
5. USB 3.0 Ports
6. Microphone-In Jack
7. Headphone-Out Jack

LEFT SIDE VIEW



Figure 5
Rear View

1. Battery

REAR VIEW



External Locator - Bottom View




Figure 6
Bottom View

1. Battery
2. Vent
3. Speakers




Overheating

To prevent your computer from overheating, make sure nothing blocks any vent while the computer is in use.

Introduction

Figure 7
Mainboard Top
Key Parts

Mainboard Overview - Top (Key Parts)



Mainboard Overview - Bottom (Key Parts)




Figure 8
**Mainboard Bottom
Key Parts**


1. KBC-ITE IT8587
2. CPU
3. Memory Slots
DDR3L SO-DIMM
4. CMOS Battery

Introduction

Figure 9
**Mainboard Top
Connectors**

1. DC-In Jack
2. HDMI-Out Port
3. USB Ports 3.0
4. Microphone-In Jack
5. Headphone-Out Jack
6. SIM Card Reader
7. Keyboard Cable Connector

Mainboard Overview - Top (Connectors)



Mainboard Overview - Bottom (Connectors)




Figure 10
**Mainboard Bottom
Connectors**

1. 3G/4G Card Connector
2. M.2 Card Connector
3. WLAN Connector
4. HDD Connector
5. Touchpad Connector
6. Speaker Connector
7. Fan Connector
8. LCD Cable Connector
9. CCD Connector
10. Battery Connector

Chapter 2: Disassembly

Overview

This chapter provides step-by-step instructions for disassembling the *N240JU / N241JU* series notebook's parts and sub-systems. When it comes to reassembly, reverse the procedures (unless otherwise indicated).

We suggest you completely review any procedure before you take the computer apart.

Procedures such as upgrading/replacing the RAM, optical device and hard disk are included in the User's Manual but are repeated here for your convenience.

To make the disassembly process easier each section may have a box in the page margin. Information contained under the figure # will give a synopsis of the sequence of procedures involved in the disassembly procedure. A box with a  lists the relevant parts you will have after the disassembly process is complete. **Note:** The parts listed will be for the disassembly procedure listed ONLY, and not any previous disassembly step(s) required. Refer to the part list for the previous disassembly procedure. The amount of screws you should be left with will be listed here also.

A box with a  will also provide any possible helpful information. A box with a  contains warnings.

An example of these types of boxes are shown in the sidebar.


Information

Warning

Disassembly

NOTE: All disassembly procedures assume that the system is turned **OFF**, and disconnected from any power supply (the battery is removed too).

Maintenance Tools

The following tools are recommended when working on the notebook PC:

- M3 Philips-head screwdriver
- M2.5 Philips-head screwdriver (magnetized)
- M2 Philips-head screwdriver
- Small flat-head screwdriver
- Pair of needle-nose pliers
- Anti-static wrist-strap

Connections

Connections within the computer are one of four types:

Locking collar sockets for ribbon connectors	To release these connectors, use a small flat-head screwdriver to gently pry the locking collar away from its base. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.
Pressure sockets for multi-wire connectors	To release this connector type, grasp it at its head and gently rock it from side to side as you pull it out. Do not pull on the wires themselves. When replacing the connection, do not try to force it. The socket only fits one way.
Pressure sockets for ribbon connectors	To release these connectors, use a small pair of needle-nose pliers to gently lift the connector away from its socket. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.
Board-to-board or multi-pin sockets	To separate the boards, gently rock them from side to side as you pull them apart. If the connection is very tight, use a small flat-head screwdriver - use just enough force to start.

Maintenance Precautions

The following precautions are a reminder. To avoid personal injury or damage to the computer while performing a removal and/or replacement job, take the following precautions:

1. **Don't drop it.** Perform your repairs and/or upgrades on a stable surface. If the computer falls, the case and other components could be damaged.
2. **Don't overheat it.** Note the proximity of any heating elements. Keep the computer out of direct sunlight.
3. **Avoid interference.** Note the proximity of any high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage components and/or data. You should also monitor the position of magnetized tools (i.e. screwdrivers).
4. **Keep it dry.** This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.
5. **Be careful with power.** Avoid accidental shocks, discharges or explosions.
 - Before removing or servicing any part from the computer, turn the computer off and detach any power supplies.
 - When you want to unplug the power cord or any cable/wire, be sure to disconnect it by the plug head. Do not pull on the wire.
6. **Peripherals** – Turn off and detach any peripherals.
7. **Beware of static discharge.** ICs, such as the CPU and main support chips, are vulnerable to static electricity. Before handling any part in the computer, discharge any static electricity inside the computer. When handling a printed circuit board, do not use gloves or other materials which allow static electricity buildup. We suggest that you use an anti-static wrist strap instead.
8. **Beware of corrosion.** As you perform your job, avoid touching any connector leads. Even the cleanest hands produce oils which can attract corrosive elements.
9. **Keep your work environment clean.** Tobacco smoke, dust or other air-born particulate matter is often attracted to charged surfaces, reducing performance.
10. **Keep track of the components.** When removing or replacing any part, be careful not to leave small parts, such as screws, loose inside the computer.

Cleaning

Do not apply cleaner directly to the computer, use a soft clean cloth.

Do not use volatile (petroleum distillates) or abrasive cleaners on any part of the computer.



Power Safety Warning

Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines and power cord). It is advisable to also remove your battery in order to prevent accidentally turning the machine on.

Disassembly Steps

The following table lists the disassembly steps, and on which page to find the related information. **PLEASE PERFORM THE DISASSEMBLY STEPS IN THE ORDER INDICATED.**

To remove the Battery:

1. Remove the battery [page 2 - 5](#)

To remove the HDD:

1. Remove the battery [page 2 - 5](#)
2. Remove the HDD [page 2 - 6](#)

To remove the System Memory:

1. Remove the battery [page 2 - 5](#)
2. Remove the system memory [page 2 - 8](#)

To remove the Keyboard:

1. Remove the battery [page 2 - 5](#)
2. Remove the keyboard [page 2 - 10](#)

To remove the Wireless LAN Module:

1. Remove the battery [page 2 - 5](#)
2. Remove the WLAN [page 2 - 11](#)

To remove the 3G Module:

1. Remove the battery [page 2 - 5](#)
2. Remove the 3G [page 2 - 13](#)

To remove and install the M.2 SSD Module:

1. Remove the battery [page 2 - 5](#)
2. Remove the SSD module [page 2 - 14](#)
3. Install the SSD module [page 2 - 15](#)

To remove the CCD Module:

1. Remove the battery [page 2 - 5](#)
2. Remove the CCD module [page 2 - 16](#)

Removing the Battery

1. Turn **off** the computer, turn it over.
2. Slide the latch **1** in the direction of the arrow (**Figure 1a**).
3. Slide the latch **2** in the direction of the arrow, and hold it in place (**Figure 1b**).
4. While holding the latch **2** in place, pull the battery **3** up in the direction of the arrow **4** and lift it out (**Figure 1c**).
5. Orientate the new battery **3** as illustrated and align the pins **5** & **6** with the edges of the battery compartment (**Figure 1d**).
6. Turn the battery **3** in the direction of the arrow **7** to insert it into the compartment (**Figure 1e**).
7. Slide the latch **8** in the direction of the arrow into the lock position (**Figure 1f**).






Figure 1
Battery Removal

- a. Slide the latch and hold it in place.
- b. Turn the battery in the direction of the arrow.
- c. Lift the battery out.
- d. Insert a new battery by aligning the pins.
- e. Turn the battery in the direction of the arrow.
- f. Lock the latch in place.



Disassembly

Figure 2
**HDD Assembly
Removal**


- Remove the screws.
- Remove the bottom cover.
- Locate the HDD assembly.

Removing the Hard Disk Drive

The hard disk drive can be taken out to accommodate other 2.5" serial (SATA) hard disk drives with a height of 7.0mm (h). Follow your operating system's installation instructions, and install all necessary drivers and utilities (as outlined in **Chapter 4 of the User's Manual**) when setting up a new hard disk.

Hard Disk Upgrade Process

- Turn **off** the computer, turn it over to remove the battery ([page 2 - 5](#)).
- Remove the SD card cover **1** and screws **2** - **18** ([Figure 2a](#)).
- Lift the bottom cover **19** up from point **20** ([Figure 2b](#)).
- The hard disk drive will be visible at point **21** ([Figure 2c](#)).



1. SD Card Cover
19. Bottom Cover
- 17 Screws

HDD System Warning

New HDD's are blank. Before you begin make sure:


You have backed up any data you want to keep from your old HDD.

You have all the CD-ROMs and FDDs required to install your operating system and programs.


If you have access to the internet, download the latest application and hardware driver updates for the operating system you plan to install. Copy these to a removable medium.

5. Slightly lift and pull the hard disk assembly in the direction of arrow 22 (Figure 3d).
6. Lift the hard disk assembly 23 out of the bay 24 (Figure 3e).
7. Remove the screws 25 - 26 and the adhesive cover 27 from the hard disk 28 (Figure 3f).
8. Reverse the process to install a new hard disk (do not forget to replace all the screws and bottom cover).

d.



e.



f.




Figure 3
**HDD Assembly
Removal (cont'd.)**

- d. Slightly lift and pull the HDD assembly in the direction of the arrow.
- e. Lift the HDD assembly out of the bay.
- f. Remove the screws and HDD bracket.



23. HDD Assembly
27. HDD Bracket
28. HDD

- 2 Screws

Disassembly

Figure 4
RAM Module Removal

- The RAM modules will be visible at point **1** on the mainboard.
- Pull the release latches.
- Remove the module.



Contact Warning

Be careful not to touch the metal pins on the module's connecting edge. Even the cleanest hands have oils which can attract particles, and degrade the module's performance.



4. RAM Module



Single Memory Module Installation

If your computer has a single memory module, then insert the module into the **Channel 0 (JDIMM1 / RAM1)** socket.


Removing the System Memory (RAM)

The computer has two memory sockets for 204 pin Small Outline Dual In-line Memory Modules (SO-DIMM) supporting single or dual channel DDR3L depending on the CPU. The main memory can be expanded up to 8GB. The SO-DIMM modules supported are 1024MB and 2048MB **DDR3L** Modules. The total memory size is automatically detected by the POST routine once you turn on your computer.


Memory Upgrade Process

- Turn **off** the computer, turn it over to remove the battery ([page 2 - 5](#)).
- The RAM modules will be visible at point **1** on the mainboard ([Figure 4b](#)).
- Gently pull the two release latches (**2** & **3**) on the sides of the memory socket in the direction indicated by the arrows ([Figure 4b](#)).
- The RAM module **4** will pop-up ([Figure 4c](#)), and you can then remove it.


a.



b.



c.





5. Pull the latches to release the second module if necessary.
6. Insert a new module holding it at about a 30° angle and fit the connectors firmly into the memory slot.
7. The module will only fit one way as defined by its pin alignment. Make sure the module is seated as far into the slot as it will go. DO NOT FORCE IT; it should fit without much pressure.
8. Press the module in and down towards the mainboard until the slot levers click into place to secure the module.
9. Replace the bottom case and the screws (see [page 2 - 5](#)).
10. Restart the computer to allow the BIOS to register the new memory configuration as it starts up.

Disassembly

Figure 5
Keyboard Removal

Removing the Keyboard

1. Turn **off** the computer, turn it over to remove the battery ([page 2 - 5](#)).
 2. Remove screws **1** - **3** from the bottom case ([Figure 5a](#)).
 3. Open it up with the LCD on a flat surface before pressing at point **4** to release the keyboard module while releasing the keyboard in the direction of the arrow **5** as shown ([Figure 5b](#)).
 4. Carefully lift the keyboard **6** up, being careful not to bend the keyboard ribbon cable **7**. Disconnect the keyboard ribbon cable from the locking collar socket **8** ([Figure 5c](#)).
 5. Carefully lift up the keyboard **6** off the computer ([Figure 5d](#)).
 6. Reverse the process to install the keyboard (be careful not to bend the keyboard ribbon cable).
- a.
 - b. Release the keyboard by pressing at point **4**.
 - c. Disconnect the keyboard ribbon cable from the locking collar socket.
 - d. Remove the keyboard.



2. Keyboard

Removing the Wireless LAN Module

1. Turn **off** the computer, turn it over to remove the battery ([page 2 - 5](#)).
2. The Wireless LAN module will be visible at point **1** on the mainboard ([Figure 6a](#)).
3. Carefully disconnect the cables **2** & **3**, and then remove the screw **4** ([Figure 6b](#))
4. The Wireless LAN module **5** ([Figure 6c](#)) will pop-up, and you can remove it from the computer.




Figure 6
**Wireless LAN
Module Removal**

- Locate the WLAN.
- Disconnect the cable and remove the screw.
- The WLAN module will pop up and lift it out of the computer.

Note: Make sure you reconnect the antenna cable to the “1 + 2” socket ([Figure 6b](#)).



5.Wireless LAN Module

- 1 Screw

Disassembly

Wireless LAN, and Combo Module Cables

Note that the cables for connecting to the antennae on WLAN, and WLAN & Bluetooth Combo modules are not labelled. The cables/covers (each cable will have either a black or transparent cable cover) are color coded for identification as outlined in the table below.

Module Type	Antenna Type	Cable Color	Cable Cover Type
WLAN/WLAN & Bluetooth Combo	WM 1	Black	Transparent
	WM 2	Gray	
	WM 3	White	

Cable 1 is usually connected to antenna 1 (Main) on the module, and cable 2 to antenna 2 (Aux).

Removing the 3G Module

3G Module Removal Procedure

1. Turn **off** the computer, remove the battery ([page 2 - 5](#)).
2. Locate the module, it is visible at point **1** ([Figure 7a](#)).
3. Carefully disconnect the cables **2** & **3**, and then remove the screw **4** from the module ([Figure 7b](#)).
4. The module **3** will pop-up ([Figure 7c](#)).
5. Lift the module **5** up and off the computer ([Figure 7d](#)).






Figure 7
3G Module Removal

- Locate the module.
- Disconnect the cables and remove the screw.
- The module will pop-up.
- Lift the module up off the socket.



5. 3G Module

- 1 Screw

Disassembly


Figure 8
M.2 SSD Module Removal

- Locate the M.2 SSD.
- Remove the screw.
- The M.2 SSD module will pop up.

Removing and Installing the M.2 SSD Module

m.2 SSD Removal Procedure

- Turn **off** the computer, turn it over to remove the battery ([page 2 - 5](#)) and bottom cover ([page 2 - 6](#)).
- The M.2 SSD module will be visible at point **1** on the mainboard ([Figure 8a](#)).
- Remove the screw **2** ([Figure 8b](#)).
- The M.2 SSD module **3** ([Figure 8c](#)) will pop-up, and you can remove it from the computer.



3.M2 SATA-1 Module


- 1 Screw

Figure 9
M.2 SSD Module
Installation

- Place the thermal pad.
- Insert the module.
- Tighten the screw.

M.2 SSD Installation Procedure

- Place the thermal pad **1** on the bottom case as shown (**Figure 9a**).
- Insert the module **2** in the computer (**Figure 9b**).
- Tighten the screw **3** to secure it in place (**Figure 9c**).







Disassembly

Figure 10
CCD Removal

- a. Remove the rubber cover and screws.
- b. Remove the hinge cover.
- c. Run your fingers around the inner frame of the LCD panel at the points as indicated by the arrows.
- d. Lay the computer down on a flat surface with the top case up forming a 90 degree angle. Push the LCD front panel upwards before carefully lifting it up.

Removing the CCD

1. Turn **off** the computer, turn it over to remove the battery ([page 2 - 5](#)) and then separate the LCD Panel from the bottom case.
2. Remove the rubber covers **1** and screws **2 - 7** ([Figure 10a](#)).
3. Remove the hinge cover **8** of the panel hinge ([Figure 10b](#)).
4. Run your fingers around the inner frame of the LCD panel at the points as indicated by the arrows **9 - 12**.
5. Lay the computer down on a flat surface with the top case up forming a 90 degree angle. Push the LCD front cover **13** upwards before carefully lifting it up ([Figure 10d](#)).



8. Hinge Cover
13. LCD Front Cover

• 6 Screws

6. Remove the LCD front cover **13** (*Figure 11e*).
7. Disconnect the cable **14** (*Figure 11f*).
8. Remove the CCD module **15** (*Figure 11g*).
9. Reverse the process to install a new CCD module.




Figure 11
CCD Removal
(cont'd.)

- e. Remove the LCD front cover.
- f. Disconnect the cable.
- g. Remove the CCD module.



15. CCD Module

Appendix A:Part Lists

This appendix breaks down the *N240JU / N241JU* series notebook's construction into a series of illustrations. The component part numbers are indicated in the tables opposite the drawings.

Note: This section indicates the *manufacturer's* part numbers. Your organization may use a different system, so be sure to cross-check any relevant documentation.

Note: Some assemblies may have parts in common (especially screws). However, the part lists DO NOT indicate the total number of duplicated parts used.

Note: Be sure to check any update notices. The parts shown in these illustrations are appropriate for the system at the time of publication. Over the product life, some parts may be improved or re-configured, resulting in *new* part numbers.


Part List Illustration Location

The following table indicates where to find the appropriate part list illustration.

Table A - 1
**Part List Illustration
Location**

Part	
Top	<i>page A - 3</i>
Top (TV Tuner)	<i>page A - 4</i>
Bottom	<i>page A - 5</i>
LCD	<i>page A - 6</i>
HDD	<i>page A - 7</i>

Top



ITEM	PART NAME	PART NO	REMARK
1	W/O USA (BLACK) FRAME (US) MODULE V300U	6-79-V330AUBK-010-W	
2	TOP CASE MODULE N240JU	6-39-N24J2-012	
2	TOP CASE MODULE N240JU-C	6-39-N24J2-012-C	
2	TOP CASE MODULE N241JU	6-39-N2412-010	
3	FFC CABLE LED MB 210MM 60V 8PIN N240LU	6-43-N24J0-031	
4	LED BOARD V3.0 N240LU	6-77-N2404-D03	
5	SCREW M2X3.0 K1 BZ ICT NY (OD=4.5,DT=0.4)	6-35-B6120-3RD	
6	RNA BATT CPVS-CHN250 VBA EPVALTDAV PUDO CHN2JY THRD VBAU	6-77-N240JU00-D02A-1D	
6	RNA BATT CPVS-CHN250 VBA EPVALTDAV PUDO CHN2JY THRD VBAU	6-77-N240JU00-D02A-3F	
6	RNA BATT CPVS-CHN250 VBA EPVALTDAV PUDO CHN2JY THRD VBAU	6-77-N240JU00-D02A-1C	
6	RNA BATT CPVS-CHN250 VBA EPVALTDAV PUDO CHN2JY THRD VBAU	6-77-N240JU00-D02A-1E	
6	RNA BATT CPVS-CHN250 VBA EPVALTDAV PUDO CHN2JY THRD VBAU	6-77-N240JU00-D02A-1F	
6	RNA BATT CPVS-CHN250 VBA EPVALTDAV PUDO CHN2JY THRD VBAU	6-77-N240JU00-D02A-1G	
7	TAPE MYLAR (CB)MYLAR M550J	6-40-M55J2-020	
8	FAN MODULE (FORCECON) N250LU	6-31-N2503-101	
9	HEATSINK MODULE N250JU	6-31-N25J3-100	
10	BATTERY 3V 220MA BBBCB2022B (KTS)	6-23-6A2B2-030	
11	SCREW M2X4.0 K1 NI ICT NY (OD=4.5, T=0.5)	6-35-B1120-2RD	
12	W/O THERMAL CONDUCTIVE PASTE (FOR THERMAL PASTE) (FOR THERMAL PASTE) (FOR THERMAL PASTE)	6-88-S210F-9400	
12	W/O THERMAL CONDUCTIVE PASTE (FOR THERMAL PASTE) (FOR THERMAL PASTE) (FOR THERMAL PASTE)	6-88-N240F-4200	
12	W/O THERMAL CONDUCTIVE PASTE (FOR THERMAL PASTE) (FOR THERMAL PASTE) (FOR THERMAL PASTE)	6-88-N170F-5100	
12	W/O THERMAL CONDUCTIVE PASTE (FOR THERMAL PASTE) (FOR THERMAL PASTE) (FOR THERMAL PASTE)	6-88-W95LF-4240	
12	W/O THERMAL CONDUCTIVE PASTE (FOR THERMAL PASTE) (FOR THERMAL PASTE) (FOR THERMAL PASTE)	6-88-W95LF-4220	
12	W/O THERMAL CONDUCTIVE PASTE (FOR THERMAL PASTE) (FOR THERMAL PASTE) (FOR THERMAL PASTE)	6-88-N25JF-4200	
13	SSD M2 2280 SATA3 CRITICAL CT57AKM2000SSD IN2500 SATA3 MLC	6-85-D515A-100	
13	SSD M2 2280 SATA3 CRITICAL CT57AKM2000SSD IN2500 SATA3 MLC	6-85-D51R0-100	
13	SSD M2 2280 SATA3 CRITICAL CT57AKM2000SSD IN2500 SATA3 MLC	6-85-D515B-S00	
13	SSD M2 2280 SATA3 CRITICAL CT57AKM2000SSD IN2500 SATA3 MLC	6-85-D515B-101	
13	SSD M2 2280 SATA3 CRITICAL CT57AKM2000SSD IN2500 SATA3 MLC	6-85-D51R6-S01	
14	FFC CABLE FOR AUDIO TO MB 130MM 60V 4PIN N240LU	6-88-W3306-8830	
14	FFC CABLE FOR AUDIO TO MB 130MM 60V 4PIN N240LU	6-88-W3306-8841	
14	W/O THERMAL CONDUCTIVE PASTE (FOR THERMAL PASTE) (FOR THERMAL PASTE) (FOR THERMAL PASTE)	6-88-S210W-8810	
15	FFC CABLE FOR AUDIO TO MB 130MM 60V 4PIN N240LU	6-43-N24J0-010	
16	CLICK BOARD V4.0 N240LU	6-77-N2402-D04	
17	FFC CABLE CLICK MB 148.5MM 60V 6PIN N240LU	6-43-N24J0-021	
18	FFC CABLE TP CLICK 120MM 60V 8PIN N240LU	6-43-N24J0-061	
19	TP MODULE PROTECT MYLAR (PE+HES+PAGS) N240LU	6-40-N24J2-020	
20	HEATSINK RUBBER SILICONE (74542) N240LU	6-47-N24J2-070	
21	TOUCH PAD SYNAPTICS 84442 TH-5375-001 N240LU	6-49-N2403-010	
22	SPK-CABLE L 23MM 15W 4P 20MM DS-2304-ML-16-IF (CSD) N240LU	6-23-5N250-0L2	
23	SCREW M2X3.0 W45 P30 STEEL ICT NY FOR RMT CARTRIDGE MIDDLE	6-35-ZA120-2R5	
24	SCREW M2.5X6.0 K BZ ICT NY	6-35-82125-6RA	
25	POWER SW BOARD V5.0 N240LU	6-77-N240S-D05	
26	FFC CABLE POWER MB 165.5MM 60V 8PIN N240LU	6-43-N24J0-051	
27	FFC CABLE USB MB 167MM 60V 16PIN N240LU	6-43-N24J0-041	
28	TV RUBBER SILICONE N240JU	6-47-N24J2-020	
29	SPK-CABLE R 23MM 15W 4P 20MM DS-2304-ML-16-IF (CSD) N240LU	6-23-5N250-0R2	
30	SCREW M2X4.0 K1 NI ICT NY (OD=4.5,DT=0.4)	6-35-B1120-4RE	
31	ANTENNA WITH SHIELD W/O LEE 2 P20 1000MHZ/1500MHZ/2450MHZ 1.3MM	6-23-7N250-021	
32	USB BOARD V4.0 N240LU	6-77-N2403-D04	
33	MULTI BOARD V4.0 N240LU	6-77-N2407-D04	
34	W/O HDD ASS'Y N240LU	6-79-N240LU0J-010	
34	W/HDD ASS'Y N240LU	6-79-N240LU0J-020	

Figure A - 1
Top

A.Part Lists

This exploded view diagram illustrates the assembly of the HP Z2 Mini G1 system. The components are numbered 1 through 36, indicating the sequence of assembly. The diagram shows the following parts:

- 1**: Top display panel.
- 2**: Main system board.
- 3**: Keyboard.
- 4**: Trackpoint.
- 5**: Various screws and fasteners used throughout the assembly.
- 6**: Front bezel.
- 7**: Front panel.
- 8**: Optical drive.
- 9**: Bottom bezel.
- 10**: Fan.
- 11**: Various screws and fasteners.
- 12**: Battery.
- 13**: Battery cover.
- 14**: Rear bezel.
- 15**: Bottom plate.
- 16**: Bottom plate.
- 17**: Bottom plate.
- 18**: Bottom plate.
- 19**: Bottom plate.
- 20**: Bottom plate.
- 21**: Bottom plate.
- 22**: Bottom plate.
- 23**: Bottom plate.
- 24**: Bottom plate.
- 25**: Bottom plate.
- 26**: Bottom plate.
- 27**: Bottom plate.
- 28**: Hard drive.
- 29**: Hard drive.
- 30**: Hard drive.
- 31**: Hard drive.
- 32**: Hard drive.
- 33**: Hard drive.
- 34**: Hard drive.
- 35**: Hard drive.
- 36**: Hard drive.

ITEM	PART NAME	PART NO	REMARK
1	WING K/9 USA BLACKOUT FRAME 035 MODULE V330AU	6-79-V330AUJK-010-W	
2	TOP CASE MODULE N240JU	6-39-N240J2-D12	
2	TOP CASE MODULE N240JU-C	6-39-N24J2-D12-C	
3	FFC CABLE LED M2 210MM 60V 6PIN N240JU	6-43-N24JU-031	
4	LED BOARD V3.0 N240LU	6-77-N2404-D03	
5	SCREW M2X4L KI BZ ICT NY (CD=44.5,D1=0.4)	6-35-B6120-3RD	
6	W/NO HDD CAVITY-SHOCKED 1EN CPV14L1P2000 D040U1 N240	6-77-N240JU00-102A-D	
6	W/NO HDD CAVITY-SHOCKED 1EN CPV14L1P2000 D040U1 N240	6-77-N240JU00-102A-D	
7	TAPE MYLAR (B),MYLAR M550J	6-40-M55J2-020	
8	FAN MODULE (FORCECON) N250LU	6-31-N250J3-101	
9	HEATSINK MODULA N250JU	6-31-N25J3-100	
10	BATTERY 3V 220MA BBBC92032B (KTS)	6-23-6A2B2-030	
11	SCREW M2X2L KI NI ICT NY (CD=45 ,T=0.5)	6-35-B1120-2R0	
12	W/NO HDD CAVITY-SHOCKED 1EN CPV14L1P2000 D040U1 N240	6-88-S210F-9400	
12	W/NO HDD CAVITY-SHOCKED 1EN CPV14L1P2000 D040U1 N240	6-77-N240JU00-102A-D	
12	W/NO HDD CAVITY-SHOCKED 1EN CPV14L1P2000 D040U1 N240	6-88-N170F-5100	
12	W/NO HDD CAVITY-SHOCKED 1EN CPV14L1P2000 D040U1 N240	6-88-W95LF-4240	
12	W/NO HDD CAVITY-SHOCKED 1EN CPV14L1P2000 D040U1 N240	6-88-S210F-9420	
12	W/NO HDD CAVITY-SHOCKED 1EN CPV14L1P2000 D040U1 N240	6-88-N25JF-4200	
13	SSD M2 2280 SATA3 CRUCIAL CPESM5800A4 M2SD0 SATA3 MLC	6-85-D515A-100	
13	SSD M2 2280 SATA3 CRUCIAL CPESM5800A4 M2SD0 SATA3 MLC	6-85-D51R0-100	
13	SSD M2 2280 SATA3 CRUCIAL CPESM5800A4 M2SD0 SATA3 MLC	6-85-D515B-S00	
13	SSD M2 2280 SATA3 CRUCIAL CPESM5800A4 M2SD0 SATA3 MLC	6-85-D515B-101	
13	SSD M2 2280 SATA3 CRUCIAL CPESM5800A4 M2SD0 SATA3 MLC	6-85-D51R6-S01	
14	LE 4K 60FPS HDR ANTIDRIFTING 1EN CPV14L1P2000 D040U1 N240	6-88-W3306-8830	
14	LE 4K 60FPS HDR ANTIDRIFTING 1EN CPV14L1P2000 D040U1 N240	6-88-W3306-8840	
14	W/NO HDD CAVITY-SHOCKED 1EN CPV14L1P2000 D040U1 N240	6-88-S210W-8810	
15	FFC CABLE FOR AUDIO TO M2 130MM 60V 40PIN N240JU	6-43-N24JU-021	
16	CLICK BOARD V4.0 N240LU	6-77-N2402-D104	
17	FFC CABLE CLICK M2 140MM 60V 6PIN N240JU	6-43-N24JU-021	
18	FFC CABLE TP CLICK 120MM 60V 6PIN N240JU	6-43-N24JU-061	
19	TP MODULE PROTECT MYLAR PET-ETHANOL N240LU	6-40-N24J2-020	
20	W/NO HDD CAVITY-SHOCKED 1EN CPV14L1P2000 D040U1 N240	6-77-N240J2-031	
21	TOUCH PAD SYNAPTICS BAA421 1EN B3375-70-010 N240LU	6-49-N2403-010	
22	SPRINKLER 1.2MM 15W 4 25MM 10V 25MA 4-4F 1EN N240LU	6-23-SN250-0R2	
23	SCREW M2X5 0.85 P40 STEEL ICT NY FOR MET COORDINATE MATERIAL	6-35-ZA120-2L5	
24	SCREW M2.5X6L K BZ ICT NY	6-35-82125-6RA	
25	POWER SW BOARD V5.0 N240LU	6-77-N240S-005	
26	FFC CABLE POWER M2 165MM 60V 6PIN N240JU	6-43-N24JU-051	
27	DIGITAL TV TUNER AVERMEDIA SV5 A857 W940TU	6-88-W9407-4600	
28	W/O HDD ASS'Y N240LU	6-79-N240LU0J-010	
28	W/HDD ASS'Y N240LU	6-79-N240LU0J-020	
29	SPRINKLER 1.2MM 15W 4 25MM 10V 25MA 4-4F 1EN N240LU	6-23-SN250-0R2	
30	SCREW M2X4L KI NI ICT NY (CD=44.5,D1=0.4)	6-35-B1120-4RE	
31	ANTENNA PAPER SATE W/LE-2 P23 D040M5800A4 M2SD0 SATA3 MLC	6-23-7N250-021	
32	USB BOARD V4.0 N240LU	6-77-N2403-D04	
33	MULTI BOARD V4.0 N240LU	6-77-N2407-D04	
34	FFC CABLE USB M2 167MM 60V 16PIN N240JU	6-43-N24JU-041	
35	TV TUNER MYLAR PET N240JU	6-40-N24J2-070	
36	HEATSINK RUBBER SILICONE (A45X42) N240JU	6-47-N24J2-070	

Bottom





Figure A - 3
Bottom

ITEM	PART NAME	PART NO	REMARK
1	SWAP S (L) BATTERY/SENSOR/PCB/SENSOR (L) GAGE (L) (TEXTURED) SENSOR/PCB/SENSOR	6-87-N24JS-42F2	
1	SWAP S (L) BATTERY/SENSOR/PCB/SENSOR (L) GAGE (L) (TEXTURED) SENSOR/PCB/SENSOR	6-87-N24JS-4UF2-1	
1	SWAP S (L) BATTERY/SENSOR/PCB/SENSOR (L) GAGE (L) (TEXTURED) SENSOR/PCB/SENSOR	6-87-N24JS-42F2-1	
1	SWAP S (L) BATTERY/SENSOR/PCB/SENSOR (L) GAGE (L) (TEXTURED) SENSOR/PCB/SENSOR	6-87-N24JS-4UF2	
1	SWAP S (L) BATTERY/SENSOR/PCB/SENSOR (L) GAGE (L) (TEXTURED) SENSOR/PCB/SENSOR	6-87-N24JS-42L2	
1	SWAP S (L) BATTERY/SENSOR/PCB/SENSOR (L) GAGE (L) (TEXTURED) SENSOR/PCB/SENSOR	6-87-N24JS-4EB2	
2	BOTTOM CASE MODULE N240JU	6-39-N24J3-012	
2	BOTTOM CASE MODULE N240LU-C	6-39-N2403-011-C	
3	SCREW M2.5*6L K BZ ICT NY	6-35-82125-6RA	
4	PRODUCT LABEL FOR N240JU	6-45-N240JU03-010	
4	PRODUCT LABEL FOR N241JU	6-45-N241JU03-010	
5	BATTERY SD PSUM PUSH TYPE PC4MS (7220P-7010C) W9703W	6-42-W9708-010	

LCD

Figure A - 4
LCD



ITEM	PART NAME	PART NO	REMARK
1	FRONT COVER PROTECT MYLAR (PET+3M 891S) N240JU	6-40-N24J1-021	
2	CCD LENS PC P750ZM	6-42-P7501-011	
3	FRONT COVER MODULE N240JU	6-39-N24J1-012	
4	SCREW M2*3L KI BZ ICT NY (DD=04.5,DT=0.4)	6-35-B6120-3RD	
5	LCD 14.0" HD EDP/GLARE TYPE BDE HBR40W03-301 (LED) 360MM	6-50-J8136-Z01	
5	LCD 14.0" HD (EEP) GLARE TYPE AU B40XTN03.4 (LED) 360MM	6-50-J8136-G12	
5	LCD 14.0" HD+ CHIMET NI40FGE-EAR (LED) 360MM (EDP)	6-50-JA130-D00	
5	LCD 14.0" FHD IPS (EEP) LG LP140WV1-SPK1 (LED) 360MM	6-50-JB230-L01	
6	LCD HINGE L (SGCC+SK7) SH N240JU	6-33-N24J1-0L2	
7	ANTENNA PEPA 3414 VET L1E+ PCB 040606/0506/0606/0606 L=600MM N240JU	6-23-7N250-010	
8	BACK COVER MODULE N240JU	6-39-N24J1-022	FOR N240JU/LU
8	BACK COVER MODULE N240LU-C	6-39-N2401-020-C	FOR N240JU-C/LU-C
8	BACK COVER MODULE N241JU	6-39-N2411-020	FOR N241JU/LU
9	BACK COVER PROTECT MYLAR (PET+3M 891S) N240JU	6-40-N24J1-031	
10	AVC CAMERA 320W FTV D00V010C-30 IN HD HIND HISS VPHU FV320 V420 VPH-MC	6-88-W94LC-4910	
10	AVC CAMERA 320W FTV D00V010C-30 IN HD HIND HISS VPHU FV320 V420 VPH-MC	6-88-W94LC-5120	OPTION
10	AVC CAMERA 320W FTV D00V010C-30 IN HD HIND HISS VPHU FV320 V420 VPH-MC	6-88-W94LC-4900	OPTION
10	AVC CAMERA 320W FTV D00V010C-30 IN HD HIND HISS VPHU FV320 V420 VPH-MC	6-88-W94LC-5110	OPTION
10	AVC CAMERA 320W FTV D00V010C-30 IN HD HIND HISS VPHU FV320 V420 VPH-MC	6-88-W94LC-4911	OPTION
10	AVC CAMERA 320W FTV D00V010C-30 IN HD HIND HISS VPHU FV320 V420 VPH-MC	6-88-W94LC-4901	OPTION
11	WIRE CABLE FOR CCD D-MIC 5000MM 3.3V BP (HL) N250LU	6-43-N250T-010	
12	SCREW M2.5*4L KI NI ICT NY	6-35-21125-4R0	
13	ANTENNA PEPA 3414 VET L1E+ PCB 040606/0506/0606/0606 L=600MM N240JU	6-23-7N240-010	
14	LCD HINGE MYLAR (MYLAR+3M 468) (75*75*0.47) N240JU	6-40-N24J1-010	
15	TDP CASE MYLAR FR83 25*7*0.05 P180H-M	6-40-P1802-030	
16	ANTENNA PEPA 3414 VET L1E+ PCB AL 246/502 V13-600MM P810H	6-23-7P870-010	
17	LCD HINGE R (SGCC+SK7) SH N240JU	6-33-N24J1-0R2	
18	WIRE CABLE FOR EDP 200MM 1V 40PIN (D) 0412C CONJL0903-HV N240JU	6-43-N2401-011-L	
19	FRONT COVER SCREW MYLAR(PET+3M468)05040351 N150SD	6-40-N1501-010	
20	LCD BOTTOM RUBBER (SILICON RUBBER 80X5*0.87) N240JU	6-47-N24J1-010	
21	BACK HINGE COVER L (TEIJUN TN-3713BX) N240JU	6-42-N24J1-0L1	
22	BACK HINGE COVER R (TEIJUN TN-3713BX) N240JU	6-42-N24J1-0R1	
23	SCREW M2*4L KI NI ICT NY (DD=04.5,DT=0.4)	6-35-B1120-4RE	

HDD




Figure A-5
HDD

Appendix B: Schematic Diagrams

This appendix has circuit diagrams of the *N240JU* / *N241JU* notebook's PCB's. The following table indicates where to find the appropriate schematic diagram.

Diagram - Page	Diagram - Page	Diagram - Page
<i>System Block Diagram - Page B - 2</i>	<i>DDR3 SO-DIMM_1 - Page B - 15</i>	<i>VDDQ_VTT, 1.5VS, 1.8VS - Page B - 28</i>
<i>Processor 1/11 - Page B - 3</i>	<i>HDMI - Page B - 16</i>	<i>1.0V Series - Page B - 29</i>
<i>Processor 2/11 - Page B - 4</i>	<i>Panel - Page B - 17</i>	<i>VCORE, VCCGT, VCCSA, VCCIO - Page B - 30</i>
<i>Processor 3/11 - Page B - 5</i>	<i>Conn, CCD, Fan, T/P, TV - Page B - 18</i>	<i>NCP81206 Regulator - Page B - 31</i>
<i>Processor 4/11 - Page B - 6</i>	<i>PS8625 - Page B - 19</i>	<i>Charger, DC-In - Page B - 32</i>
<i>Processor 5/11 - Page B - 7</i>	<i>SATA, LED, KB, G-Sensor - Page B - 20</i>	<i>USB Board - Page B - 33</i>
<i>Processor 6/11 - Page B - 8</i>	<i>USB, TPM - Page B - 21</i>	<i>CRT - Page B - 34</i>
<i>Processor 7/11 - Page B - 9</i>	<i>WLAN/BT, 3G/mSATA - Page B - 22</i>	<i>RTL8411B - Page B - 35</i>
<i>Processor 8/11 - Page B - 10</i>	<i>NGFF_M SSD - Page B - 23</i>	<i>Power SW Board - Page B - 36</i>
<i>Processor 9/11 - Page B - 11</i>	<i>Audio Codec - Page B - 24</i>	<i>Click Board - Page B - 37</i>
<i>Processor 10/11 - Page B - 12</i>	<i>KBC ITE IT8587 - Page B - 25</i>	<i>LED Board - Page B - 38</i>
<i>Processor 11/11 - Page B - 13</i>	<i>3V, 5V, 3VS, 5VS, CTL Signal - Page B - 26</i>	<i>HDD Board - Page B - 39</i>
<i>DDR3 SO-DIMM_0 - Page B - 14</i>	<i>VDD3, VDD5 - Page B - 27</i>	

Table B - 1
**SCHEMATIC
DIAGRAMS**




Version Note


The schematic diagrams in this chapter are based upon version 6-7P-N24J7-003. If your mainboard (or other boards) are a later version, please check with the Service Center for updated diagrams (if required).

System Block Diagram

Sheet 1 of 38
System Block
Diagram




Processor 1/11




Schematic Diagrams

Processor 2/11

Sheet 3 of 38
Processor 2/11




Processor 3/11




Sheet 4 of 38
Processor 3/11

Processor 4/11

Sheet 5 of 38
Processor 4/11




Processor 5/11 B - 7



Processor 6/11

Sheet 7 of 38
Processor 6/11




Sheet 8 of 38
Processor 7/11




Processor 8/11

Sheet 9 of 38
Processor 8/11



Processor 9/11

Sheet 10 of 38
Processor 9/11

Processor 10/11

B. Schematic Diagrams

放置cpu 背面

放置cpu TOP 周圍 電源輸入處

(For 28W 上件)

U19M SKL_ULT

CPU POWER 2 OF 4

31 A

31 A

SHORT

J17

*OPEN-3mm

FOR 28W 才需上件

VCCGT SENSE


VSSGT SENSE

13 OF 20

SKL_ULT REV = 1


[29,30] VCCGT

Processor 11/11

Sheet 12 of 38
Processor 11/11


DDR3 SO-DIMM_0

Sheet 13 of 38
DDR3 SO-DIMM_0



HDMI


Sheet 15 of 38
HDMI




Schematic Diagrams

Conn, CCD, Fan, T/P, TV

Sheet 17 of 38
Conn, CCD, Fan, T/
P, TV



PS8625




Sheet 18 of 38
PS8625


Schematic Diagrams

SATA, LED, KB, G-Sensor


Sheet 19 of 38
SATA, LED, KB,
G-Sensor



USB, TPM

Sheet 20 of 38
USB, TPM

WLAN/BT, 3G/mSATA




NGFF_M SSD B - 23



Audio Codec

Sheet 23 of 38
Audio Codec




Sheet 24 of 38
KBC ITE IT8587


Schematic Diagrams

3V, 5V, 3VS, 5VS, CTL Signal

Sheet 25 of 38
3V, 5V, 3VS, 5VS,
CTL Signal




VDD3, VDD5 B - 27




Schematic Diagrams

VDDQ_VTT, 1.5VS, 1.8VS




Sheet 27 of 38
VDDQ_VTT, 1.5VS,
1.8VS

VCORE, VCCGT, VCCSA, VCCIO




NCP81206 Regulator



Schematic Diagrams

Charger, DC-In

Sheet 31 of 38
Charger, DC-In




Sheet 32 of 38
USB Board




Schematic Diagrams

CRT

Sheet 33 of 38
CRT


RTL8411B




Schematic Diagrams

Power SW Board

Sheet 35 of 38
Power SW Board



Click Board




Sheet 36 of 38
Click Board

B.Schematic Diagrams


Schematic Diagrams

LED Board

Sheet 37 of 38
LED Board



HDD Board

Sheet 38 of 38
HDD Board

Appendix C: Updating the FLASH ROM BIOS

To update the FLASH ROM BIOS, you must:

- Download the BIOS update from the web site.
- Unzip the files onto a bootable CD/DVD/USB Flash Drive.
- Reboot your computer from an external CD/DVD/USB Flash Drive.
- Use the flash tools to update the flash BIOS using the commands indicated below.
- Restart the computer booting from the HDD and press **F2** at startup enter the BIOS.
- Load setup defaults from the BIOS and save the default settings and exit the BIOS to restart the computer.
- After rebooting the computer you may restart the computer again and make any required changes to the default BIOS settings.

Download the BIOS

1. Go to www.clevo.com.tw and point to **E-Services** and click **E-Channel**.
2. Use your user ID and password to access the appropriate download area (BIOS), and download the latest BIOS files (the BIOS file will be contained in a batch file that may be run directly once unzipped) for your computer model (see sidebar for important information on BIOS versions).

Unzip the downloaded files to a bootable CD/DVD/ or USB Flash drive

1. Insert a bootable CD/DVD/USB flash drive into the CD/DVD drive/USB port of the computer containing the downloaded files.
2. Use a tool such as Winzip or Winrar to unzip all the BIOS files and refresh tools to your bootable CD/DVD/USB flash drive (you may need to create a bootable CD/DVD with the files using a 3rd party software).

Set the computer to boot from the external drive

1. With the bootable CD/DVD/USB flash drive containing the BIOS files in your CD/DVD drive/USB port, restart the computer and press **F2** (in most cases) to enter the BIOS.
2. Use the arrow keys to highlight the **Boot** menu.
3. Use the “+” and “-” keys to move boot devices up and down the priority order.
4. Make sure that the CD/DVD drive/USB flash drive is set first in the boot priority of the BIOS.
5. Press **F4** to save any changes you have made and exit the BIOS to restart the computer.



BIOS Version

Make sure you download the latest correct version of the BIOS appropriate for the computer model you are working on.

You should only download BIOS versions that are **V1.01.XX or higher** as appropriate for your computer model.

Note that BIOS versions are not backward compatible and therefore **you may not downgrade your BIOS to an older version** after upgrading to a later version (e.g if you upgrade a BIOS to ver 1.01.05, you **MAY NOT** then go back and flash the BIOS to ver 1.01.04).

BIOS Update

Use the flash tools to update the BIOS

1. Make sure you are not loading any memory management programs such as HIMEM by holding the **F8** key as you see the message “**EFI Shell**”. You will then be prompted to give “**Y**” or “**N**” responses to the programs being loaded by EFI Shell. Choose “**N**” for any memory management programs.
2. You should now see **DISK fsX:\>** (X is the designated drive number for the CD/DVD drive/USB flash drive).
3. **Type the following command:**

fsX:\> Flash.nsh

4. The utility will then proceed to flash the BIOS.
5. You should then be prompted to press any key to restart the system or turn the power off, and then on again but make sure you remove the CD/DVD/USB flash drive from the CD/DVD drive/USB port before the computer restarts.

Restart the computer (booting from the HDD)

1. With the CD/DVD/USB flash drive removed from the CD/DVD drive/USB port the computer should restart from the HDD.
2. Press **F2** as the computer restarts to enter the BIOS.
3. Use the arrow keys to highlight the **Exit** menu.
4. Select **Load Setup Defaults** (or press **F3**) and select “**Yes**” to confirm the selection.
5. Press **F4** to save any changes you have made and exit the BIOS to restart the computer.

Your computer is now running normally with the updated BIOS

You may now enter the BIOS and make any changes you require to the default settings.